

Vendor	Device Model
AU	iPad Air (GSM)
AU	iPad mini
AU	Memory Card
AU	SHL21 Aquos Phone Sharp
AU	E30HT
AU	W61T
AU	W62T
AU	W47T
AU	W41H
AU	W52K(MEDIA SKIN)
AU	W44S
AU	S001(Cyber-shot)
AU	W41SH
AU	W52SH
AU	W62SH
AU	W64SH
AU	SH003(AQUOS SHOT)
AU	W42H
AU	W52H
AU	W61H
AU	H001
AU	W43K
AU	W53K
AU	W62K
AU	W63K
AU	W51S
AU	W54S
AU	W65S(Xmini)
AU	S004(BRAVIA)
AU	W51CA
AU	W61CA
AU	CA003(EXILIM)
AU	W51P
AU	W52P
AU	W61P
AU	P001
AU	W33SA2
AU	W41T
AU	W43T
AU	W62PT
AU	W41SA
AU	W41K
AU	W51SH
AU	W61SH(AQUOS)
AU	W63SH(URBANO)
AU	SH001
AU	W42S
AU	W52S
AU	W51H
AU	W53H(Wooo)
AU	SHY01(Sportio water beat)
AU	W43S
AU	W53S
AU	W61S(Cyber-shot)

AU	W43SA
AU	W53SA
AU	W62SA
AU	W52T
AU	W56T
AU	W64T
AU	W42CA(G'zOne)
AU	W52CA
AU	W62CA(G'zOne)
AU	W45T
AU	W51T
AU	W54T
AU	W55T
AU	W63T(Sportio)
AU	T002
AU	TSY01(biblio)
AU	W61SA
AU	W44T
AU	W53T
AU	W65T
AU	W42SA
AU	W54SA
AU	W63SA
AU	SA001
AU	W43CA
AU	W53CA
AU	W63CA(EXILIM)
AU	W63S(re)
AU	W44K
AU	W51K
AU	W61K
AU	W51SA
AU	W55SA(INFOBAR2)
AU	W64SA
AU	K003
AU	W64K
AU	W44K2
AU	TSX04(PLY)
AU	HIY02(beskey)
AU	W52SA
AU	SOY01(Premier3)
AU	E08T
AU	W46T(DRAPE)
AU	T003
AU	K001
AU	K002
AU	E07K
AU	KYX03(PRISMOID)
AU	T004
AU	W33SA
AU	W63H
AU	HIY01(Mobile Hi-Vision CAM Wooo)
AU	SH002(AQUOS SHOT)
AU	SH004
AU	SH005

AU	SH007(AQUOS SHOT)
AU	CA001
AU	CA002(G'zOne)
AU	CA004(EXILIM)
AU	W41CA
AU	W65K
AU	K004
AU	NS01
AU	KYX02(misora)
AU	W41S
AU	W62S
AU	W64S
AU	SOX01(G9)
AU	TSX05(LIGHT POOL)
AU	SOY02(BRAVIA U1)
AU	SOY03(URBANO BARONE)
AU	K005
AU	W62P
AU	CA005(EXILIM)
AU	SH006(AQUOS SHOT)
AU	S003(Cyber-shot)
AU	S002
AU	E05SH
AU	E06SH
AU	KYX04(lotta)
AU	W43H
AU	W43H2
AU	T001
AU	NS02
AU	SA002
AU	W62H(Wooo)
AU	SH008(AQUOS SHOT)
AU	W42K
AU	W42T(neon)
AU	IS02
AU	K006
AU	IS01
AU	IS03
AU	SH009
AU	SH010(AQUOS SHOT)
AU	T005
AU	TSX06(X-RAY)
AU	CA006(EXILIM)
AU	CAY01(G'zOne Type-X)
AU	SOY04(URBANO MOND)
AU	S005(BRAVIA)
AU	IS06(SIRIUS)
AU	K007
AU	K008
AU	SH011
AU	S006(Cyber-shot)
AU	SOX02(G11)
AU	T006
AU	PT002
AU	CA007

AU	K009
AU	K010
AU	S007
AU	T007
AU	T008
AU	IS11CA(G'zOne)
AU	IS05
AU	IS11SH
AU	IS12SH
AU	IS11S XPERIA acro
AU	IS04(REGZA Phone)
AU	ISW11HT(EVO WiMAX)
AU	iPhone 4S
AU	SOY05(URBANO AFFARE)
AU	IS11N(MEDIAS BR)
AU	ISW11K(DIGNO)
AU	IS11T(REGZA Phone)
AU	IS11PT(MIRACH)
AU	ISW11F(ARROWS Z)
AU	IS12F(ARROWS ES)
AU	IS13SH
AU	IS14SH AQUOS
AU	A01(INFOBAR)
AU	A02 HTX21 KDDI INFOBAR
AU	ISW11M PHOTON
AU	ISW12HT(EVO 3D)
AU	SHX12 InfoBar C01
AU	F001
AU	IS12S(XPERIA acroHD)
AU	IS11LG [Optimus X]
AU	IS12M (XT909)
AU	KYY04 Urbano Progresso
AU	ISW16SH
AU	IS17SH AQUOS
AU	ISW13HT
AU	K011
AU	IS15SH AQUOS
AU	ISW13F
AU	iPhone 5 (USB cable)
AU	iPhone 5 (Bluetooth (fast phonebook))
AU	iPhone 5S (USB cable)
AU	iPhone 5S (Bluetooth (fast phonebook))
AU	iPhone 5C (USB cable)
AU	iPhone 5C (Bluetooth (fast phonebook))
AU	K012
AU	PT003
AU	HTL21
AU	KYL21 Digno S
AU	CAL21 G'zOne
AU	PTL21 VEGA
AU	FJL21 ARROWS
AU	ISW11SC(GALAXY S2)
AU	SCL21 Galaxy S III
AU	SOL21 Xperia
AU	L01 UBANO (KYY21)

AU	SHL22
AU	SOL22 Xperia UL
AU	HTL22
AU	SHT21 (AQUOS PAD)
AU	FJL22 (ARROWS Z)
AU	SCL22 (Galaxy Note3)
AU	LGL22 (isai)
AU	KYL22 (DIGNO M)
AU	SHL23
AU	SOL23 (XPERIA Z1)
AU	LGL21
AU	KYY08 (MARVERA)
AU	L02(URBANO)
AU	SHL24(AQOUS PHONE SIRIE)
AU	SOL24(XPERIA Ultra)
AU	LGL23(G Flex)
AU	SHL25
AU	SOL25
AU	L03
AU	iPhone 6
AU	iPhone 6 Plus
AU	SOT21 (XPERIA Z2 Tablet)
AU	SCL23 (Galaxy S5)
AU	SCL24 (Galaxy Note Edge)
AU	G01 (TORQUE)
AU	SCT21 Galaxy Tab S 10.5
AU	KYL23
AU	KYV32 (BASIO)
AU	KYV33 (INFOBAR A03)
AU	KYV34 (URBANO V02)
AU	SHF31 (AQUOS K)
AU	SCV31 (Galaxy S6 Edge)
AU	HTL23 (HTC J butterfly)
AU	HTV31 (HTC J butterfly)
AU	SOV31 (Xperia Z4)
AU	SOL26 (Xperia Z3)
AU	SHT22 (AQUOS PAD)
AU	LGL24 (isai FL)
AU	LGV31 (isai VL)
AU	KYV31 (URBANO V01)
AU	FJT21 (ARROWS Tab)
AU	KYY06
AU	KYY09
AU	KYY10
AU	SHV31 (AQUOS SERIE mini)
AU	iPhone 6s
AU	iPhone 6s Plus
AU	iPhone SE
AU	iPhone 7 Plus
AU	SOV32 (Xperia Z5)
AU	KYV37 (Qua phone)
AU	HWT31 (Qua tab 02)
AU	KYF31 (GRATINA 4G)
AU	SCV33 (Galaxy S7 Edge)
AU	HTV32 (HTC10)

AU	SHV34 (AQUOS SERIE)
AU	SOV33 (Xperia X Performance)
AU	SCV32(Galaxy A8)
AU	KYT31(Qua tab 01)
AU	KYV36(DIGNO rafre)
AU	KYF32
AU	SHF32(AQUOS K)
AU	KYF33(TORQUE X01)
AU	SOT31(Xperia Z4 Tablet)
AU	LGV33(Qua phone PX)
AU	SHV36(BASIO2)
AU	KYV38(URBANO V03)
AU	LGT32(Qua tab PZ)
AU	KYV39(miraie f)
AU	SHV38(AQUOS SERIE mini)
AU	KYF36
AU	KYV40 (rafre)
AU	SOV35 (Xperia XZs)
AU	KYV41(TORQUE G03)
AU	KYV42(Qua phone QX)
AU	KYF35(MARVERA)
AU	SHV39(AQUOS R)
AU	SCV36(Galaxy S8)
AU	SCV35(Galaxy S8+)
AU	HTV33(HTC U11)
AU	SHF33(AQUOS K)
AU	KYV35(TORQUE G02)
AU	SOV34(Xperia XZ)
AU	LGV34
AU	SHV37
AU	SHV40(AQUOS sense)
AU	SOV36(Xperia XZ1)
AU	SCV37(Galaxy Note8)
AU	SHF34(AQUOS K)
AU	SHV41(AQUOS R compact)
AU	KYF37(GRATINA)
AU	KYV43(BASIO3)
AU	KYV44(Qua phone QZ)
AU	LGV35(isai V30+)
AU	KYT32(Qua tab QZ8)
AU	KYT33(Qua tab QZ10)
AU	SCV38(Galaxy S9)
AU	SCV39(Galaxy S9+)
AU	SOV37(Xperia XZ2)
AU	SHV42(AQUOS R2)
AU	HWV32(P20 lite)
AU	SOV38(Xperia XZ2 Premium)
AU	KYF38
AU	KYX31(INFOBAR xv)
AU	SCV40(Galaxy Note9)
AU	SOV39(Xperia XZ3)
AU	SHV43(AQUOS sense2)
AU	LGV36(LG it)
AVEA	inTouch2
AVEA	InTouch4

AceMobile	LONDON
AceMobile	Cali
AceMobile	Monterrey
Acer	S100 Liquid
Acer	T06 Liquid Zest
Acer	T07 Liquid Zest 4G
Acer	T11 Liquid Z6 Plus
Acer	S100 Liquid E (Rogers)
Acer	E101 beTouch
Acer	Z110 Liquid
Acer	Z120 Liquid Z2
Acer	S120 Liquid Metal
Acer	Z130 Liquid Z3
Acer	Z150 Liquid Z5
Acer	Z160 Liquid Z4
Acer	S200 F1 neoTouch
Acer	E210 Betouch
Acer	Z220 Liquid
Acer	Z320 Liquid
Acer	M220 Liquid (USB)
Acer	M220 Liquid (BT)
Acer	E310 Liquid mini
Acer	C6 Liquid Express
Acer	E320 Liquid Express
Acer	E330 Liquid Glow
Acer	E350 Liquid Gallant Duo
Acer	V360 Liquid E1
Acer	V370 Liquid E2
Acer	E380 Liquid E3
Acer	E400 BeTouch
Acer	Z410 Liquid
Acer	A500 Iconia Tab
Acer	S510 Liquid S1
Acer	Z330 Liquid
Acer	Z520 Liquid
Acer	S500 CloudMobile
Acer	E600 Liquid
Acer	B1-730 Iconia One 7
Acer	B1-770 Iconia One 7
Acer	A1-840FHD Iconia Tab 8
Acer	B3-A30 Tab One 10
Airtyme	SAF3011
Alba	ACF18_DS
Alba	ACF28 2.8
Alba	AC40DTI
Alba	8in
Alba	AC70PLV5 7
Alcatel	EVO 7 One Touch
Alcatel	Bic Phone
Alcatel	KPN Hi Messenger
Alcatel	STARADDICT II
Alcatel	Infinity POP
Alcatel	A450TL Pixi Charm
Alcatel	A621BL One Touch Pixi Glory
Alcatel	A460G Pixi Pulsar

Alcatel	A460T Pixi 3(4)
Alcatel	A463BG Pixi Glitz
Alcatel	A464BG One Touch
Alcatel	A466BG PIXI Unite
Alcatel	A564C One Touch Pop Icon
Alcatel	A845L One Touch Pop Star
Alcatel	A846L One Touch Pop Icon
Alcatel	A851L OneTouch Sonic
Alcatel	A521L One Touch Pop Star LTE 2
Alcatel	A564R One Touch Pop Icon
Alcatel	P310A Pop 7
Alcatel	P330X One Touch POP 7S
Alcatel	CP-100 One Touch (Carphone)
Alcatel	OT-103A
Alcatel	OT-105
Alcatel	OT-108
Alcatel	OT-322
Alcatel	SFR 121
Alcatel	SFR 122
Alcatel	316A One Touch
Alcatel	319 One Touch BIC V4
Alcatel	V155 Gun Grey
Alcatel	One Touch 361
Alcatel	CP200 Voyager
Alcatel	OT-203
Alcatel	A205G-B
Alcatel	A206G
Alcatel	OT-206
Alcatel	A207BG
Alcatel	OT-208
Alcatel	OT-209
Alcatel	OT-216
Alcatel	OT-S218
Alcatel	OT-222
Alcatel	232 One Touch
Alcatel	OT-255
Alcatel	OT-280
Alcatel	OT-305
Alcatel	OT-305A
Alcatel	OT-308A One Touch
Alcatel	OT-311
Alcatel	OT-S319
Alcatel	OT-330
Alcatel	OT-355
Alcatel	OT-355 (Phone House)
Alcatel	OT-355A
Alcatel	OT-358 One Touch
Alcatel	OT-363
Alcatel	A382G
Alcatel	OT-385 One Touch
Alcatel	OT-385 Text Edition
Alcatel	A392A One Touch
Alcatel	A392cc One Touch (USB)
Alcatel	A392cc One Touch (BT)
Alcatel	A392G OneTouch

Alcatel	A394C One Touch
Alcatel	A462C Pixi Eclipse (Bluetooth)
Alcatel	A462C Pixi Eclipse (USB)
Alcatel	SFR-262 GRIS
Alcatel	639G One Touch
Alcatel	OT-C701
Alcatel	MD01 Mandarinina Duck
Alcatel	OT-C825
Alcatel	OT-505
Alcatel	506A One Touch (USB)
Alcatel	506A One Touch (BT)
Alcatel	OT-510APIB One Touch 510A
Alcatel	OT-S521
Alcatel	536 One Touch
Alcatel	Vodafone 555 Blue
Alcatel	A574BL Raven
Alcatel	A570BL One Touch Pixi (Bluetooth)
Alcatel	A570BL One Touch Pixi (USB)
Alcatel	A577VL
Alcatel	OT-585
Alcatel	OT-600
Alcatel	OT-606
Alcatel	606A One Touch
Alcatel	OT-665A
Alcatel	OT-665TM
Alcatel	OT-668 One Touch
Alcatel	OT-706
Alcatel	OT-708 (Orange)
Alcatel	OT-708 (USB)
Alcatel	OT-708A (USB)
Alcatel	OT-708 (BT)
Alcatel	OT-708A (BT)
Alcatel	OT-710
Alcatel	OT-720 One Touch
Alcatel	OT-720D
Alcatel	768T One Touch
Alcatel	OT-799 Play
Alcatel	OT-800 One Touch Tribe
Alcatel	OT-800A (USB)
Alcatel	OT-800A (BT)
Alcatel	E801
Alcatel	OT-802A (USB)
Alcatel	OT-802A (BT)
Alcatel	OT-806 Vairy Text II
Alcatel	OT-806A
Alcatel	OT-806D Vairy Text II
Alcatel	OT-808
Alcatel	OT-810 One Touch
Alcatel	OT-813
Alcatel	OT-813D
Alcatel	OT-815 One Touch
Alcatel	OT-819
Alcatel	OT-838 One Touch
Alcatel	OT-871A
Alcatel	V860 Smart II

Alcatel	875 Smart Mini
Alcatel	875T
Alcatel	OT-880 One Touch XTRA
Alcatel	888A One Touch (USB)
Alcatel	888A One Touch (BT)
Alcatel	OT-903 One Touch
Alcatel	DL900 One Touch Pop C7
Alcatel	902A One Touch (USB)
Alcatel	902A One Touch (BT)
Alcatel	9007T One Touch
Alcatel	OT-906 One Touch
Alcatel	OT-908 Move
Alcatel	OT-908 One Touch
Alcatel	909B One Touch
Alcatel	918D One Touch
Alcatel	991D One Touch
Alcatel	918M One Touch
Alcatel	OT-993D One Touch
Alcatel	1011A One Touch
Alcatel	1011D One Touch
Alcatel	One Touch 1010D
Alcatel	1017G One Touch
Alcatel	1030X Bc 211
Alcatel	1054X
Alcatel	1042X One Touch
Alcatel	1054D
Alcatel	OT-1060 Riga
Alcatel	1066D
Alcatel	2010D One Touch
Alcatel	2045X One Touch
Alcatel	2004C One Touch
Alcatel	2008G
Alcatel	2010G One Touch
Alcatel	2036X
Alcatel	2040D
Alcatel	2067X One Touch
Alcatel	ADR3010
Alcatel	OT-960C One Touch
Alcatel	OT-1009X
Alcatel	OT-1010X
Alcatel	ADR3010C Authority
Alcatel	3040D OneTouch Tribe
Alcatel	3040G OneTouch Tribe
Alcatel	3075M One Touch
Alcatel	ADR3045US One Touch Shockwave
Alcatel	OT-988 One Touch Shockwave
Alcatel	OT-990 One Touch
Alcatel	OT-995 Infinity
Alcatel	OT-995 one touch
Alcatel	OT-602
Alcatel	OT-1063 BIC V5
Alcatel	2005X
Alcatel	2007D One Touch
Alcatel	Venture
Alcatel	Crystal

Alcatel	2012G One Touch
Alcatel	2012D One Touch
Alcatel	2038X
Alcatel	2051D
Alcatel	3020D OneTouch
Alcatel	3022G One Touch
Alcatel	4003A One Touch Pixi 3 (4)
Alcatel	4009A One Touch Pixi 3
Alcatel	4009E One Touch Pixi 3 (3.5)
Alcatel	4009F One Touch Pixi 3 3.5
Alcatel	4009X One Touch Pixi 3 3.5
Alcatel	4010X One Touch T'Pop
Alcatel	4013M One Touch Pixi 3
Alcatel	4015A One Touch POP C1
Alcatel	4015D One Touch Pop C1
Alcatel	4015T One Touch Star
Alcatel	4013X Orange Rise 30
Alcatel	4015X One Touch Pop C1
Alcatel	4027A OneTouch Pixi 3 4.5
Alcatel	4028S One Touch Pixi 3 (4.5)
Alcatel	4047X U5
Alcatel	A502DL TCL LX Prepaid
Alcatel	5008D_EEA 1X
Alcatel	5059A 1X
Alcatel	5059Z 1X
Alcatel	4055T U3
Alcatel	A501DL TCL A1
Alcatel	5095I Pop 4S
Alcatel	5044C Verso
Alcatel	5044Y U5
Alcatel	9003X PIX14
Alcatel	5033T Joy 1
Alcatel	5044S U50
Alcatel	5059I 1X
Alcatel	5059R Ideal Xtra
Alcatel	9024 A30
Alcatel	5099D 3V
Alcatel	5099Y 3V
Alcatel	4030X One Touch S Pop
Alcatel	4033A One Touch Pop C3
Alcatel	4033X One Touch Pop C3
Alcatel	4033D One Touch Pop C3
Alcatel	4034X One Touch Pixi 4 (4)
Alcatel	4034D Pixi 4 4.0
Alcatel	4037N One Touch Evolve 2
Alcatel	4037T One Touch Evolve 2
Alcatel	4044C QUICKFLIP
Alcatel	4044L Go Flip
Alcatel	4044N Go Flip 2
Alcatel	4044V Go Flip
Alcatel	4044T Go Flip
Alcatel	4044W
Alcatel	4047D U5
Alcatel	4055J U3
Alcatel	5010X Pixi 4 (5)

Alcatel	5009A 1C
Alcatel	A622GL Jitterbug
Alcatel	5012G Pixi 4 5.5
Alcatel	5027B Dawn
Alcatel	A571VL One Touch Pixi Avion (Bluetooth)
Alcatel	A573VC One Touch Pixi Bond
Alcatel	5017A OneTouch Pixi 3 4.5
Alcatel	5017X OneTouch Pixi 3 4.5
Alcatel	4060A
Alcatel	4060O Streak
Alcatel	5026D 3C
Alcatel	5059D 1X
Alcatel	5080X One Touch Shine Lite
Alcatel	5085Y A5 LED
Alcatel	5080Q Shine Lite Optus X Sleek
Alcatel	7047A Pop C9
Alcatel	5041C
Alcatel	5098O Pixi Theatre
Alcatel	5017B One Touch Pixi 3 4.5
Alcatel	5015D One Touch Pixi 3 5.0
Alcatel	5015X One Touch Pop 3
Alcatel	5016J One Touch Pop 3
Alcatel	5020N One Touch Evolve
Alcatel	5020T One Touch Evolve
Alcatel	5025G OneTouch Pop 3 (5.5)
Alcatel	5035D One Touch X'Pop
Alcatel	5036A One Touch Pop C5
Alcatel	5036D One Touch Pop C5
Alcatel	5042T One Touch Pop Astro
Alcatel	5044D U5
Alcatel	5045X Pixi 4 (5)
Alcatel	5042A OneTouch Pop 2 4.5
Alcatel	A995L OneTouch POP Mega
Alcatel	5042X Orange Roya
Alcatel	5044O U5
Alcatel	5044T U5
Alcatel	Orange Nura
Alcatel	Nura 2
Alcatel	5044R idealXCITE
Alcatel	5046Y A3
Alcatel	5099A 3V
Alcatel	5056I Optus X Smart
Alcatel	5058Y A5 LED
Alcatel	5058I 3X
Alcatel	5049Z
Alcatel	5049W Revvl
Alcatel	5050X One Touch Pop S3
Alcatel	5051X Pop 4
Alcatel	5055W Fierce XL (Windows) (USB)
Alcatel	5055W Fierce XL (Windows) (BT)
Alcatel	5080A Shine Lite
Alcatel	5085C PulseMix
Alcatel	5090i A7
Alcatel	7046T Conquest
Alcatel	7047D One Touch Pop C9

Alcatel	7048X One Touch Go Play
Alcatel	6010D One Touch Star
Alcatel	5054N One Touch
Alcatel	5056E Pop 4+
Alcatel	5065N
Alcatel	5054W One Touch
Alcatel	5054S One Touch Pop 3 (5.5)
Alcatel	5020X One Touch M'Pop
Alcatel	5056O OneTouch Allura
Alcatel	5056W
Alcatel	5056N Fierce 4
Alcatel	6012A One Touch Idol Mini
Alcatel	6012D One Touch Idol Mini
Alcatel	6012X One Touch Idol Mini
Alcatel	6016D One Touch Idol 2 Mini
Alcatel	6016X One Touch Idol 2 Mini
Alcatel	6032 One Touch Idol Alpha
Alcatel	6032A One Touch Idol Alpha
Alcatel	6033X One Touch Idol
Alcatel	6036Y One Touch Idol 2 Mini S
Alcatel	6036A One Touch Idol 2 Mini S
Alcatel	6037B One Touch Idol 2
Alcatel	6040A One Touch Idol X
Alcatel	6040D One Touch Idol X
Alcatel	6040X One Touch Idol X
Alcatel	6043A One Touch Idol X+
Alcatel	6055U One Touch Idol 4
Alcatel	6055K One Touch Idol 4
Alcatel	6055P One Touch Idol 4
Alcatel	6058D One Touch Idol 5
Alcatel	6060S One Touch Idol 5S
Alcatel	6062W
Alcatel	6043D One Touch Idol X+
Alcatel	6039Y One Touch Idol 3 4.7
Alcatel	6039S One Touch Idol 3 4.7
Alcatel	6045F One Touch Idol 3 (5.5)
Alcatel	6045O One Touch Idol 3
Alcatel	6045I One Touch Idol 3
Alcatel	6045Y One Touch Idol 3
Alcatel	6050A One Touch Idol 2 S
Alcatel	6050Y Infinity X2\One Touch Idol 2S
Alcatel	6071W One Touch Idol 4S (USB)
Alcatel	6071W One Touch Idol 4S (BT)
Alcatel	7024W One Touch Fierce
Alcatel	7040A One Touch Pop C7
Alcatel	7040N Fierce 2
Alcatel	7040T One Touch Fierce 2
Alcatel	7040T One Touch Pop Icon
Alcatel	7041D One Touch Pop C7
Alcatel	7041X One Touch Pop C7
Alcatel	7045Y One Touch Pop S7
Alcatel	7055A One Touch Hero 2C
Alcatel	8008D One Touch Scribe HD
Alcatel	8030Y One Touch Hero 2
Alcatel	8079 A3 10

Alcatel	9001X One Touch Pixi 4 6.0
Alcatel	9006W One Touch Pixi 7
Alcatel	9008X One Touch A3 XL
Alcatel	9020A Trek HD
Alcatel	Zuco
Alcatel	1066G
Allview	W1i (USB)
Allview	W1i (BT)
Allview	X2 Soul Mini
Allview	X4 Soul
Allview	Viper i V1
Allview	E3 Living
Allview	V2 Viper X
Allview	Sign E3
Allview	A5 Lite
Allview	A5 Quad Plus
Allview	P5 Life
Allview	A6 Lite
Allview	A7 Lite
Allview	E4 Lite
Allview	P4 Life
Allview	P6 Life
Allview	P6 Energy
Allview	A6 Duo
Allview	A4 You
Allview	P6 Pro
Allview	V2 Viper
Allview	M9 Jump
Altice	STARADDICT 6
Altice	STAREXTREM 6
Amazon	Kindle Fire
Amazon	X43Z60 Kindle Fire HD
Amazon	PR53DC Fire HD 8
Amazon	Fire HD 10 (7th Generation)
Amazon	SV98LN Fire
Amazon	SD4930UR Fire Phone
Amazon	SR043KL Fire 7
Amoi	WP-S1 Skype
Amoi	WP-S2 Skype
Amoi	N60
Amoi	A920
AnyDATA	ASP-505A
Apple	Fast Phonebook (Bluetooth)
Apple	Fast Phonebook (USB)
Apple	iPad 1 WiFi (A1219)
Apple	iPad 1 (A1337)
Apple	iPad 2 WiFi (A1395)
Apple	iPad 2 (A1396)
Apple	iPad 2 (A1397)
Apple	iPad 3 (A1403)
Apple	iPad 3 WiFi (A1416)
Apple	iPad 3 (A1430)
Apple	iPad 4 WiFi (A1458)
Apple	iPad 4 (A1459)
Apple	iPad 4 (A1460)

Apple	iPad Pro 12.9" WiFi (A1584)
Apple	iPad Pro 12.9" (A1652)
Apple	iPad Pro 10.5 (A1701)
Apple	iPad Pro 9.7" WiFi (A1673)
Apple	iPad Pro 9.7" (A1674)
Apple	iPad Pro 9.7" (A1675)
Apple	iPad 9.7" (5th Gen) WiFi (A1822)
Apple	iPad 9.7" (5th Gen) (A1823)
Apple	iPad Mini (5th Gen) (A2133)
Apple	iPad 6th Gen MR7F2LL_A (A1893)
Apple	iPad 7th Gen MW742LL_A (A2197)
Apple	iPad MR6N2CL_A
Apple	iPad Air WiFi (3rd Gen) (A2152)
Apple	iPad Pro 11 (A1980)
Apple	iPad mini WiFi (A1432)
Apple	iPad mini (A1454)
Apple	iPad mini (A1455)
Apple	iPad Air WiFi (A1474)
Apple	iPad Air (A1475)
Apple	iPad Air (A1476)
Apple	iPad Air 2 WiFi (A1566)
Apple	iPad Air 2 (A1567)
Apple	iPad mini with Retina display WiFi (A1489)
Apple	iPad mini with Retina display (A1490)
Apple	iPad mini with Retina display (A1491)
Apple	iPad mini 3 WiFi (A1599)
Apple	iPad mini 3 (A1600)
Apple	iPad mini 3 (A1601)
Apple	iPad mini 4 WiFi (A1538)
Apple	iPad mini 4 (A1550)
Apple	iPhone 2G (A1203)
Apple	iPhone 3G (A1241)
Apple	iPhone 3G (A1324)
Apple	iPhone 3GS (A1303)
Apple	iPhone 3GS (A1325)
Apple	iPhone 4 (A1332)
Apple	iPhone 4 (A1349)
Apple	iPhone 4s (A1387)
Apple	iPhone 4s (A1431)
Apple	iPhone 5 (A1428)
Apple	iPhone 5 (A1429)
Apple	iPhone 5 (A1442)
Apple	iPhone 5c (A1456)
Apple	iPhone 5c (A1507)
Apple	iPhone 5c (A1516)
Apple	iPhone 5c (A1526)
Apple	iPhone 5c (A1529)
Apple	iPhone 5c (A1532)
Apple	iPhone 5s (A1453)
Apple	iPhone 5s (A1457)
Apple	iPhone 5s (A1518)
Apple	iPhone 5s (A1528)
Apple	iPhone 5s (A1530)
Apple	iPhone 5s (A1533)
Apple	iPhone SE (A1662)

Apple	iPhone SE (A1723)
Apple	iPhone SE (A1724)
Apple	iPhone 6 (A1549)
Apple	iPhone 6 (A1586)
Apple	iPhone 6 (A1589)
Apple	iPhone 6 Plus (A1522)
Apple	iPhone 6 Plus (A1524)
Apple	iPhone 6 Plus (A1593)
Apple	iPhone 6s (A1633)
Apple	iPhone 6s (A1688)
Apple	iPhone 6s (A1691)
Apple	iPhone 6s (A1700)
Apple	iPhone 6s Plus (A1634)
Apple	iPhone 6s Plus (A1687)
Apple	iPhone 6s Plus (A1690)
Apple	iPhone 6s Plus (A1699)
Apple	iPhone 7 (A1660)
Apple	iPhone 7 (A1778)
Apple	iPhone 7 (A1779)
Apple	iPhone 7 (A1780)
Apple	iPhone 7 Plus (A1661)
Apple	iPhone 7 Plus (A1784)
Apple	iPhone 7 Plus (A1785)
Apple	iPhone 7 Plus (A1786)
Apple	Fake MNRM2CH_A iPhone 7 Plus
Apple	iPhone 8 (A1863)
Apple	iPhone 8 (A1905)
Apple	iPhone 8 (A1906)
Apple	iPhone 8 (A1907)
Apple	iPhone 8 Plus (A1864)
Apple	iPhone 8 Plus (A1897)
Apple	iPhone 8 Plus (A1898)
Apple	iPhone 8 Plus (A1899)
Apple	iPhone X (A1865)
Apple	iPhone X (A1901)
Apple	iPhone X (A1902)
Apple	iPhone Xs (A1920)
Apple	A iPhone Xs
Apple	A2097 MT9G2RM
Apple	A iPhone SE
Apple	A2275 MX9N2LL
Apple	A iPhone SE
Apple	A2296 MX9T2HB
Apple	A iPhone Xs
Apple	A2100 MT9P2CH
Apple	Fake XS iPhone MQA52CH_A
Apple	Fake iPhone 8 MQ6K2ZP_A
Apple	iPhone XR (A1984)
Apple	iPad Pro 12.9 (A1670)
Apple	MWLD2LL_A iPhone 11
Apple	MWH22LL_A A2161 iPhone 11 Pro Max
Apple	iPhone 11 (A2111)
Apple	lphone 11 Pro (A2160)
Apple	Fake iPhone X MT982ZA_A
Apple	Fake iPhone 7 MF354ZP_A

Apple	Fake iPhone X MQA62CH_A
Apple	Fake iPhone XS Max MNRJ2CH_A
Apple	iPhone XR (A2105)
Apple	iPhone Xs Max(A1921)
Apple	iPhone Xs Max (A2101)
Apple	iPhone Xs Max (A2104)
Apple	iPod Touch (A1213)
Apple	iPod Touch 2G (A1288)
Apple	iPod Touch 3G (A1318)
Apple	iPod Touch 4G (A1367)
Apple	iPod Touch 5G (A1421)
Apple	iPod Touch 5G (A1509)
Apple	iPod Touch 6G (A1574)
Apple	MTK Mini Iphone 168 Hello Kitty
Apple	Fake China iPhone cphone 4
Apple	Fake iPhone 5C Ai383
Apple	Fake iPhone 5S (A1530)
Archos	F18
Archos	ACF28 F28
Archos	AC45HE Helium 4G
Archos	50c Platinum
Archos	A70BHT Home Tablet 7
Archos	50b Neon
Archos	80 G9
Archos	101 G9
Archos	AC68OXXL Oxygen 68XL
Archos	AC63OX_DS Oxygen 63
Archos	AC57OX Oxygen 57
Ark	M3S Benefit
Asus	T00D PadFone X
Asus	T00s PadFone X mini
Asus	P01V Zenpad 7
Asus	P01Z Zenpad
Asus	T00J Zenfone 5
Asus	K004 Fonepad
Asus	A66 PadFone
Asus	ME375CL MeMO Pad 7 LTE
Asus	K008 Google Nexus 7 II
Asus	K009 Nexus 7
Asus	TF101 Transformer Eee Pad
Asus	ME172V Memo Pad
Asus	TF201 Transformer Prime
Asus	TF300T Transformer Pad
Asus	ME370T Nexus 7
Asus	P550
Asus	P750
Asus	1210 VDA
Asus	ZE500CL ZenFone 2
Asus	Z380KL P024 ZenPad 8.0
Asus	P028 ZenPad 10
Asus	A006 ZenFone V V520KL
Asus	Z00AD Zenfone 2 ZE551ML
Asus	X00AD ZenFone Go
Asus	ZB553KL X00LDA ZenFone 4 Live
Asus	Z00MD Zenfone 2 Laser ZE600KL

Asus	Z00D Zenfone 2E
Asus	Z00LD Zenfone 2 Lazer ZE550KL
Asus	X018D Zenfone Max Plus
Asus	Z012DE ZenFone 3_DS
Asus	ZS620KL ZenFone 5Z
Asus	X015D Zenfone 4 Max Plus
Asus	X017DA ZenFone 5Q
Asus	ZC600KL
Asus	X00TD Zenfone Max Pro
Asus	ZB602KL
Asus	X00QD Zenfone 5
Asus	ZE620KL
Asus	Z00TD Zenfone 2 Laser ZE551KL
Asus	Z00UD Zenfone Selfie ZD551KL
Asus	Z00XS ZenFone Zoom
Asus	ZB501KL A007 ZenFone Live
Asus	A009 ZenFone V Live
Asus	X00ID ZC554KL ZenFone 4 Max 5.5
Asus	ZC520KL Zenfone 4 Max
Asus	Z010D ZC550KL Zenfone Max
Asus	Z011D Zenfone 2 Laser ZE601KL
Asus	Z012DA Zenfone 3 ZE552KL
Asus	ZE553KL Z01HD Zenfone 3 Zoom
Asus	P00I
Asus	T001 Zenfone 4
Asus	Z002 Zenfone 6
Asus	ME175CG Fonepad 7 K00Z
Asus	X013D Zenfone Go ZB551KL
Asus	X014D Zenfone Go ZB452KG
Asus	Z00SD Zenfone Go ZC451TG
Asus	ZE551 Zenfone 2
Asus	ZE554KL Z01KDA ZenFone 4
Asus	Z01KD ZenFone 4
Asus	Z01MD Zenfone 4 Selfie Pro
Asus	Z01MDA ZenFone 4 Selfie Pro
Asus	ZD552KL
Asus	X00RD ZenFone Live
Asus	ZA550KL
Asus	ASUS_101WD_DS ZenFone 6
Asus	K010 Transformer Pad TF103C
Asus	ZC553KL Zenfone 3 Max
Asus	Z008D Zenfone 2
Asus	I001DA_DS ROG_Phone 2 Gaming
Asus	X008DB Zenfone 3 Max
Asus	X00HD_DS ZenFone 4 Max
Asus	Z01BDC ZenFone 3
Asus	ZC551KL
Asus	X008D Zenfone Pegasus 3
Asus	X008DC Zenfone 3 Max
Audiovox/UTStarcom/PCD	CDM-105
Audiovox/UTStarcom/PCD	CDM-120 (Sprint)
Audiovox/UTStarcom/PCD	CDM-180
Audiovox/UTStarcom/PCD	GPT380CTE
Audiovox/UTStarcom/PCD	C655
Audiovox/UTStarcom/PCD	C659

Audiovox/UTStarcom/PCD	1450M
Audiovox/UTStarcom/PCD	CDM-2030CS
Audiovox/UTStarcom/PCD	CDM-2080
Audiovox/UTStarcom/PCD	SMT-5800
Audiovox/UTStarcom/PCD	PPC-6600
Audiovox/UTStarcom/PCD	PPC-6601KIT
Audiovox/UTStarcom/PCD	VX-6600
Audiovox/UTStarcom/PCD	XV-6600 WOC
Audiovox/UTStarcom/PCD	PPC-6700
Audiovox/UTStarcom/PCD	XV-6700
Audiovox/UTStarcom/PCD	XV-6800
Audiovox/UTStarcom/PCD	XV-6850 Touch Pro
Audiovox/UTStarcom/PCD	XV-6875 Touch Pro2 (CDMA)
Audiovox/UTStarcom/PCD	XV-6875 Touch Pro2 (GSM)
Audiovox/UTStarcom/PCD	XV-6900 Touch
Audiovox/UTStarcom/PCD	XV-6950 Touch Diamond
Audiovox/UTStarcom/PCD	CDM-7000
Audiovox/UTStarcom/PCD	CDM-7025
Audiovox/UTStarcom/PCD	CDM-7026 (Cricket)
Audiovox/UTStarcom/PCD	CDM-7075 (Verizon)
Audiovox/UTStarcom/PCD	PLS-7075 (TBayTel)
Audiovox/UTStarcom/PCD	CDM-7076
Audiovox/UTStarcom/PCD	CDM-7126c (Cricket)
Audiovox/UTStarcom/PCD	CDM-7126c (MetroPCS)
Audiovox/UTStarcom/PCD	TXT-8010 Blitz
Audiovox/UTStarcom/PCD	TXT-8026c
Audiovox/UTStarcom/PCD	TXT-8030VW Razzle
Audiovox/UTStarcom/PCD	TXT-8035 Caper
Audiovox/UTStarcom/PCD	TXT-8040
Audiovox/UTStarcom/PCD	CDM-8200 (Bell)
Audiovox/UTStarcom/PCD	CDM-8300
Audiovox/UTStarcom/PCD	CDM-8400
Audiovox/UTStarcom/PCD	CDM-8410
Audiovox/UTStarcom/PCD	CDM-8450
Audiovox/UTStarcom/PCD	CDM-8500
Audiovox/UTStarcom/PCD	CDM-8500E
Audiovox/UTStarcom/PCD	CDM-8600
Audiovox/UTStarcom/PCD	CDM-8610
Audiovox/UTStarcom/PCD	CDM-8615
Audiovox/UTStarcom/PCD	CDM-8625
Audiovox/UTStarcom/PCD	CDM-8630 Coupe
Audiovox/UTStarcom/PCD	CDM-8900
Audiovox/UTStarcom/PCD	CDM-8905
Audiovox/UTStarcom/PCD	CDM-8910
Audiovox/UTStarcom/PCD	CDM-8912
Audiovox/UTStarcom/PCD	CDM-8915
Audiovox/UTStarcom/PCD	CDM-8920
Audiovox/UTStarcom/PCD	CDM-8930
Audiovox/UTStarcom/PCD	CDM-8932
Audiovox/UTStarcom/PCD	CDM-8935 L1
Audiovox/UTStarcom/PCD	CDM-8940
Audiovox/UTStarcom/PCD	CDM-8945
Audiovox/UTStarcom/PCD	CDM-8950
Audiovox/UTStarcom/PCD	CDM-8955
Audiovox/UTStarcom/PCD	CDM-8960

Audiovox/UTStarcom/PCD	CDM-8975
Audiovox/UTStarcom/PCD	WP-8990VW Escapade
Audiovox/UTStarcom/PCD	CDM-8999 Crux
Audiovox/UTStarcom/PCD	CDM-9100
Audiovox/UTStarcom/PCD	CDM-9150
Audiovox/UTStarcom/PCD	CDM-9155
Audiovox/UTStarcom/PCD	CDM-9200
Audiovox/UTStarcom/PCD	CDM-9500
Audiovox/UTStarcom/PCD	CDM-9900
Audiovox/UTStarcom/PCD	CDM-9950
Audiovox/UTStarcom/PCD	CDM-2035C
Audiovox/UTStarcom/PCD	CDM-2040C
Audiovox/UTStarcom/PCD	VM2090 Chaser
Azumi	A40C
BLU	Studio One
BLU	R1 HD
BLU	R1 Plus
BLU	N1 Bold
BLU	Z4_DS Bold
BLU	Vivo 4.8 HD
BLU	Vivo GO
BLU	X010Q Life One
BLU	D010U Dash X
BLU	L0030EE 024 Life Mark
BLU	E030L Energy X Plus
BLU	E030U Energy X Plus
BLU	Grand M2
BLU	V0311WW Vivo XI Plus
BLU	C5
BLU	G150Q Grand XL
BLU	Q41 Charleston
BLU	Q53 Samba Jr.
BLU	Q53i Samba Jr Plus
BLU	N110U NEO XL
BLU	S0151UU 01 Studio X Mini
BLU	S090Q Studio C HD
BLU	S530 Studio X8 HD
BLU	S550Q Studio G2 HD
BLU	S110U Studio M HD
BLU	S070Q Selfie
BLU	L050U Life XL
BLU	D070 Dash J
BLU	L170i Life Play 2
BLU	L090a Life Play
BLU	Z070L Zoey 2.4
BLU	Z070u Zoey 2.4
BLU	A090L Advance 4.0M
BLU	B100DL View 1
BLU	Z090 Z3
BLU	Z110X Z3 M
BLU	Z130 Zoey Flex
BLU	X150Q Win HD 4G (USB)
BLU	X150Q Win HD 4G (BT)
BLU	L0150WW_DS Life One X3
BLU	Z150 Z3 Music

BLU	X100Q Studio Mini LTE
BLU	X020Q Life One XL
BLU	L110 Life View
BLU	L100a Life Play
BLU	Joy J010
BLU	L102a Life Play X
BLU	W110a Tank 4.5
BLU	L120 Life One
BLU	S130 Spark
BLU	L131I Life One X
BLU	L131L Life One M
BLU	L131U Life One M
BLU	Q-133 Deco Mini
BLU	D140 Dash JR
BLU	T150 Lindy B
BLU	L150u Life Play S
BLU	Q160A DeeJay 2
BLU	T166 Zoey
BLU	Q170w Samba W
BLU	D171a Dash 3.5
BLU	T172 Jenny
BLU	T172i Jenny
BLU	T176 Zoey
BLU	T177 Jenny II
BLU	T276T Jenny TV
BLU	T179 Aria II
BLU	L180a Life Play Mini
BLU	Q180 Tattoo Mini
BLU	S190 Hero
BLU	T190i Tank
BLU	T190Q Tank
BLU	T193 Tank II
BLU	T274T
BLU	T470 Life One X2 Mini
BLU	Q210E Samba Elite
BLU	L210a Life Pro
BLU	L220a Life Pure Mini
BLU	A230Q Advance 5.2
BLU	L240a Life Pure
BLU	L240i Life Pure
BLU	A010L 01 Advance 4.0 L Realtime
BLU	A030L Advance 4.0 L2
BLU	D250U Dash L2
BLU	A270a Advance 4.0
BLU	D270a Dash 4.0
BLU	D272a Dash Music 4.0
BLU	T272T Diva
BLU	D280a Amour
BLU	L280a Life 8
BLU	D290i Amour
BLU	D310a Dash 4.5
BLU	D310i Dash 4.5
BLU	A310a Advance 4.5
BLU	S330L Neo 4.5
BLU	T370 Diva Flex

BLU	T390 Diva Flip
BLU	D390L Dash C Music
BLU	D390U Dash C Music
BLU	S410a Star 4.0
BLU	G0210LL G6
BLU	G0170_DS G8
BLU	C5L C0050LL
BLU	G0090 G5
BLU	G0130WW G9
BLU	D410a Dash 5.0
BLU	D090U Dash M2
BLU	D412u Dash 5.0+
BLU	D440 Quattro 4.5
BLU	D450 Quattro 4.5 HD
BLU	S451L Star 4.5
BLU	D490U Dash G
BLU	D530 Studio 5.0
BLU	D530e Studio 5.0e
BLU	D531K Studio 5.0K
BLU	D532u Studio 5.0 II
BLU	D534L Studio 5.0 C HD
BLU	D534u 5.0C HD
BLU	D536u Studio 5.0 C
BLU	D572a Studio 5.0 S II
BLU	D590a Studio 5.3 S
BLU	D610i Studio 5.5
BLU	D610a Studio 5.5
BLU	D630u Studio 5.5
BLU	D650a Studio 6.0 HD
BLU	D670L Studio C Mini
BLU	D790L Studio G
BLU	D810L 01 Studio Energy
BLU	D910a Vivo 4.3
BLU	D750L Studio X
BLU	770L Studio X Plus Realtime
BLU	D890L Studio C 5+5
BLU	D940i Vivo 4.8 HD Realtime
BLU	D940a VIVO 4.8 HD
BLU	D970L Vivo IV
BLU	D980i Vivo Air
BLU	D980L Vivo Air
BLU	Vivo 5 Mini
BLU	R0170WW R2_DS
BLU	A350A Advance L4
BLU	C031P C6
BLU	Studio Mega
BLU	Vivo XL4
BLU	Vivo One PLUS
BLU	S1
BLU	C050U C4
BLU	Vivo 8
BLU	Vivo XL2
BQ	Aquaris E4
BQ	Aquaris M5
BQ	Aquaris E5 HD

BQ	Aquaris X5
BQ	Aquaris X5 Plus
BQ	Aquaris U Plus
BQ	Aquaris V
BQ	Aquaris X Pro
BQ	Aquaris X
BQ	Aquaris U2
BQ	Aquaris V Plus
BQ	Aquaris C
BQ	Aquaris X2
BQ	Aquaris X2 Pro
BQ	Aquaris U2 Lite
Barnes And Noble	BNTV400 Nook HD
Barnes And Noble	BNTV600 Nook HD+
Beafon	C150
Beafon	SL320
Beafon	T850
Beeline	Beeline C201
BlackBerry CDMA	SQC100-3 Classic (Bluetooth)
BlackBerry CDMA	SQC100-3 Classic (USB cable)
BlackBerry CDMA	ro27 storm 2
BlackBerry CDMA	7100
BlackBerry CDMA	7130e
BlackBerry CDMA	Q10 (Bluetooth)
BlackBerry CDMA	Q10 (USB cable)
BlackBerry CDMA	Z10 (Bluetooth)
BlackBerry CDMA	Z10 (USB cable)
BlackBerry CDMA	Z30 STA100-3 (Bluetooth)
BlackBerry CDMA	Z30 STA100-3 (USB cable)
BlackBerry CDMA	7250
BlackBerry CDMA	7520
BlackBerry CDMA	7750
BlackBerry CDMA	8130 Pearl
BlackBerry CDMA	8230 Pearl Flip
BlackBerry CDMA	8330 Curve
BlackBerry CDMA	8350i Curve
BlackBerry CDMA	8530 Aires
BlackBerry CDMA	8530 Curve II
BlackBerry CDMA	8703e
BlackBerry CDMA	8830
BlackBerry CDMA	9310 Curve
BlackBerry CDMA	9330 Curve 3
BlackBerry CDMA	9350 Curve
BlackBerry CDMA	9350 Curve (MetroPCS)
BlackBerry CDMA	9370 Curve
BlackBerry CDMA	9530 Storm
BlackBerry CDMA	9550 Storm 2 (Verizon)
BlackBerry CDMA	9570 Storm 3
BlackBerry CDMA	9630 Tour
BlackBerry CDMA	9650 Bold
BlackBerry CDMA	9670 Style
BlackBerry CDMA	9850 Torch
BlackBerry CDMA	9930 Bold
BlackBerry CDMA	STV100-2 Priv
BlackBerry GSM	P9981 Porche

BlackBerry GSM	STV100-1 Priv
BlackBerry GSM	STV100-4 Priv
BlackBerry GSM	SQC100-4 Classic (USB cable)
BlackBerry GSM	SQW100-1 Passport (Bluetooth)
BlackBerry GSM	SQW100-1 Passport (USB cable)
BlackBerry GSM	SQW100-3 Passport (Bluetooth)
BlackBerry GSM	SQW100-3 Passport (USB cable)
BlackBerry GSM	Q10 (Bluetooth)
BlackBerry GSM	Q10 (USB cable)
BlackBerry GSM	Z10 (Bluetooth)
BlackBerry GSM	Z10 (USB cable)
BlackBerry GSM	Z10(Turkcell) (Bluetooth)
BlackBerry GSM	Z10(Turkcell) (USB cable)
BlackBerry GSM	7100
BlackBerry GSM	SQR100-1 Q5 (Bluetooth)
BlackBerry GSM	SQR100-1 Q5 (USB cable)
BlackBerry GSM	SQR100-2 Q5 (Bluetooth)
BlackBerry GSM	SQR100-2 Q5 (USB cable)
BlackBerry GSM	STA100-2 Z30 (Bluetooth)
BlackBerry GSM	STA100-2 Z30 (USB cable)
BlackBerry GSM	STA100-5 Z30 (Bluetooth)
BlackBerry GSM	BBB100-1 KEYone
BlackBerry GSM	BBD100-1 Motion
BlackBerry GSM	BBA100-2 DTEK60
BlackBerry GSM	BBF100-2 KEY2
BlackBerry GSM	STH100-2 DTEK50
BlackBerry GSM	STA100-5 Z30 (USB cable)
BlackBerry GSM	STR100-2 Leap (Bluetooth)
BlackBerry GSM	STR100-2 Leap (USB cable)
BlackBerry GSM	STK100-2 10
BlackBerry GSM	7130v
BlackBerry GSM	7290
BlackBerry GSM	8100 Pearl
BlackBerry GSM	8110 Pearl
BlackBerry GSM	8120 Pearl
BlackBerry GSM	8220 Pearl Flip
BlackBerry GSM	8300 Curve
BlackBerry GSM	8310 Curve
BlackBerry GSM	8320 Curve
BlackBerry GSM	8350i
BlackBerry GSM	8520 Curve (USA)
BlackBerry GSM	8520 Curve (OrangeUK)
BlackBerry GSM	8700
BlackBerry GSM	8700f
BlackBerry GSM	8700g
BlackBerry GSM	8700v
BlackBerry GSM	8707
BlackBerry GSM	8800
BlackBerry GSM	8820
BlackBerry GSM	8900 Curve
BlackBerry GSM	8910
BlackBerry GSM	9000 Bold
BlackBerry GSM	9000
BlackBerry GSM	9100 Pearl
BlackBerry GSM	9105 Pearl 3G

BlackBerry GSM	9220 Curve
BlackBerry GSM	9300 Curve
BlackBerry GSM	9300 Curve 3G
BlackBerry GSM	Fake Blackberry K9300 Kimfly
BlackBerry GSM	9315 Curve
BlackBerry GSM	9320 Curve
BlackBerry GSM	9360 Curve
BlackBerry GSM	9380 Orlando
BlackBerry GSM	9380 Curve
BlackBerry GSM	9500 Storm
BlackBerry GSM	9520 Storm2
BlackBerry GSM	9550 Storm 2
BlackBerry GSM	9620 Curve
BlackBerry GSM	9630 Tour
BlackBerry GSM	9700 Bold
BlackBerry GSM	9700 Onyx
BlackBerry GSM	9780 Bold
BlackBerry GSM	9780 Onyx II
BlackBerry GSM	9720 Samoa
BlackBerry GSM	9790 Bold
BlackBerry GSM	9800 Raptor
BlackBerry GSM	9800 Torch
BlackBerry GSM	9810 Torch
BlackBerry GSM	9860 Monza
BlackBerry GSM	9860 Torch
BlackBerry GSM	9900 Bold
Blackview	A9 Pro
Blackview	S6
Blackview	A20
Blackview	S8
Blackview	A7 Pro
Blackview	A5
Blackview	A8 Max
Blackview	BV5800
Blackview	BV5800 Pro
Blackview	BV6000
Blackview	A30
Blackview	BV5500
Blackview	BV7000
Blackview	A60
Blackview	BV9500 Pro
Bluboo	XFire
Bluboo	Xtouch
Bluboo	D1 3G Smartphone 5.0
Bmobile	AX570
Bmobile	AX512
Bmobile	AX524
Bmobile	AX600
Bmobile	AX605
Bmobile	AX670
Bmobile	AX810
Bmobile	AX820
Bmobile	AX1030
Bmobile	AX1060 Negro
CAT	B15

CAT	B15Q
CAT	S50
CAT	S40
CAT	S41
CAT	S60
CAT	S61 Rugged Waterproof
CAT	B25
CAT	B30
CAT	CAT B35
CAT	S30
CAT	B100
Cal Comp	J88b (Cricket EZ)
Cal Comp	A100
Cal Comp	A150
Cal Comp	A200 CAPTR
Cal Comp	A210
Cal Comp	A300
Casio	GzOne type S
Casio	C711 GzOne Boulder
Casio	C721 GzOne Exilim
Casio	C731 GzOne Rock
Casio	C741 GzOne Brigade
Casio	C751 GzOne Ravine
Casio	C771 GzOne Commando
Casio	C781 Ravine 2
Casio	C781T Ravine 3
Casio	C811 4G G'zOne
Celkon	Mega 4G Diamond
Celkon	UFeel 4G
Celkon	C345
Celkon	C9 JUMBO
Celkon	C108
Celkon	C349 Star
Celkon	A15
Celkon	A63
Celkon	A35K
Celkon	C2233
Celkon	U_DS Diamond
Changhong	008-IIM
Changhong	008-V
Changhong	008-VI
Changhong	K258
Changhong	G368
Cherry Mobile	Blaze 2.0
Cherry Mobile	Burst
Cherry Mobile	Burst 2.0
Cherry Mobile	Click
Cherry Mobile	Cosmos s
Cherry Mobile	Cosmos X
Cherry Mobile	Cosmos X2
Cherry Mobile	D8
Cherry Mobile	D15 TV
Cherry Mobile	Flame 2
Cherry Mobile	Flare 2X
Cherry Mobile	H120 Omega HD 2.0

Cherry Mobile	K1 Kiss
Cherry Mobile	Skyfire 2.0
Cherry Mobile	Thunder 2.0
Cherry Mobile	Spark TV
Cherry Mobile	Q9 TV
Cherry Mobile	QW1
Condor	CLB7502A Allure A9 Plus
Coolpad	T2-C01
Coolpad	T2-00
Coolpad	Y75
Coolpad	Y90
Coolpad	Y72-921 Fengshang Mini
Coolpad	Y91-921 Fengshang Pro 2
Coolpad	9190 T00 S6
Coolpad	Fova
Coolpad	C105-E0 S1
Coolpad	3310A Illumina
Coolpad	E503 Fancy 3
Coolpad	3600I Note 5
Coolpad	C103 Cool 1
Coolpad	POL-T0 Cool M7
Coolpad	cp3636a Canvas
Coolpad	5860E Quattro 4G
Coolpad	F620
Coolpad	801E Quattro II
Coolpad	801EM Quattro II
Coolpad	A8-831 Max
Coolpad	A8-930 Max
Coolpad	1803_DS
Coolpad	SAC-A0_DS 26
Coolpad	3320A
Coolpad	3622A
Coolpad	3632A Catalyst
Coolpad	3635A
Coolpad	5213
Coolpad	5217
Coolpad	5560S
Coolpad	5872
Coolpad	5879
Coolpad	5891
Coolpad	5950
Coolpad	7060
Coolpad	7231
Coolpad	7232
Coolpad	7235
Coolpad	7236
Coolpad	7269
Coolpad	7270
Coolpad	7295
Coolpad	7295A
Coolpad	7295C
Coolpad	7296
Coolpad	7560T Flo
Coolpad	8012
Coolpad	8085Q

Coolpad	8297W F1
Coolpad	8297-T01 Dashen F1 Plus
Coolpad	8675-A Dazen
Coolpad	8690 Dazen X7
Coolpad	8690_T00 Dazen X7
Coolpad	8681-A01 QiKU Phone Q Luna
Coolpad	QiKU 8681-M02
Coolpad	8712
Coolpad	8720Q
Coolpad	CP3700A Diamante
Coolpad	YuLong C3701A Revvl Plus
Coolpad	9190L_C00 S6
Coolpad	YuLong ivvi SS2-01 i3
Covia	CP-F03a (FleaPhone)
Covia	CP-L42A(FLEAZ POP)
Covia	CP-VL5A (i-dio Phone)
Covia	CP-B43(FLEAZ NEO)
Crosscall	Action-X3
Crosscall	Trendy
Crosscall	Shark V2
Crosscall	Spider X1
Crosscall	Odyssey_Plus
Crosscall	Trekker X1
Crosscall	Trekker M1
Cubot	Dinosaur
Cubot	Max
Cubot	Echo
Cubot	King Kong 3
Cubot	S208
Cubot	Rainbow 2
Cubot	X16 S
Datawind	DW-PS3G5 PocketSurfer
Daxian	C5
Daxian	06A
Daxian	M007
Daxian	DX F60
Daxian	A90
Daxian	K188
Daxian	R188
Daxian	YAO189
Daxian	F308
Daxian	X507
Daxian	520
Daxian	N560
Daxian	X607
Daxian	HX618
Daxian	688
Daxian	F858
Daxian	JX888
Daxian	A1806
Daxian	DM2068
Daxian	DX2078
Daxian	D2207
Daxian	KV5518
Daxian	KV5558

Daxian	KV5588
Daxian	KV5598
Daxian	T7000
Daxian	JH7888
Daxian	DX8816
Daxian	V8888
Daxian	DX9188
Daxian	DX9588
Daxian	C9999
Daxian	D58000
Dell	GS01 Streak Pro D43
Dell	Mini 3i
Dell	Streak
Dell	Streak Mini 5
Dell	Streak 7
Dell	V02S Venue Pro (USB)
Dell	V02S Venue Pro (BT)
Dell	XCD28
Dell	XCD35
Dell	3830 Venue 8
Digicel	DL750
Digicel	DL800
Donod	Donod 500C
Donod	Donod 5130C
Donod	Donod D800
Donod	Donod D906
Donod	Donod D908
Donod	Donod DX8
Doogee	X5
Doogee	X5 Pro
Doogee	X6 Pro
Doogee	X10
Doogee	N10
Doogee	Y8
Doogee	X10S
Doogee	S55
Doogee	X55
Doogee	S95Pro
Doogee	DG580 Kissme
Dopod	Magic
Dopod	S1
Dopod	Touch
Dopod	Touch HD
Dopod	A168
Dopod	C500
Dopod	S500
Dopod	535
Dopod	565
Dopod	566
Dopod	575
Dopod	577W
Dopod	586
Dopod	595
Dopod	D600
Dopod	S600

Dopod	P660
Dopod	696
Dopod	696i
Dopod	700
Dopod	S700
Dopod	C720
Dopod	C720W
Dopod	C730
Dopod	C750
Dopod	C800
Dopod	C858
Dopod	P800
Dopod	P800W
Dopod	D810
Dopod	818
Dopod	828
Dopod	828+
Dopod	818 Pro
Dopod	830 Pro
Dopod	838
Dopod	838 Pro
Dopod	P860
Dopod	D. S900 Touch Diamond
Dopod	U1000
Dopod	T2222 Touch Viva
Dopod	T3238
Dopod	A6188
Dopod	A6388
Dopod	A8188
Dopod	T8288
Dopod	T8388
Dopod	CHT9000
Dopod	CHT9100
Dopod	CHT9110
Doro	DFC-0180 7050
Doro	DFC-0190 7060
Doro	Primo 215
Doro	Primo 305
Doro	PhoneEasy 345
Doro	Primo 365
Doro	PhoneEasy 410
Doro	Primo 405
Doro	Primo 413
Doro	PhoneEasy 610
Doro	PhoneEasy 611
Doro	PhoneEasy 612
Doro	PhoneEasy 613 (USB)
Doro	PhoneEasy 613 (BT)
Doro	PhoneEasy 615
Doro	PhoneEasy 618
Doro	PhoneEasy 621
Doro	PhoneEasy 622
Doro	PhoneEasy 624
Doro	PhoneEasy 625
Doro	PhoneEasy 626 (Serial)

Doro	PhoneEasy 626 (BT)
Doro	PhoneEasy 631
Doro	632 PhoneEasy
Doro	PhoneEasy 632s
Doro	Liberto 810
Doro	Liberto 820
Doro	Liberto 820 Mini
Doro	PhoneEasy 740
Doro	Liberto 825
Doro	6030 PhoneEasy (USB)
Doro	6030 PhoneEasy (BT)
Doro	PhoneEasy 530X (USB)
Doro	PhoneEasy 530X (BT)
Doro	6031 (USB)
Doro	6031 (BT)
Doro	DFC-0080 6050
Doro	DFB-0210 1370
Doro	DFB-0070 5516
Doro	6521 (USB)
Doro	6521 (BT)
Doro	6531
Doro	DSB-0010 8030
Doro	DSB-0010 8031
Doro	8035
Doro	DSB-0090 8040
Elephone	P7000
Elephone	P8000
Elephone	P9000 Lite
Emobile	S21HT(Touch Diamond)
Emobile	S22HT(Dual Diamond)
Emobile	H11T
Emobile	S11HT (EMONSTER)
Emobile	S12HT(EMONSTER lite)
Emobile	S31HT(HTC Aria)
Emobile	S31HW(Poket WiFi S)
Emobile	S41HW(Poket WiFi S2)
Emobile	S42HW(smart bar)
Emobile	GS02
Emobile	S51SE(Sony Ericsson mini)
Emobile	GS01
Emobile	GS03
Emobile	GL07S (STREAM X)
Emobile	EM01L (NEXUS 5)
Emobile	EM01F (Arrows S)
Explay	RioPlay
Explay	MU220
Explay	Q232
Explay	Q233
Explay	B242
Explay	T280
Explay	A400
Fly	Ezzy Trendy
Fly	Ezzy 4
Fly	TS91
Fly	DS106

Fly	Banana_DS
Fly	TS107
Fly	Ezzy 7 Plus_DS
Fly	EZZY 9
Fly	DS115
Fly	TS114
Fly	DS123
Fly	DS124
Fly	E200
Fly	MC220
Fly	FF250_DS
Fly	IQ4414 Quad Evo Tech 3
Fly	IQ4410 Quad
Fly	IQ238 Jazz
Fly	IQ431 Glory
Fly	IQ440
Fly	IQ442 Quad
Fly	IQ443 Trend
Fly	IQ445 Genius
Fly	IQ446 Magic
Fly	IQ451 Quattro
Fly	IQ449 Pronto
Fly	IQ4411 Quad Energie 2
Fly	IQ4417 Quad ERA Energy 3
Fly	IQ4490i Era Nano 10
Fly	IQ4503 Quad Era Life 6
Fly	201118 Life Jet
Fly	151018 Life Compact 4G
Fly	261118 Life Play
Fly	FS458 Straus 7
Fly	IQ456 ERA Life 2
Fly	DS105C
Fly	E146
Freetel	FT142A (Priori2)
Freetel	SAMURAI MIYABI(FTJ152C)
Freetel	SAMURAI KIWAMI(FTJ152D)
Freetel	SAMURAI REI(FTJ161B)
Freetel	SAMURAI KIWAMI 2(FTJ162B)
Freetel	Priori3S LTE
Freetel	Priori4(FJT162D)
Fujitsu	F-01H Arrows Fit
Fujitsu	F-02G Arrows NX
Fujitsu	F-01J Arrows NX
Fujitsu	Arrows M04
Fujitsu	Arrows M03
G-Tide	G-TIDE G7
G-Tide	G-TIDE G9
G-Tide	G-TIDE G28
G-Tide	G-tide W520
G-Tide	G-TIDE L600
G-Tide	G-TIDE G838
GOLive	Dual Core Go Live
GOMobile	GO190
GOMobile	GO400
GOMobile	GO778

Garmin	Garminfone
Garmin	A50 Nuifone
GeeksPhone	BP1 blackphone
GeeksPhone	BP2H001AM1 Blackphone 2
GeneralMobile	Discovery
GeneralMobile	GM Discovery Elite
GeneralMobile	GM Discovery II
GeneralMobile	GM Discovery II Mini
GeneralMobile	4G AndroidOne
GeneralMobile	GM 5 Plus d
GeneralMobile	GM 6 d
Gigabyte	GSmart S1200
Gigabyte	GSmart S1205
Gigabyte	GSmart G1355
Gionee	M3 Marathon
Gionee	GN-100
Gionee	GN137
Gionee	GN151
Gionee	Gini S5 Pro
Gionee	GN5005L_DS
Gionee	F205_DS
Gionee	S11L
Gionee	F100S_DS
Gionee	F100SD_DS
Gionee	M6SPlus
Gionee	E6T
Gionee	20190619G_DS M11s
Gionee	GN5001_DS
Gionee	V188
Gionee	GN3003L_DS
Gionee	GN8003_DS M6
Gionee	Gini w5
Gionee	Gini W6
Gionee	M7
Gionee	Allview Gini W7
Gionee	BBL7505
Gionee	CBL7521
Gionee	Gini s4
Gionee	Gini N6
Gionee	Gini n7
Gionee	Gini N8
Gionee	Gini N9
Gionee	S11_DS
Gionee	SWW1617 A1 Plus
Gionee	S11S
Gionee	M7L
Gionee	M5_DS Marathon
Gionee	GN5007L
Gionee	S10BL
Gionee	20190620G_DS K3
Gionee	F5
Gionee	E6 Mini
Gionee	GN5005 Steel 2_DS
Gionee	GN5006 Jingang 3_DS
Gionee	M2017

Gionee	F6_DS
Gionee	M7 Plus
Gionee	F205L
Gionee	F205L (Bluetooth)
Gionee	E3 Elife
Gionee	Elife E7
Gionee	GN8002S_DS M6 Plus
Gionee	GN9011 Elife S8
Gionee	S10
Gionee	Elife S5.5
Gionee	E6 Elife
Gionee	TD103
Gionee	A320
Gionee	GN777
Gionee	X817
Gionee	L900
Gionee	GN9006 Elife S7
Gionee	P5W Pioneer
Gionee	F100_DS
Gionee	W900
Gionee	W909 Cheonjian Dual
Gionee	X805
Gionee	GN708W
Gionee	GN8001 M5 Plus
Gionee	V182
Gionee	V183
Gionee	V185
Gionee	V188S_DS
Gionee	GN190801_DS
Google	C1502W Pixel C
Google	G-2PW4100 Pixel
Google	G-2PW2100 Pixel XL
Google	Taimen go11c
Google	Pixel 2
Google	G013A Pixel 3
Google	G013A Pixel 3 XL
Google	G013C Pixel 3 XL
Google	Pixel 3a XL
Google	Pixel 2 XL
Google	G020I Pixel 4
Google	G020P Pixel 4 XL
HP	Elite x3 (USB)
HP	Elite x3 (BT)
HP	iPAQ rw6815
HP	iPAQ rw6915
HP	HP-500 Series Ipaq
HP	iPAQ 910c
HP	P130www Pre 3 CDMA (USB)
HP	P130www Pre 3 CDMA (BT)
HP	P130una Pre 3 GSM (USB)
HP	P130una Pre 3 GSM (BT)
HP	P160UNA Veer (USB)
HP	P160UNA Veer (BT)
HTC	Generic Android (Logical Bypassing Lock)
HTC	Generic Android (Logical ADB Normal(Recommended))

HTC	Wildfire X
HTC	X2-HT X2
HTC	HTC 10
HTC	2PS5100 One X9
HTC	2PXH200 X10u One X10
HTC	2PS6200 10
HTC	2PS6500 10
HTC	2PZC100 U-3h U11
HTC	U11 Life
HTC	2PQ9120 One A9
HTC	2Q4R100 U11 EYEs
HTC	2Q4D100 U11 Plus
HTC	Orbit II Polaris
HTC	HTCD100LVW
HTC	2PQ9100 One A9
HTC	2PQ912 One A9
HTC	HTCD200LVW
HTC	HTCD160LVW
HTC	PM33100 First
HTC	Touch Pro
HTC	One
HTC	U-1w Ultra
HTC	0P3P7 One Max
HTC	0P3P500 One Max
HTC	0P4E1 Desire
HTC	0PGQ120 Desire 520
HTC	0PGQ100 Desire 520
HTC	0P9C700 Desire 816
HTC	7060 Desire 700
HTC	0P4O300 700 Desire dual sim
HTC	0PL4100 desire 526G
HTC	0PFJ400 D820n Desire 820
HTC	0PA2110\HTC_V1 Desire 310
HTC	0P9C200 Desire 816
HTC	0P90201 Desire 610
HTC	0P6B120 One M8
HTC	0PKV100 One M8s
HTC	0P6B100 One M8
HTC	0P6B130 One M8
HTC	0P6B160 One M8
HTC	0P6B180 One M8 for Windows (USB)
HTC	0P6B180 One M8 for Windows (BT)
HTC	0P8B210 One Mini 2
HTC	0P8B200 One Mini 2
HTC	0PCV100
HTC	0PCV200 Desire 510
HTC	0PCV220 Desire 510
HTC	C2 Desire 516 dual sim
HTC	0PFH1 Desire EYE
HTC	0PFH200 M910x Desire Eye
HTC	2PQ93 One A9
HTC	One A9S
HTC	102E Desire 200
HTC	Desire 300
HTC	Desire 310

HTC	D310w Desire 310
HTC	0PF1100 Desire 320
HTC	Desire 826
HTC	HTC331ZLVW
HTC	HTL21 J Butterfly
HTC	HTL23 J Butterfly
HTC	HTC331ZL Desire 612
HTC	HTC331ZLW Desire 612
HTC	PN07100 M7 One
HTC	0P9O110
HTC	0PM9120 Desire 626
HTC	2PST2 Desire 530
HTC	0PM92 Desire 626
HTC	0P4E230 Desire 601
HTC	606h Desire 600
HTC	609d Desire
HTC	D616w Desire 616
HTC	A620m 8s (USB)
HTC	A620m 8s (BT)
HTC	C625a 8X (USB)
HTC	C625a 8X (BT)
HTC	831C One M8
HTC	PN07120 One
HTC	PN07120 One Google Play
HTC	PN07130 One
HTC	PN072 One
HTC	C110e Radar (USB)
HTC	C110e Radar (BT)
HTC	T327E Desire U
HTC	PL01210 Desire C
HTC	A810a ChaCha
HTC	PH06130 Status
HTC	PH06130 ChaCha
HTC	U12 Plus
HTC	2Q6E100 U12 Life
HTC	2Q8L100 Desire 19s
HTC	ZPZM100 U Play
HTC	2PZC300 U-3u U11
HTC	2PVG200 Desire 628
HTC	2Q7A100 U19e
HTC	Desire 19+
HTC	2Q5W100 Desire 12 Plus
HTC	802d One
HTC	802w One
HTC	ADR6400 Cobalt
HTC	HTC6525LVW One M8
HTC	0PJA2 One M9
HTC	0PJA100 One M9
HTC	0PJA120 HTC One M9
HTC	0PJA110 One (M9)
HTC	0PE6400 Desire 620
HTC	HTC6535LVW One M9
HTC	HTC6545LVW 10
HTC	2PUK200 Desire 10 Lifestyle
HTC	A7272 Desire Z

HTC	myTouch 3G
HTC	myTouch 3G Slide
HTC	myTouch 4G Glacier
HTC	PG58100 Pyramid
HTC	PG58100 Sensation 4G
HTC	PJ40110 One S
HTC	0I06110 Radar 4G (USB)
HTC	0I06110 Radar 4G (BT)
HTC	PI06110 Radar 4G (USB)
HTC	PI06110 Radar 4G (BT)
HTC	Smart
HTC	Click
HTC	Tattoo
HTC	D816w Desire 816
HTC	A8181 Bravo GSM
HTC	A8181 Desire GSM
HTC	HD mini
HTC	Legend
HTC	Wildfire S
HTC	G1 Dream
HTC	PC10100 G2
HTC	Apache
HTC	Google Nexus One
HTC	Harrier
HTC	T8585 Touch HD2
HTC	A61XX Magic
HTC	Hero GSM
HTC	Hero CDMA
HTC	Hero (Cox)
HTC	MTeoR
HTC	HD7 (USB)
HTC	HD7 (BT)
HTC	MSM7x30 Omega (USB)
HTC	MSM7x30 Omega (BT)
HTC	T222X Touch Viva
HTC	T320e One V
HTC	T328d Desire VC
HTC	T328w Wind
HTC	T329d Desire XC
HTC	T329w Desire X
HTC	A3333 Wildfire
HTC	506e Desire 500
HTC	A510c Wildfire S
HTC	PG76100\A510e Wildfire S
HTC	S510e Desire S
HTC	S510b Rhyme
HTC	PL80100 One SV
HTC	C525c One SV
HTC	PL80110 One SV
HTC	T528d
HTC	T528w Desire 400
HTC	T528d One SC
HTC	T535X Touch Diamond2
HTC	P510e Flyer
HTC	T323X Touch 3G

HTC	S621 Excalibur
HTC	T737X Touch Pro2
HTC	T828x Touch HD
HTC	TyTN
HTC	TyTN II
HTC	S350
HTC	S511 Snap
HTC	S520
HTC	C520e One SV
HTC	710C
HTC	S521
HTC	S523 Snap
HTC	D610X Desire 610
HTC	D825U Desire 825
HTC	S720e One X Endeavor
HTC	S620
HTC	S630
HTC	S631
HTC	S710
HTC	S711
HTC	S710e Incredible S
HTC	Z710e Sensation
HTC	T528t One ST
HTC	S720
HTC	S730
HTC	S740
HTC	0PAJ5 One E8
HTC	0PAJ100 M8Ss One E8
HTC	E9w One E9
HTC	801e One
HTC	803s One Max
HTC	PL02100 Desire C
HTC	H3000C One SV
HTC	H3000C One SV Refresh
HTC	P3050 Vogue
HTC	P3100
HTC	A310e Explorer
HTC	PJ03100 Explorer
HTC	P3300
HTC	P3301
HTC	T3333 Mega
HTC	T3333 Touch2
HTC	P3400
HTC	P3401
HTC	P3450 Touch
HTC	P3470
HTC	P3600
HTC	P3650 Touch Cruise
HTC	P3700 Touch Diamond
HTC	P4000
HTC	T4242 Touch Cruise 09
HTC	P4300
HTC	P4350
HTC	P4500
HTC	P4550

HTC	P4600
HTC	P4601
HTC	P4602
HTC	5088 Desire
HTC	ADR6330VW
HTC	PI46110 Rhyme
HTC	F5151 Freestyle
HTC	PD53100 Freestyle
HTC	P5500 Touch Dual
HTC	P5520 Touch Dual
HTC	5800 Fusion
HTC	SMT 5800
HTC	A7373 Evo Shift 4G
HTC	PG06100 Evo Shift 4G
HTC	T7373 Evo Shift 4G
HTC	XV6175 Ozone (CDMA)
HTC	XV6175 Ozone (GSM)
HTC	ADR6200VW Droid Eris
HTC	ADR6225 Wildfire A315c
HTC	6230 Wildfire
HTC	ADR6250 Hero200
HTC	6275
HTC	PB99400 Desire CDMA
HTC	6285 Hero S
HTC	ADR6285 Aquire
HTC	ADR6300 Droid Incredible
HTC	6320 Kingdom
HTC	ADR6325 Merge
HTC	ADR6350 Droid Incredible 2
HTC	ST6356
HTC	A6366 Aria
HTC	A6380 Gratia
HTC	ADR6400L Thunderbolt
HTC	ADR6425LVW Rezound
HTC	PH98100 Rezound
HTC	P6500 Sedna
HTC	6800 Mogul
HTC	PPC6800 Mogul
HTC	6850 Fuze
HTC	6850 Touch Pro
HTC	6900 Touch
HTC	XV6900 Touch
HTC	6950 Touch Diamond
HTC	MWP6985 Trophy (USB)
HTC	MWP6985 Trophy (BT)
HTC	301e Desire
HTC	X310e Titan (USB)
HTC	X310e Titan (BT)
HTC	6600LVW One Max
HTC	ADR6435LVW Droid DNA
HTC	T8686 7 Trophy (USB)
HTC	T8686 7 Trophy (BT)
HTC	7 Mozart (USB)
HTC	7 Mozart (BT)
HTC	T7272 Touch Pro

HTC	T7380 Touch Pro 2
HTC	Advantage X7500
HTC	6875 Tilt2 (CDMA)
HTC	6875 Touch Pro2 (CDMA)
HTC	6875 Tilt2 (GSM)
HTC	6875 Touch Pro2 (GSM)
HTC	HTC6500LVW One
HTC	HTC6515LVW One Remix
HTC	HTC6995LVW One M8 (USB)
HTC	HTC6995LVW One M8 (BT)
HTC	XV6975 Imagio (CDMA)
HTC	MWP6885 7 Pro (USB)
HTC	MWP6885 7 Pro (BT)
HTC	XV6975 Imagio (GSM)
HTC	PN07200 One
HTC	PC93100 Arrive (USB)
HTC	T7575 Arrive (USB)
HTC	PC93100 Arrive (BT)
HTC	T7575 Arrive (BT)
HTC	A8180 Desire
HTC	T8788 Surround (USB)
HTC	T8788 Surround (BT)
HTC	T9188 Touch Pro2
HTC	A9191 Desire HD
HTC	PD98100 Desire HD
HTC	T9193 HD2
HTC	A9292 Evo 4G\PC36100 Evo 4G
HTC	9292 Desire HD 7 (USB)
HTC	9292 Desire HD 7 (BT)
HTC	T9295 HD7S (USB)
HTC	T9295 HD7S (BT)
HTC	PL01100\A320e Desire C
HTC	PL01110 Desire C
HTC	PL01130 Desire C
HTC	PL01200 Desire C
HTC	PH11120 Salsa
HTC	D20822 Marvel
HTC	PM23220 8X (USB)
HTC	PM23220 8X (BT)
HTC	PM23200 8X (USB)
HTC	PM23200 8X (BT)
HTC	PM23300 8X (USB)
HTC	PM23300 8X (BT)
HTC	PM23320 8X (USB)
HTC	PM23320 8X (BT)
HTC	PM36100 One VX
HTC	PH39100 Vivid
HTC	PI39100 Titan (USB)
HTC	PI39100 Titan (BT)
HTC	PI39200 Sensation XL
HTC	PJ40100 One S
HTC	PJ40200 One S
HTC	PG41200 Evo View 4G
HTC	PJ46100 One X
HTC	PC49100 Wildfire

HTC	PM59100 8S (USB)
HTC	PM59100 8S (BT)
HTC	6990L 8X (USB)
HTC	6990L 8X (BT)
HTC	PG76210 Wildfire
HTC	PH44100 Evo Design 4G
HTC	PG58130 Sensation XE
HTC	PO58200 One Mini M4
HTC	PO58220 One Mini
HTC	One Mini
HTC	PG59100 myTouch 4G Slide
HTC	ADR6410 Desire LTE
HTC	ADR6410L Droid Incredible 4G
HTC	Droid Incredible 4G LTE ADR6410 Fireball
HTC	ADR6410LVW Incredible 4G
HTC	PB65100 MyTouch 3G Slide
HTC	PM66100 Desire X
HTC	T328e Desire X
HTC	PN07140 One
HTC	PJ75100 EVO 4G LTE
HTC	PB76100 Legend
HTC	PK76100 One V
HTC	ADR6290 One V
HTC	PK76110 One V
HTC	PK76310 One V
HTC	PG76240 Wildfire S
HTC	PK76300 One V
HTC	PL80120 One SV
HTC	0P82100 Nexus 9
HTC	PJ83100 One X
HTC	PJ83120 One XL
HTC	X325s One XL
HTC	PH85110 Amaze 4G
HTC	PI86100 Titan II (USB)
HTC	PI86100 Titan II (BT)
HTC	PM86100 Desire SV
HTC	0PKX210 Desire 626
HTC	0PM9110 Desire 626s
HTC	PG86100 Evo 3D
HTC	PG86100 Evo V 4G
HTC	PG86300 Evo 3D
HTC	PG86310 Evo 3D
HTC	A9192 Inspire 4G
HTC	PD98120 Inspire 4G
HTC	PM63100 One X+
HTC	PO68220 Butterfly S
HTC	PL99110X920d Butterfly
HTC	PB99200 Desire
HTC	PO88100 8XT (USB)
HTC	PO88100 8XT (BT)
AT&T	M3620
AT&T	2100
AT&T	2125
AT&T	3100
AT&T	3125

AT&T	8100
AT&T	8125
AT&T	8500
AT&T	8525
AT&T	8925 Tilt
I-mate	JAM
I-mate	JAMin
I-mate	JASJAM
I-mate	K-JAM
I-mate	PDA
I-mate	PDA2K
I-mate	PDA2k EVDO
I-mate	Smartflip
I-mate	i-mate SP2
I-mate	i-mate SP3
I-mate	SP3i
I-mate	SP4m
I-mate	SP5
I-mate	mate SP5m
I-mate	SPJAS
O2	Jet
O2	XDA Atmos
O2	XDA Guide
O2	XDA II
O2	XDA II mini
O2	XDA III
O2	XDA IIs
O2	XDA Cosmo
O2	XDA Diamond
O2	XDA Ignito
O2	Xda Diamond Pro
O2	XDA Mantle
O2	XDA mini Pro
O2	XDA mini S
O2	XDA Neo
O2	XDA Nova
O2	XDA Orbit
O2	XDA Orbit II
O2	XDA IQ
O2	XDA Orion
O2	XDA Phone
O2	XDA Terra
O2	XDA Trion
O2	XDA Serra
O2	XDA Star
O2	XDA Stellar
O2	XPhone
O2	XPhone II
QTEK	S100
QTEK	S110
QTEK	G200
QTEK	S200
QTEK	2020
QTEK	2060
QTEK	8010

QTEK	Qtek 8020
QTEK	8060
QTEK	8080
QTEK	8200
QTEK	8300
QTEK	8310
QTEK	8500
QTEK	8600
QTEK	9090
QTEK	9100
QTEK	9600
Orange (SPV)	Neva 80
Orange (SPV)	Hapi 30
Orange (SPV)	Rise 31
Orange (SPV)	4015X One Touch Pop C1
Orange (SPV)	Boston
Orange (SPV)	Blade Apex 2(Orange Hi 4G)
Orange (SPV)	Orange Rono
Orange (SPV)	Orange Dive 30
Orange (SPV)	SCL-L01 Orange Dive 70
Orange (SPV)	Orange Nura
Orange (SPV)	SPV E200
Orange (SPV)	SPV C500
Orange (SPV)	SPV E500
Orange (SPV)	SPV M500
Orange (SPV)	SPV C550
Orange (SPV)	SPV C600
Orange (SPV)	SPV E600
Orange (SPV)	SPV M600
Orange (SPV)	SPV E650
Orange (SPV)	SPV M650
Orange (SPV)	SPV C700
Orange (SPV)	SPV M700
Orange (SPV)	SPV M1000
Orange (SPV)	SPV M2000
Orange (SPV)	SPV M3000
Orange (SPV)	SPV M3100
Orange (SPV)	SPV M6000
T-Mobile	Ameo
T-Mobile	Dash
T-Mobile	Dash 3G
T-Mobile	Pulse
T-Mobile	Dream G1
T-Mobile	HD7 (USB)
T-Mobile	HD7 (BT)
T-Mobile	PI06110 Radar 4G (USB)
T-Mobile	PI06110 Radar 4G (BT)
T-Mobile	PJ40110 One S
T-Mobile	Touch G2
T-Mobile	T-Mobile G2
T-Mobile	myTouch 3G
T-Mobile	myTouch 3G Slide
T-Mobile	myTouch 4G Glacier
T-Mobile	myTouch 4G Slide
T-Mobile	MDA (USA)

T-Mobile	MDA Basic
T-Mobile	MDA II
T-Mobile	MDA II music
T-Mobile	MDA III
T-Mobile	MDA Compact
T-Mobile	MDA Compact II
T-Mobile	MDA Compact III
T-Mobile	MDA Compact IV
T-Mobile	MDA Compact V
T-Mobile	MDA Mail
T-Mobile	MDA Touch
T-Mobile	MDA Touch Plus
T-Mobile	Vairy Text
T-Mobile	Vairy Touch
T-Mobile	MDA Vario
T-Mobile	MDA Vario II
T-Mobile	MDA Vario III
T-Mobile	MDA Vario IV
T-Mobile	MDA Vario V
T-Mobile	SDA
T-Mobile	SDA music II
T-Mobile	Sensation 4G
T-Mobile	Shadow
T-Mobile	Shadow 2009
T-Mobile	Touch Pro 2
T-Mobile	Wing II
T-Mobile	Wing P4350 Herald
T-Mobile	Wildfire S
T-Mobile	Touch HD2
T-Mobile	Shadow II
T-Mobile	Sidekick (2008)
T-Mobile	Sidekick LX
T-Mobile	Sidekick LX (2009)
T-Mobile	Sidekick Slide
T-Mobile	Sidekick 3
T-Mobile	U8150 Comet
T-Mobile	PH85110 Amaze 4G
Haier	H-U90T
Haier	HG-V77
Haier	HT-I600
Haier	HT-I860
Hisense	STARSHINE 4
Hisense	C20 Infinity KO
Hisense	HLTE202N A5
Hisense	HLTE730T A6L
Hisense	HS-T930
Hisense	HS-U930
Hisense	HS-U688 Infinity Pro
Hisense	HS-U988 Infinity H3
Hisense	F20
Hisense	F23
Hisense	F31
Hisense	E76
Hisense	E270BSA
Hisense	L675

Hisense	HS-E830
Hisense	HS-EG929
Hisense	L678 STARADDICT 5
Hisense	STARACTIVE 2
Homtom	HT70
Homtom	H10
Homtom	S16
Homtom	S17_DS
Homtom	HT7
Homtom	HT16
Homtom	S8
Homtom	S9 Plus
Homtom	S99
Homtom	Z8 Zoji
Homtom	C2
Huawei	Generic Android
Huawei	Joy
Huawei	CRR-L09 Mate S
Huawei	NXT-CL00 Mate 8
Huawei	RIO-UL00 G7 Plus
Huawei	BKK-AL10_DS Honor 8C
Huawei	MOA-AL00_DS Honor 9A
Huawei	MHA-AL00 Mate 9
Huawei	ALP-AL00 Mate 10
Huawei	VNS-L23 P9 lite
Huawei	ART-TL00X
Huawei	YAL-AL50
Huawei	LIO-L29 Mate 30 Pro
Huawei	BLA-L09 Mate 10 Pro
Huawei	HWI-TL00 Nova 2S
Huawei	DRA-LX3_DS Y5 2018
Huawei	ARS-L22_DS Y Max
Huawei	KIW-L21_DS Honor 5X
Huawei	FIG-LX2 Y7s
Huawei	HWV31 Nova 2 AU
Huawei	ELE-L29_DS P30
Huawei	DIG-AL00C00B210 Enjoy 6s
Huawei	JNY-AL10_DS Nova 6SE
Huawei	MAR-LX1A P30 Lite
Huawei	HRY-LX1MEB Honor 10 Lite
Huawei	JNY-LX2_DS Nova 7i
Huawei	AKA-AL10_DS Honor Play4T
Huawei	FIG-AL00 Enjoy 7S
Huawei	GLK-AL00 Nova 5i
Huawei	SEA-AL00 Nova 5
Huawei	SPN-AL00_DS Nova 5z
Huawei	SPN-AL00_DS Nova 5i Pro
Huawei	YAL-AL00_DS Honor 20
Huawei	MED-LX9_DS Y6p
Huawei	JMM-AL00 Honor V9 Play
Huawei	OXF-AN00 Honor V30
Huawei	CDY-AN00_DS Nova 7 SE 5G
Huawei	WLZ-AN00_DS Nova 6 (5G)
Huawei	KSA-AL00_DS Honor Play 8
Huawei	WLZ-AL10_DS Nova 6

Huawei	TEL-AN00_DS Honor X10
Huawei	AMN-LX3_DS Y5 2019
Huawei	HLK-AL10 Honor 9X Pro
Huawei	DUB-TL00_DS
Huawei	PAR-TL00 Nova 3
Huawei	MRX-W09 MatePad Pro
Huawei	JEF-AN00_DS Nova 7 5G
Huawei	CDY-AN90_DS Honor 30S
Huawei	YAL-L21_DS Nova 5T
Huawei	ELS-NX9 P40 Pro
Huawei	ASK-AL00X_DS Honor Play3
Huawei	CLT-L04 P20 Pro
Huawei	MRD-LX1 Y6 2019
Huawei	DUB-LX2_DS Y7 Pro 2019
Huawei	LDN-L01 Y7 2018
Huawei	DUB-LX3_DS Y7 2019
Huawei	STK-L22 Y9 Prime 2019
Huawei	STK-AL00 Enjoy 10 Plus
Huawei	STK-LX3 Honor 9X
Huawei	LLD-AL00 Honor 9 Lite
Huawei	MED-AL00_DS Enjoy 10e
Huawei	NEO-L29_DS Mate Rs
Huawei	HLK-AL00 Honor 9X
Huawei	STK-L21 Y9
Huawei	MAR-AL00 nova 4e
Huawei	HRY-AL00Ta Honor 20i
Huawei	MRD-AL00_DS Enjoy 9e
Huawei	ARE-AL00_DS Honor 8x Max
Huawei	POT-AL00a Enjoy 9s
Huawei	YAL-AL10 Honor 20 PRO
Huawei	PCT-L29_DS Honor View 20
Huawei	COR-AL00 Honor Play
Huawei	EVR-L29 Mate 20 X
Huawei	SNE-AL00 Maimang 7
Huawei	EVR-AL00 Mate 20 X
Huawei	VCE-AL00_DS Nova 4
Huawei	JAT-LX3 Honor 8A
Huawei	POT-LX3 P Smart
Huawei	VOG-L29 P30 Pro
Huawei	AUM-L33 Honor 7A
Huawei	DUA-L22 Honor 7S
Huawei	MHA-L29 Mate 9
Huawei	EVA-L19 P9
Huawei	EVA-L09 P9
Huawei	VIE-L09 P9 Plus
Huawei	VTR-AL00 P10
Huawei	VTR-L09 P10
Huawei	EVA-AL00 P9
Huawei	EML-AL00 P20
Huawei	ANE-AL00 Nova 3E
Huawei	LDN-LX2 Nova 2 Lite
Huawei	LDN-LX3 y7 (2018)
Huawei	LLD-AL20 Honor 9i
Huawei	ANE-LX2J Nova 3E
Huawei	DUB-AL20_DS Enjoy 9

Huawei	JMM-L22 Honor 6C Pro
Huawei	AGS2-L09 MediaPad T5
Huawei	COR-L29 Honor Play
Huawei	PCT-TL10_DS Honor V20
Huawei	TRT-TL10 Enjoy 7 Plus
Huawei	AQM-AL00_DS Enjoy 10S
Huawei	SHT-W09 Mediapad M5
Huawei	EVA-CL00 P9
Huawei	ERT-A09 VENUS ERT
Huawei	EVA-AL10 P9
Huawei	VIE-AL10 P9 Plus
Huawei	VNS-L22 P9 lite
Huawei	VIE-L29 P9 Plus
Huawei	VTR-L29 P10
Huawei	VKY-L09 P10 Plus
Huawei	VKY-L29 P10 Plus
Huawei	VKY-AL00 P10 Plus
Huawei	YKY-L29A P10 Plus
Huawei	VNS-L31 Huawei P9 Lite
Huawei	VNS-L52 P9 Lite
Huawei	WAS-AL00 Nova Lite
Huawei	WAS-LX1A Huawei P10 Lite
Huawei	CRR-CL00 Mate S
Huawei	CRR-UL00 Mate S
Huawei	NXT-AL10 Mate 8
Huawei	NXT-DL00 Mate 8
Huawei	VNS-AL00 G9 Lite
Huawei	VNS-DL00 G9 Dual
Huawei	NXT-L09 Mate 8
Huawei	NXT-TL00 Mate 8
Huawei	LON-L29 Mate 9 Pro
Huawei	NXT-L29 Mate 8
Huawei	LLD-L31 Honor 9 Lite
Huawei	NMO-GT3
Huawei	NMO-L31 GR5 Mini
Huawei	CRR-TL00 Mate S
Huawei	CAM-TL00H_DS Honor Play 5A
Huawei	POT-AL00 Maimang 8
Huawei	JNY-LX1_DS P40 Lite
Huawei	SEA-AL10_DS Nova 5 Pro
Huawei	KIW-TL00H Honor 5X
Huawei	RIO-L01 G7 Plus
Huawei	RIO-L03 G8
Huawei	RIO-TL00 G7 Plus
Huawei	CAM-UL00 Honor 5A
Huawei	NEM-L21 Honor 5C
Huawei	MLA-UL00 G9 Plus
Huawei	NEM-L51 Honor 5C
Huawei	NEM-TL00 Honor 5C
Huawei	KIW-AL10 Honor 5X
Huawei	GRA-UL00 P8 Standard Edition
Huawei	GRA-CL00 P8 Standard Edition
Huawei	GRA-TL00 P8
Huawei	GRA-CL10 P8
Huawei	GRA-UL10 P8

Huawei	W1-U00 Ascend (USB)
Huawei	W1-U00 Ascend (BT)
Huawei	ALE-TL00 P8 Lite
Huawei	ALE-UL00 P8 Lite
Huawei	ALE-CL00 P8 Lite
Huawei	MT7-TL00 Ascend Mate 7
Huawei	MT7-TL10 Ascend Mate 7
Huawei	Y336-A1 Ascend
Huawei	MT2-L03 Ascend Mate 2
Huawei	KII-L05 GR5
Huawei	MT2-L05 Ascend Mate 2
Huawei	G7-L01 Ascend
Huawei	G7-L03 Ascend G7
Huawei	UL20 Ascend G7
Huawei	ALE-L02 P8 Lite
Huawei	ALE-L04 P8 Lite
Huawei	ALE-L21 P8 Lite
Huawei	PRA-LX1 P8 Lite 2017
Huawei	LEO-BX9 Watch 2 1415
Huawei	ALE-L23 P8 Lite
Huawei	KIW-L24 TexasA1
Huawei	GRA-UL10 P8 Premium Edition
Huawei	GRA-L09 P8
Huawei	P6-T00 Ascend
Huawei	STF-AL00 Honor 9
Huawei	STF-AL10 Honor 9
Huawei	BKL-AL00 Honor V10
Huawei	TNY-AL00 Honor Magic 2
Huawei	BKL-L09 Honor View 10
Huawei	MT7-CL00 Ascend Mate 7
Huawei	MT7-L09 Ascend Mate 7
Huawei	H30-L02 Honor 3C
Huawei	H30-U10 Honor 3C
Huawei	T1-701u Honor Play 7.0
Huawei	CHM-UL00 Honor 4C
Huawei	Y320-U151 Ascend
Huawei	PE-TL20 Honor 6 Plus
Huawei	PE-UL00 Honor 6 Plus
Huawei	EDI-AL10 Honor Note 8
Huawei	RVL-AL09 Honor Note 10
Huawei	W2-U00 Ascend W2 (USB)
Huawei	W2-U00 Ascend W2 (BT)
Huawei	MT7-UL00 Ascend Mate 7
Huawei	SCL-AL00 Honor 4A
Huawei	PE-CL00 Honor 6 Plus
Huawei	HN3-U01 Honor 3
Huawei	PLK-TL01H Honor 7
Huawei	PLK-AL10 Honor 7
Huawei	FRD-L14 Honor 8
Huawei	PRA-AL00 Honor 8
Huawei	DUK-L09 Honor 8 Pro
Huawei	DUK-AL20 Honor V9
Huawei	BND-AL10 Honor Changwan 7X
Huawei	CAZ-AL10 Nova
Huawei	KNT-AL10 Honor V8

Huawei	PLK-UL00 Honor 7
Huawei	PLK-CL00 Honor 7
Huawei	ATH-AL00 Honor 7i
Huawei	ATH-CL00H Honor 7i
Huawei	ATH-TL00H Honor 7i
Huawei	RIO-CL00 G7 Plus
Huawei	RIO-L02 G7 Plus
Huawei	RIO-AL00 G7 Plus
Huawei	Ascend P2 DC LTE
Huawei	Y360-U23
Huawei	GS03 Emobile
Huawei	MT1-U06 Ascend Mate
Huawei	P6-U06 Ascend P6
Huawei	P7-L00 Ascend P7
Huawei	P6-C00 Ascend P6
Huawei	GL07S STREAM X
Huawei	P7-L07 Ascend P7
Huawei	P7-L09 Ascend P7
Huawei	P7-L10 Ascend P7
Huawei	S7 Ideos
Huawei	T-Touch Tab
Huawei	EVR-N29 Mate 20 X 5G
Huawei	LIO-AN00 Mate 30 Pro 5G
Huawei	LRA-AL00_DS Honor 20 Lite
Huawei	TAS-AN00 Mate 30 5G
Huawei	MRD-LX3_DS Y6 2019
Huawei	S7-301u MediaPad
Huawei	S7-303u SpringBoard
Huawei	S10-103LT Mediapad 10 FHD
Huawei	PLE-703L MediaPad M2 7.0
Huawei	CPN-AL00 MediaPad M3 Lite 8
Huawei	CPN-L09 MediaPad M3 Lite 8
Huawei	KOB-L09 MediaPad T3
Huawei	MAR-LX3A P30 Lite
Huawei	BAH-W09 MediaPad M3 Lite 10
Huawei	BAH2-W19 MediaPad M5 Lite
Huawei	MYA-L41 Y6 2017
Huawei	JSN-L23 Honor 8X
Huawei	C199s Maimang S3
Huawei	INE-LX2 Nova 3i
Huawei	S10-231W MediaPad 10 Link+
Huawei	403HW MediaPad
Huawei	H60-L01 Honor 6
Huawei	H60-L02 Honor 6
Huawei	U120
Huawei	B199
Huawei	Y210-0151 Ascend
Huawei	Y210-2010
Huawei	Y221-U03 Ascend
Huawei	U8685D Ascend Y210
Huawei	Y340-U081 Ascend Y340
Huawei	M228
Huawei	Y300C
Huawei	Y300-0100 Ascend
Huawei	Y330-U01 Ascend

Huawei	Y330-U05 Ascend
Huawei	Y301A1 Valiant
Huawei	Y301A2 Vitria
Huawei	M318
Huawei	M328
Huawei	Y320-U01 Ascend
Huawei	G510 Ascend
Huawei	G510-0200 Orange Daytona
Huawei	G510-0251 Ascend
Huawei	Y520-U03 Ascend
Huawei	Y560-L01
Huawei	Y600-U00 Ascend
Huawei	Y560-L03 Ascend
Huawei	Y511 Ascend
Huawei	G520 Ascend
Huawei	G525 Ascend
Huawei	G527-U081 Ascend G527
Huawei	Y220-U05 Ascend Y220
Huawei	Y530-U051 Ascend
Huawei	CUN-L01 Y5 II
Huawei	CUN-L21 Y5II
Huawei	CAM-L21 Honor 5A
Huawei	Y538 Union
Huawei	Y550-L01 Ascend
Huawei	Y550-L03 Ascend
Huawei	Y536A1
Huawei	G535-L11 Kestrel EE
Huawei	M570
Huawei	M580
Huawei	G610-U00
Huawei	G610-U20 Ascend G610
Huawei	G615-U10 Ascend
Huawei	Y625-U13 Ascend
Huawei	G620S-L01 Ascend Alek 4G
Huawei	BAC-AL00 Nova 2 Plus
Huawei	JAT-AL00_DS Honor 8A
Huawei	JKM-TL00 Enjoy 9 Plus
Huawei	PIC-AL00 Nova 2
Huawei	BLA-A09 Mate 10 Pro
Huawei	BLA-L29 Mate 10 Pro
Huawei	BLA-AL00 Mate 10 Pro
Huawei	EML-L09 P20
Huawei	COL-L29 Honor 10
Huawei	HRY-AL00a Honor 10 Lite
Huawei	JSN-AL00a Honor 8X
Huawei	PAR-AL00 Nova 3
Huawei	INE-AL00 Nova 3I
Huawei	EML-L29 P20
Huawei	LND-L29 Honor 7C
Huawei	AUM-L41_DS Honor 7C
Huawei	C199 Maimang
Huawei	ANE-LX1 P20 Lite
Huawei	ANE-LX3 P20 Lite
Huawei	FLA-AL20 Enjoy 8 Plus
Huawei	FLA-LX3 Y9 2018

Huawei	JKM-LX3 Y9 2019
Huawei	FIG-LX1 P Smart
Huawei	ATU-TL10 ENJOY 8e
Huawei	DUB-AL00 Enjoy 9
Huawei	CLT-L09 P20 Pro
Huawei	C8815
Huawei	BLN-L24 Honor 6X
Huawei	CAN-L01 Nova
Huawei	Y625-U43
Huawei	Y625-U51
Huawei	G630-U251 Ascend
Huawei	Y635-L01 Ascend
Huawei	LYO-L01 Y6 II
Huawei	LUA-L21 Y3II
Huawei	Y635-L02 Ascend
Huawei	M650
Huawei	M635 Pinnacle
Huawei	M636
Huawei	T1-701w T1 7.0
Huawei	GEM-703L Honor X2
Huawei	DAV-703L P8 Max
Huawei	G700-U00 Ascend
Huawei	M735
Huawei	M660 Ascend Q
Huawei	G730-U00 Ascend
Huawei	G730-U251 Ascend
Huawei	G735-L03 G Play
Huawei	736
Huawei	G740-L00 Ascend
Huawei	G750-T00 Honor 3X
Huawei	M750
Huawei	830i
Huawei	M835 Ascend
Huawei	M835SE Ascend
Huawei	M860 Ascend
Huawei	M860SE Ascend
Huawei	M865 Ascend II
Huawei	M865 Sonic
Huawei	M865C
Huawei	M866
Huawei	H866C Ascend
Huawei	H868C Glory
Huawei	H871G Magna
Huawei	H881C Ascend Plus
Huawei	H883G W1 (USB)
Huawei	H883G W1 (BT)
Huawei	M886 Mercury
Huawei	MLA-AL10 Maimang 5
Huawei	RNE-AL00 Maimang 6
Huawei	LUA-L02 Y3 II
Huawei	RNE-L02 Nova 2i
Huawei	ATU-L21 Y6 2018
Huawei	LYO-L21 Y6 II Compact
Huawei	BLN-L21 Honor 6X
Huawei	RNE-L21 Mate 10 Lite

Huawei	RNE-L23 Mate 10 Lite
Huawei	MLA-L13 Nova Plus
Huawei	H891L Pronto LTE
Huawei	H892L Raven Che-A1
Huawei	H867G Inspira
Huawei	M921
Huawei	KII-L21 GR5
Huawei	M920 Activa 4G
Huawei	M931 Premia 4G
Huawei	201HW Stream
Huawei	S7-931w MediaPad 7Pad Lite
Huawei	U1100
Huawei	U1200
Huawei	U1250
Huawei	U1251
Huawei	U1211
Huawei	U1300
Huawei	H1711
Huawei	U2800
Huawei	U2801
Huawei	U3100
Huawei	U3200-9
Huawei	U3220
Huawei	U3300
Huawei	G3512
Huawei	G3620
Huawei	G3622
Huawei	U5130-7
Huawei	U5200
Huawei	U5700
Huawei	U6020
Huawei	G6153W
Huawei	G6600
Huawei	G6600D
Huawei	G6006
Huawei	G6603
Huawei	G6620
Huawei	G7002
Huawei	G7010
Huawei	U7200
Huawei	G7300
Huawei	T-Mobile Energy
Huawei	U7510 Blue Stone
Huawei	U7519 Tap
Huawei	U8100-9
Huawei	RBM K
Huawei	U8110
Huawei	U8110 Pulse Mini
Huawei	U8150 Comet
Huawei	U8150 IDEOS
Huawei	U8160
Huawei	U8180
Huawei	U8180 Ideos X1
Huawei	U8220
Huawei	U8230 A1

Huawei	U8230 RBM2
Huawei	T8300
Huawei	U8300 Boost Droid
Huawei	U8350 Boulder
Huawei	U8500
Huawei	U8510-1 Ideos X3
Huawei	U8600 Move
Huawei	U8650
Huawei	SCL-L01 Y6
Huawei	MYA-L11 Y6 Pro
Huawei	U8651S Summit
Huawei	U8651T Prism
Huawei	U8652 Fusion
Huawei	Ascend Y200
Huawei	STARTRAIL II by SFR
Huawei	U8655
Huawei	U8660 Maxi Pro5
Huawei	U8661
Huawei	U8665 Fusion 2
Huawei	U8667 Speed
Huawei	U8680 MyTouch
Huawei	U8681 Ascend G312
Huawei	U8686 Prism II
Huawei	U8730 My touch Q
Huawei	U8800 IDEOS X5
Huawei	U8800-51 Impulse 4G
Huawei	C8813
Huawei	C8813D
Huawei	C8812
Huawei	C8812E
Huawei	Ascend G300
Huawei	U8815
Huawei	C8816
Huawei	U8820
Huawei	C8825D
Huawei	U8825-1 Ascend G330
Huawei	C8826D
Huawei	U8850-5 Vision
Huawei	U8860
Huawei	U8950D G600
Huawei	G6-L11 Ascend G6
Huawei	G6-L22 Ascend G6
Huawei	C8000 Tactile TV
Huawei	T8808D Ascend G306T
Huawei	204HW
Huawei	U9200 Ascend P1
Huawei	U9500 Ascend D1
Huawei	U9508 Ascend Honor 2
Huawei	U9510E Ascend D1
Huawei	S-U06 Ascend P6
Huawei	X1 7.0 MediaPad X1
Huawei	H1511 Nexus 6P
Huawei	H1512 Nexus 6P
Huawei	S8-301L Mediapad M1 8.0
Huawei	M2-803L Mediapad M2 8.0

Huawei	M2-802L MediaPad M2
Huawei	T1-821L Mediapad T1 Pro 8.0
Huawei	CHE-TL00H Honor Spree 4x
Huawei	CHC-U01 G Play Mini
Huawei	CHE2-L11 Honor 4X
Huawei	H1611
Huawei	TAG-AL00 Enjoy 5S
Huawei	TIT-AL00 Y6 Pro
Huawei	TAG-CL00 Enjoy 5S
Huawei	TAG-TL00 Enjoy 5S
Huawei	DLI-L42 Honor 6A
Huawei	DLI-L22 Honor 6A
Huawei	KNT-TL10 Honor V8
Huawei	DRA-LX2 Y5 Prime 2018
Huawei	HMA-L29 Mate 20
Huawei	SNE-LX1 Mate 20 lite
Huawei	LYA-L29 Mate 20 Pro
Huawei	SLA-L22 Y6 Pro 2017
Huawei	SLA-TL10 Enjoy 7
Huawei	TRT-L21A Enjoy 7 Plus
Huawei	TRT-LX2 Y7 2017
Huawei	NCE-AL10 Enjoy 6
Huawei	CLT-L29 P20 Pro
Huawei	LDN-AL00 Enjoy 8
Huawei	BND-L21 Honor 7X
Huawei	BND-L24 Honor 7X
Huawei	POT-LX1 P Smart
Huawei	SHT-AL09 MediaPad M5 8.4
Huawei	TRT-LX3 Y7 2017
Huawei	H710VL Sensa LTE
Huawei	H715BL Sensa LTE
Hyundai	Tx30 Spirit
Hyundai	Tx60
Hyundai	Tx95
Hyundai	S1
I-Mobile	Hitz 18 TV
I-Mobile	T3_DS
I-Mobile	Hitz 20
I-Mobile	IQ 512 DTV
I-Mobile	IQX Leon
I-Mobile	IQ X PRO
I-Mobile	IQ4
I-Mobile	I-STYLE 2
I-Mobile	I-STYLE 6
INQ	INQ1 THREE
INQ	Mini 3G
INQ	T2-218U Cloud Touch
IUNI	U0001 N1
IUSACELL	M8047IU Dilo
Infinix	X403 Surf Spice
Infinix	X451 Race Bolt Q
Infinix	X454 Race Bolt 2
Infinix	X503 Surf Bravo
Infinix	X505 RACE Jet
Infinix	X508 Hot 2

Infinix	X623 Hot 6X
Infinix	X608 HOT 6 Pro
Infinix	X624B HOT7
Infinix	X627V_DS Smart 3 Plus
Infinix	X522 S2 Pro
Infinix	X559 Hot 5 Lite
Infinix	X572 Note 4
Intel	AZ210B San Diego
Intex	Intex Aqua i7
Intex	TURBO 2400_DS
Intex	Intex Aqua Amoled
Intex	Intex Aqua Core
Intex	Intex Aqua 4G Mini
Intex	Intex Cloud Y5
Intex	Aqua T4
Intex	Aqua Ring
Intex	Intex Neo V+
Intex	IP0218ND Staari 10
Intex	3000_DS Ultra
Jaga	T20 Mobile watch
Jaga	V30A
Jaga	V30B
Jaga	V30J
Jaga	V78B
Jaga	V78C
Jaga	K530i
Jugate	ZJ587
Jugate	ZJ885
Jugate	ZJ965
Jugate	ZJ983
Jugate	U1666
Jugate	Z5588
Jugate	Z5606
Jugate	Z5678
Jugate	Z8090
Jugate	Z8811
Jugate	Z8899
Jugate	Z9178
Jugate	Z9615
Jugate	Z9658
Jugate	Z9679
Jugate	Z9689
Jugate	Z9788
Jugate	Z9959
Jugate	Z9986
Just5	Blaster
KPN	Hi Messenger
K-Touch	Tou ch 2
K-Touch	ES65
K-Touch	D99
K-Touch	X90
K-Touch	A193
K-Touch	T200
K-Touch	T230
K-Touch	T260

K-Touch	T290
K-Touch	E329
K-Touch	E379
K-Touch	E500 (SMS)
K-Touch	E500
K-Touch	B618
K-Touch	T619+
K-Touch	N650
K-Touch	W656
K-Touch	I9
K-Touch	X15
K-Touch	Q1 Q21
K-Touch	Q3 Q31
K-Touch	T2
K-Touch	T3
K-Touch	T9_DS T91
K-Touch	T2S_DS T2A
K-Touch	E2
K-Touch	W68
K-Touch	W70
K-Touch	A788
K-Touch	D1100
K-Touch	A7715
Karbons	A6
Karbons	A12+
Karbons	A25
Karbons	K33
Karbons	Frames S9_DS
Karbons	S99 Titanium
Kazam	B2 Life
Kazam	Trooper 450L
Kazam	Trooper 2 4.0
Kazam	Tornado 348
Konrow	Chipo 3
Konrow	K-Flip
Konrow	Slider_SD
Konrow	Stone
Konrow	Coolsense
Konrow	Primo +
Konrow	Link 50
Kyocera	KX1
Kyocera	WX02K Sweetia
Kyocera	KX2 Koi
Kyocera	KX5 Slider
Kyocera	WX07K Honey Bee
Kyocera	KX9B Milan
Kyocera	KX9C Milan
Kyocera	KX12
Kyocera	KX13 Dorado
Kyocera	S14 Opal
Kyocera	KX16 Candid
Kyocera	KX18
Kyocera	DM015K Disney Mobile
Kyocera	S2 Android One S2
Kyocera	S4-KC Android One S4

Kyocera	KYL23 Miraie
Kyocera	602KC Digno G
Kyocera	704KC Digno J
Kyocera	KYX31 Infobar Xv
Kyocera	KYF34 Gratina 4G
Kyocera	KYV34 Urbano V02
Kyocera	KYF39 Gratina
Kyocera	KYV42(Qua phone QX)
Kyocera	K612B
Kyocera	KX21
Kyocera	KYF31 (GRATINA 4G)
Kyocera	KYF33(TORQUE X01)
Kyocera	SE44
Kyocera	SE47 Slider
Kyocera	K132
Kyocera	KX160 Xcursion
Kyocera	201K Honey Bee
Kyocera	202K Digno
Kyocera	302KC Digno T
Kyocera	K312
Kyocera	K322 K24
Kyocera	K323
Kyocera	K323 (Pioneer)
Kyocera	WX350K(HONEY BEE 4)
Kyocera	KE400
Kyocera	KX400 Ser.
Kyocera	404KC Digno C
Kyocera	KX444
Kyocera	E4210 Pro720 DuraCore
Kyocera	Pro820 DuraMax
Kyocera	E1000
Kyocera	E6830 DuraForce Pro
Kyocera	M1000 (Cricket)
Kyocera	M1000 Lingo (Pioneer)
Kyocera	M2000 G2GO
Kyocera	S2000
Kyocera	QCP 1100 Series
Kyocera	E2000 Tempo
Kyocera	E1100 Neo
Kyocera	S1300 Melo
Kyocera	S1310 Domino
Kyocera	S1350 Presto
Kyocera	M1400 Laylo
Kyocera	QCP 2000 Series
Kyocera	QCP 2100 Series
Kyocera	S2100
Kyocera	S2150 Kona
Kyocera	S2151 Kona
Kyocera	QCP 2200 Series
Kyocera	QCP 2300 Series
Kyocera	S2300 Torino
Kyocera	S2410 Tomo
Kyocera	S2720
Kyocera	QCP 3000 Series
Kyocera	S3015 Brio

Kyocera	E3100 (MetroPCS)
Kyocera	E3100 (Cricket)
Kyocera	E4610
Kyocera	E4710 Dura XE
Kyocera	S3150 Verve \ Rookie
Kyocera	QCP 3200 Series
Kyocera	S4000 Mako
Kyocera	K4130 SoHo
Kyocera	E4233 DuraPlus
Kyocera	E4277 DuraXT (Sprint)
Kyocera	E4281 DuraXTP
Kyocera	E4277 DuraXT (UScellular)
Kyocera	E4510 DuraXA
Kyocera	E4520 DuraXV
Kyocera	QCP 5100 Series
Kyocera	C5120 Milano
Kyocera	C5121 Milano
Kyocera	C5133 Event
Kyocera	C5155 Rise
Kyocera	C5170
Kyocera	C5170 Hydro
Kyocera	C5171 Hydro Plus
Kyocera	C5215 Hydro 2
Kyocera	M6000 Zio
Kyocera	C6522N Hydro Xtrm
Kyocera	E6560
Kyocera	E6560C DuraForce
Kyocera	C6530N Hydro Life
Kyocera	C6530 Hydro Life
Kyocera	E6710 Torque
Kyocera	E6810
Kyocera	E6715 Torque XT
Kyocera	C6721 Hydro XTRM
Kyocera	C6725 Vibe
Kyocera	C6730 Hydro Icon
Kyocera	C6740
Kyocera	C6740N Hydro Wave
Kyocera	C6742A Hydro View
Kyocera	C6743 Hydro Reach
Kyocera	E6762 DuraForce
Kyocera	E6790 DuraForce XD
Kyocera	C6745 Hydro Air
Kyocera	E6782 Brigadier
Kyocera	C6750 Hydro Elite
Kyocera	E6820
Kyocera	E6820TM
Kyocera	WX06K Honey Bee
Kyocera	M9300 Echo
Kyocera	TORQUE SKT01
Kyocera	WX04K(DIGNO DUAL)
Kyocera	WX10K Digno Dual 2
Kyocera	KYL22 Digno M
Kyocera	KYV31 Urbano V01
Kyocera	KYV32 (BASIO)
Kyocera	KYY24 Torque

Kyocera	KYV37 Qua Phone AU
LEXAND	S4A2 IRIDA
LEXAND	S4A1 Vega
LYF	LS-4503 Flame 1
LYF	LS-4508_DS C451
LYF	LS-5010 Wind 1
LYF	LS-5015
LYF	LS-5016_DS Wind 7
LYF	LS-5020_DS Water 10
LYF	LS-5201 Water F1S
LYF	LS-5501 Earth 1
LYF	LS-5504 Water 7
LYF	LS-5505 Water F1_DS
LYF	LYF LS-5507 Water 7S
LYF	LS-5005 Water 4
LYF	LS-5018 Wind 4S
LYF	LS-5021 Earth 2
Lanix	LX6
Lanix	LX11
Lanix	LX14
Lanix	W30
Lanix	T60
Lanix	T99
Lanix	S106
Lanix	X110
Lanix	X200
Lava	A1
Lava	ARC One Plus
Lava	ARC12
Lava	A48
Lava	A44_DS
Lava	Spark 250
Lava	Lava Iris 349s
Lava	Iris 360
Lava	Iris 510
LeTV	X600 One
LeTV	X900 Le Max
LeTV	LEX727 Le Pro3
LeTV	LEX622 Le S3
Leagoo	Power 2 Pro
Leagoo	Elite 4
Leagoo	M9
Leagoo	M11
Leagoo	Lead 6
Leagoo	T5
Leagoo	M9 PRO
Leagoo	M8
Leagoo	Z5C
Leagoo	Z6
Leagoo	S8 PRO
Lenovo	O1
Lenovo	S5
Lenovo	S7
Lenovo	Smart Tab II 10
Lenovo	TD30t

Lenovo	TD80T Miro
Lenovo	K10a40 C2
Lenovo	K10e70
Lenovo	L78011 Z5
Lenovo	L78031 Z5 Pro
Lenovo	L38011 K5 Play
Lenovo	L38012 K5 Note
Lenovo	L18011 A5
Lenovo	P2a42 P2
Lenovo	XT1902-3 K8 Note
Lenovo	K80M
Lenovo	XT1902-2 K8 Plus
Lenovo	PB2-650M
Lenovo	K33B36 Vibe K6
Lenovo	K33a48 K6
Lenovo	A60
Lenovo	P60
Lenovo	A66
Lenovo	P70
Lenovo	Z90-7 Vibe Shot
Lenovo	101
Lenovo	TB-X103F Tab 10
Lenovo	S200
Lenovo	A201s
Lenovo	E210
Lenovo	A269
Lenovo	A319
Lenovo	i328TD
Lenovo	A308T
Lenovo	A328
Lenovo	K350t K5
Lenovo	i350
Lenovo	A369
Lenovo	A376
Lenovo	A388t
Lenovo	A390
Lenovo	E520
Lenovo	A520
Lenovo	S533
Lenovo	A536
Lenovo	A550
Lenovo	A560
Lenovo	A610
Lenovo	P612
Lenovo	A628t
Lenovo	A630
Lenovo	A630t
Lenovo	P650WG
Lenovo	S660_DS
Lenovo	A680
Lenovo	A690
Lenovo	S700
Lenovo	TB-X304L Tablet 4 10
Lenovo	PB1-770P PHAB Plus
Lenovo	L38111_DS Z6 Youth

Lenovo	P1a42 Vibe P1
Lenovo	L78071 Z5s
Lenovo	TB-8704F Tab 4 Plus
Lenovo	L58091 S5 Pro GT
Lenovo	TB3-850F Tab3 8
Lenovo	PB2-670M Phab 2 Plus
Lenovo	L78032 Z5 Pro GT
Lenovo	TB-7304X TAB 7 Essential
Lenovo	TB-8504F Tab 4
Lenovo	L58041 S5 Pro
Lenovo	TB-X704A Tab 4
Lenovo	TB-X704F Tab 4 10 Plus
Lenovo	TB-7504X Tab 7
Lenovo	YT-X703F YOGA Tab 3 Plus
Lenovo	TB-X704V Tab 4 10 Plus
Lenovo	S720
Lenovo	A760
Lenovo	P770
Lenovo	A766
Lenovo	A780
Lenovo	P780
Lenovo	A788t
Lenovo	TD800 Dragon
Lenovo	A808t Golden Warrior A8
Lenovo	i817
Lenovo	A820
Lenovo	A820T
Lenovo	S820
Lenovo	A850
Lenovo	YT3-X50L Yoga Tab 3
Lenovo	TB3-X70L Tab 3
Lenovo	YT3-850F Yoga Tab 3 8
Lenovo	K860
Lenovo	A880
Lenovo	S890
Lenovo	S960 Vibe X
Lenovo	K900
Lenovo	K910 Vibe Z
Lenovo	i909
Lenovo	S90-t Sisley
Lenovo	S920
Lenovo	A936 Note 8
Lenovo	A1010a20 A Plus
Lenovo	A2016a40 Vibe B
Lenovo	S5000-F
Lenovo	A6000 Plus Dual
Lenovo	B6000-F Yoga 8
Lenovo	S6000L-F
Lenovo	X2-EU Vibe
Lenovo	X3c50 Vibe X3
Lenovo	P1c72 Vibe P1
Lenovo	K50-t5 K3 Note
Lenovo	ZUK Z1
Lenovo	A1000
Lenovo	A2010-I A2010

Lenovo	Z2131 ZUK Z2 Plus
Lenovo	A1000L-F IdeaTab
Lenovo	A3000 IdeaPad
Lenovo	A3500-FL
Lenovo	A6020I36 Vibe K5
Lenovo	A6020a40 Vibe K5
Lenovo	A6020a46 Vibe K5 Plus
Lenovo	A6800
Lenovo	A7000-a
Lenovo	A7010a48 K4 Note
Lenovo	A7600-m S8
Lenovo	TB2-X30F Tab 2 A10-30
Lenovo	A10-70 A7600-H
LG CDMA	Generic Android
LG CDMA	VX-1
LG CDMA	4NE1
LG CDMA	VX-10
LG CDMA	L16C Lucky
LG CDMA	LGL18VC Classic
LG CDMA	LGL22C Power
LG CDMA	L34C Optimus Fuel
LG CDMA	L38C Optimus Dynamic
LG CDMA	L45C Optimus Net
LG CDMA	L52VL Treasure
LG CDMA	L55C Optimus Q
LG CDMA	LGUK410 G Pad 7.0 E7
LG CDMA	LK430 G Pad F 7.0
LG CDMA	UK495 G Pad F 8.0
LG CDMA	AS876 F90
LG CDMA	AS985 G3
LG CDMA	AS990 G3
LG CDMA	LGL41C Ultimate 2
LG CDMA	LGL75C Optimus Slider
LG CDMA	L85C Optimus Black
LG CDMA	L86C Optimus Showtime
LG CDMA	LG-100
LG CDMA	VW820 (USB)
LG CDMA	VW820 (BT)
LG CDMA	DM-110
LG CDMA	LG-125 (Telus)
LG CDMA	VI-125 (Sprint)
LG CDMA	TM-125
LG CDMA	AX-145
LG CDMA	UX-145
LG CDMA	LG-150 (Bell)
LG CDMA	LX-150 (Sprint)
LG CDMA	UN-150
LG CDMA	VN-150 Revere
LG CDMA	AX-155
LG CDMA	LG-160
LG CDMA	AN-160
LG CDMA	AN-170
LG CDMA	LX-160
LG CDMA	UN160 ENVOY2
LG CDMA	UN-161

LG CDMA	VN170 Revere 3
LG CDMA	MD-180
LG CDMA	MN-180 Select
LG CDMA	AN-200
LG CDMA	LM-X210ULM K8+
LG CDMA	LM-X210VPP
LG CDMA	VN210 Terra
LG CDMA	LHD-200
LG CDMA	MX-200
LG CDMA	UN-200 Saber
LG CDMA	LG-210
LG CDMA	MX-210
LG CDMA	UX-210
LG CDMA	UN220 Wine LTE
LG CDMA	PM-225
LG CDMA	LG-231
LG CDMA	LG-231C
LG CDMA	236C
LG CDMA	237C
LG CDMA	238C
LG CDMA	LN-240 Remarq
LG CDMA	MX-240 (iUSAcell)
LG CDMA	LG-240 (IL)
LG CDMA	CX-245 (Telus)
LG CDMA	AX-245
LG CDMA	LG-245
LG CDMA	UX-245
LG CDMA	LG-245 (Mid.Wireless)
LG CDMA	TM-250 (Bell)
LG CDMA	VN-250 Cosmos
LG CDMA	VN-251 Cosmos 2
LG CDMA	VN251S Cosmos 3
LG CDMA	LX-260 Rumor
LG CDMA	UX-260
LG CDMA	AX260BL Scoop
LG CDMA	LG-260
LG CDMA	LG-260 (Bell)
LG CDMA	LG-260 (Virgin Mobile)
LG CDMA	AX-265
LG CDMA	LG-265 Banter
LG CDMA	LG-265t Banter
LG CDMA	LG-265X Banter (Koodo)
LG CDMA	LG-265 Rumor II
LG CDMA	LG-265 (Bell)
LG CDMA	LX-265 Rumor II
LG CDMA	UX-265
LG CDMA	UX-220
LG CDMA	LG-230
LG CDMA	LG-230 (Bell)
LG CDMA	MN-240
LG CDMA	AN-270
LG CDMA	MN-270 Beacon
LG CDMA	UN-270
LG CDMA	UN280 Freedom II
LG CDMA	UN280PP Freedom II

LG CDMA	VN-270 Cosmos Touch
LG CDMA	VN-271 Extravert
LG CDMA	AN-272
LG CDMA	LN-272 Rumor Reflex
LG CDMA	UN-272
LG CDMA	AX-275PK(Alltel)
LG CDMA	AX-275SV
LG CDMA	MX-275 (iUSAcCell)
LG CDMA	LG-280 Wine (Bell)
LG CDMA	LN280 Aspire
LG CDMA	VN280 Extravert 2
LG CDMA	UX-280 Wine
LG CDMA	LG-285
LG CDMA	LX-290
LG CDMA	LG-300
LG CDMA	AX-300
LG CDMA	UX-300
LG CDMA	305C (USB)
LG CDMA	305C (BT)
LG CDMA	AX-310
LG CDMA	LW-310
LG CDMA	MT-310
LG CDMA	UX-310 US Cellular
LG CDMA	MS323 Optimus L70
LG CDMA	PM-325
LG CDMA	LX-350
LG CDMA	AX-355
LG CDMA	UX-355
LG CDMA	LG-370
LG CDMA	LX-370
LG CDMA	VN370
LG CDMA	AS375
LG CDMA	MT-375
LG CDMA	LG-380
LG CDMA	LG-380 (Telus)
LG CDMA	AX-380 Wave
LG CDMA	US110 K3 2017
LG CDMA	US215 K8 2017
LG CDMA	US375 K8
LG CDMA	MX-380
LG CDMA	UX-380 Wave
LG CDMA	LG-385
LG CDMA	AX-390
LG CDMA	UX-390
LG CDMA	LX-400
LG CDMA	VS415PP Optimus Zone 2
LG CDMA	VS410PP Optimus Zone
LG CDMA	VS425PP Optimus Zone 3
LG CDMA	AN-430
LG CDMA	UN-430 Wine2
LG CDMA	442BG
LG CDMA	VS450PP Optimus Exceed 2
LG CDMA	LG-470 (IL)
LG CDMA	AX-490
LG CDMA	CX-490 (Telus)

LG CDMA	AX-500 Swift
LG CDMA	VS500 K8 V
LG CDMA	US550
LG CDMA	VS500PP K8 V
LG CDMA	LGMS500 Optimus F6
LG CDMA	VS501
LG CDMA	630 (AD-6335)
LG CDMA	AN-510
LG CDMA	DM-510
LG CDMA	MN-510 Banter Touch
LG CDMA	MX-500
LG CDMA	MX-510
LG CDMA	TM-510
LG CDMA	UN-510 Banter Touch
LG CDMA	LN-510 Rumor Touch
LG CDMA	UN530 Wine 3
LG CDMA	VN-530 Octane
LG CDMA	LG-535 (Telus)
LG CDMA	LX-535
LG CDMA	UN540 Wine 4
LG CDMA	LX-550 Fusic
LG CDMA	LG-560 (IL)
LG CDMA	AX-565
LG CDMA	UX-565
LG CDMA	LX-570 Muziq
LG CDMA	AX-585 Rhythm
LG CDMA	UX-585
LG CDMA	LG-600 (Bell)
LG CDMA	LX-600 Lotus
LG CDMA	US610 X Power
LG CDMA	K212 X Power
LG CDMA	US701 X Venture
LG CDMA	LX-610 Lotus Elite
LG CDMA	UN-610 Lotus 2
LG CDMA	LS620 Volt
LG CDMA	LG LS660 Tribute 4G
LG CDMA	LS675 Tribute 5
LG CDMA	LS676 Tribute HD
LG CDMA	LS665
LG CDMA	LS740 Volt
LG CDMA	LS751 Volt 2
LG CDMA	LS755 X Power
LG CDMA	LGM322 X Charge Xfinity
LG CDMA	X Power 2
LG CDMA	MS659 Optimus F3
LG CDMA	LS-670 Optimus S
LG CDMA	US-670 Optimus U
LG CDMA	VM-670 Optimus V
LG CDMA	AS680 Optimus 2
LG CDMA	MS690 Optimus M
LG CDMA	UK750 G Pad X II 10.1
LG CDMA	MS770 Motion
LG CDMA	VS660 Vortex
LG CDMA	LW-690 Optimus C
LG CDMA	AS695 Optimus Plus

LG CDMA	MS695 Optimus M+
LG CDMA	LS-696 Optimus Elite
LG CDMA	VM-696 Optimus Elite
LG CDMA	LG-700
LG CDMA	LG-700 Bliss
LG CDMA	LS-700
LG CDMA	UX-700 Bliss
LG CDMA	VS700 Enlighten
LG CDMA	VM-701 Optimus Slider
LG CDMA	LS720 Optimus F3
LG CDMA	AS730 Optimus Select
LG CDMA	US-730 Splendor
LG CDMA	LG-730 Venice
LG CDMA	AS740 Axis
LG CDMA	US-740 Apex
LG CDMA	VS740 Ally
LG CDMA	VS995 V20
LG CDMA	VS750 Fathom
LG CDMA	US-760
LG CDMA	LS770
LG CDMA	LS775 Stylo 2
LG CDMA	LW-770 Regard
LG CDMA	US-780 Optimus F7
LG CDMA	LG-800 (Bell)
LG CDMA	MX-800 (Vivo)
LG CDMA	PX800 Chocolate(IL)
LG CDMA	D803 G2
LG CDMA	VK410 G Pad 7.0
LG CDMA	VS810PP
LG CDMA	VK810 G Pad 8.3
LG CDMA	VK815 G Pad X
LG CDMA	LG-820 (IL)
LG CDMA	H790
LG CDMA	bullhead Nexus 5x
LG CDMA	VS820 Lancet
LG CDMA	AX-830
LG CDMA	UX-830 Glimmer
LG CDMA	LG-830
LG CDMA	LG-830 Vantage (Bell)
LG CDMA	VS835 Stylo 2
LG CDMA	AS840
LG CDMA	AX-840 Tritan
LG CDMA	LG-840
LG CDMA	MS840
LG CDMA	LS-840 Viper
LG CDMA	MS840 Connect 4G
LG CDMA	MS840V Connect 4G (VoLTE)
LG CDMA	VS840 Lucid 4G
LG CDMA	UX-840 Tritan
LG CDMA	AS855 Ignite
LG CDMA	LG855 Marquee
LG CDMA	LS-855 Marquee
LG CDMA	LS-860 Mach
LG CDMA	LG870 Optimus 7
LG CDMA	MS870

LG CDMA	VS870 Lucid II
LG CDMA	VS876 Lucid 3
LG CDMA	VS880 G Vista
LG CDMA	VS880PP G Vista
LG CDMA	LS885 G2 Mini
LG CDMA	VS890 Enact
LG CDMA	MS910 Esteem
LG CDMA	VS910 Revolution
LG CDMA	VS920 Spectrum
LG CDMA	VS930 Spectrum 2
LG CDMA	VS950 Intuition
LG CDMA	LS-970 Optimus G
LG CDMA	LS-980 G2
LG CDMA	VS980 G2
LG CDMA	VS985 G3
LG CDMA	VS985W G3
LG CDMA	AS991 G4
LG CDMA	AS992 G5
LG CDMA	VS986 G4
LG CDMA	VS987 G5
LG CDMA	LS990 G3
LG CDMA	VS990
LG CDMA	US990 G3
LG CDMA	US991 G4
LG CDMA	RS988 G5
LG CDMA	US992 G5
LG CDMA	US996 V20
LG CDMA	US997 G6
LG CDMA	US998 V30
LG CDMA	VS996
LG CDMA	LS991 G4
LG CDMA	LS992 G5
LG CDMA	LS995 G Flex
LG CDMA	AS995 G Flex 2
LG CDMA	US995 G Flex 2
LG CDMA	LS996 G Flex 2
LG CDMA	VS988 G6
LG CDMA	LM-G710ULM G7 ThinQ
LG CDMA	LM-G710VM G7 ThinQ
LG CDMA	LM-Q710US QStylus
LG CDMA	LG-1010
LG CDMA	LG-1100
LG CDMA	LX-1200
LG CDMA	VX-2000
LG CDMA	MD-3000
LG CDMA	VX-3100
LG CDMA	LG-3200 (Telus)
LG CDMA	VX-3200
LG CDMA	LG-3280
LG CDMA	UX-3300
LG CDMA	VX-3300
LG CDMA	VX-3400
LG CDMA	VX-3450
LG CDMA	LSP-3510
LG CDMA	HD-4000 (Telstra)

LG CDMA	AX-4270
LG CDMA	BP-4270
LG CDMA	VX-4270
LG CDMA	VX-4400
LG CDMA	VX-4500
LG CDMA	VX-4600
LG CDMA	VX-4650
LG CDMA	VX-4700
LG CDMA	LG-4750 (Telus)
LG CDMA	AX-4750
LG CDMA	UX-4750
LG CDMA	AX-5000
LG CDMA	UX-5000
LG CDMA	KE500
LG CDMA	TD-5130 (Telstra)
LG CDMA	TP-5200
LG CDMA	VX-5200
LG CDMA	VI-5225 (Sprint)
LG CDMA	VI-5225G
LG CDMA	TP-5250
LG CDMA	VX-5300
LG CDMA	LX-5350
LG CDMA	LG-5400 (Bell)
LG CDMA	LX-5400
LG CDMA	VX-5400
LG CDMA	LG-5450 (Telus)
LG CDMA	LX-5450
LG CDMA	VX-5500
LG CDMA	LG-5500
LG CDMA	LG-5550
LG CDMA	LX-5550
LG CDMA	VX-5600 Accolade
LG CDMA	VX-6000
LG CDMA	LG-6070
LG CDMA	VX-6100
LG CDMA	LG-6190
LG CDMA	LG-6200 (Bell)
LG CDMA	VX-7000
LG CDMA	VX-7100 Glance
LG CDMA	LG-7100 Glance (Telus)
LG CDMA	LG-7100X
LG CDMA	TD-7130 (Telstra)
LG CDMA	VX-8000
LG CDMA	VX-8100
LG CDMA	LG-8300 (IL)
LG CDMA	VX-8300
LG CDMA	LG-8350 (IL)
LG CDMA	VX-8350
LG CDMA	VX-8360
LG CDMA	AX-8370
LG CDMA	VX-8370 Clout
LG CDMA	8380
LG CDMA	VX8500 Chocolate Old
LG CDMA	LG-8500 (iUSAcell)
LG CDMA	LG-8500 (Telus)

LG CDMA	LG-8550 (Telus)
LG CDMA	VX8550 Chocolate New
LG CDMA	8560
LG CDMA	VX-8560 Chocolate 3
LG CDMA	LG-8575
LG CDMA	VX-8575 Chocolate Touch
LG CDMA	AX-8575 Touch
LG CDMA	8600 Chocolate Flip
LG CDMA	AX-8600
LG CDMA	VX-8600 (IL)
LG CDMA	VX-8600
LG CDMA	UX-8600
LG CDMA	VX-8610 Decoy
LG CDMA	LG-8700 (Koodo)
LG CDMA	LG-8700 (Telus)
LG CDMA	VX-8700
LG CDMA	MX-8700 (iUSAccl)
LG CDMA	VX-8800 Venus
LG CDMA	LG-8800
LG CDMA	VX9100 enV2
LG CDMA	VX9100M
LG CDMA	LG-9100 Keybo
LG CDMA	LG-9100T (Telus)
LG CDMA	CX-9200 (Telus)
LG CDMA	VX-9200 enV3
LG CDMA	LG-9250
LG CDMA	VX-9400
LG CDMA	CX-9600 Versa (Telus)
LG CDMA	LG-9600
LG CDMA	VX-9600M Versa
LG CDMA	VX-9700 Dare (Verizon)
LG CDMA	LG-9700 (Telus)
LG CDMA	VX-9800 V
LG CDMA	VX-9900 enV
LG CDMA	LG-10000 (Bell, Telus)
LG CDMA	VX-10000 Voyager
LG CDMA	VX-11000 enV Touch
LG CDMA	VN-360
LG GSM	Generic Android
LG GSM	L15G Sunrise
LG GSM	L16C Lucky
LG GSM	L21G Destiny HSPA
LG GSM	L62VL Premier
LG GSM	CD02 Dior
LG GSM	G2 Plum
LG GSM	V7
LG GSM	M700Y Q6
LG GSM	M700A_DS Q6
LG GSM	LM-X410PM K30 Sprint
LG GSM	LG-Q710AL Stylo 4 Boost
LG GSM	LM-Q720PS Stylo 5
LG GSM	LM-G910EMW VELVET
LG GSM	LM-Q720QM Stylo 5
LG GSM	M700Y Q6 Plus
LG GSM	LGL23G Flex

LG GSM	LGL24 au isai
LG GSM	LGV31 isai
LG GSM	LGV32 Isai
LG GSM	BL20 New Chocolate
LG GSM	KS20
LG GSM	L31L Access
LG GSM	L33L Sunset
LG GSM	LM-X210EM K9
LG GSM	LGV34 Isai Beat
LG GSM	L35G
LG GSM	BL40g New Chocolate (Telus)
LG GSM	BL40 New Chocolate
LG GSM	H735L G4 Beat
LG GSM	L40G Optimus Extreme
LG GSM	L43AL Rebel
LG GSM	L44VL Rebel
LG GSM	L59BL Grace
LG GSM	L63BL Fiesta LTE
LG GSM	L163BL Fiesta 2
LG GSM	L64VL Fiesta LTE
LG GSM	L164VL Fiesta 2
LG GSM	KG77
LG GSM	LGL82VL Stylo 2
LG GSM	LGL53BL X Style
LG GSM	LGL84VL Stylo 3
LG GSM	LGL83BL Stylo 3
LG GSM	LG LGL57BL Rebel 2
LG GSM	LGL58VL Rebel 2
LG GSM	LGL158VL Rebel 3
LG GSM	M327 X
LG GSM	LML413DL Premier Pro
LG GSM	LS777 Stylus 3
LG GSM	M400F Stylus 3
LG GSM	LM-X410TK K30
LG GSM	LM-X510WM X Power 3
LG GSM	M430 Stylo 3
LG GSM	KP100
LG GSM	K520 Stylus 2
LG GSM	K520DY Stylus 2
LG GSM	V521 G Pad X 8.0
LG GSM	K530F Stylus 2 Plus
LG GSM	K580 X Cam
LG GSM	F100S Optimus Vu
LG GSM	F720L Stylus 2
LG GSM	LG-H635C G4 Stylus
LG GSM	VK700 G Pad 10.1
LG GSM	D100 L20
LG GSM	D100g L20
LG GSM	GB102
LG GSM	C105 Buzz
LG GSM	D105 L20 Dual
LG GSM	KP105
LG GSM	KP105a
LG GSM	KP106
LG GSM	KP106b

LG GSM	KP107a
LG GSM	KP108
LG GSM	KP109a
LG GSM	CE110
LG GSM	K120 K4
LG GSM	K120E K4
LG GSM	K121 K4
LG GSM	X220 K5
LG GSM	X230DS K4 Novo 2017
LG GSM	KG129
LG GSM	KG130
LG GSM	A133
LG GSM	A133R ALICIA
LG GSM	CP150
LG GSM	X150 L Bello II
LG GSM	GS155
LG GSM	F160S Optimus LTE II
LG GSM	A165
LG GSM	GS170 (USB)
LG GSM	GS170 (BT)
LG GSM	KP170
LG GSM	F180S Optimus G
LG GSM	GB190A
LG GSM	GB190B
LG GSM	C195
LG GSM	C195N
LG GSM	A200
LG GSM	MG200
LG GSM	B200E
LG GSM	TB200
LG GSM	GU200
LG GSM	F200S Optimus Vu II
LG GSM	GX200
LG GSM	KP202
LG GSM	KP202 i-mode
LG GSM	C205
LG GSM	GM205
LG GSM	X180G Zone
LG GSM	X210 K7
LG GSM	KP215a
LG GSM	B220
LG GSM	GB220
LG GSM	L-03K Style
LG GSM	LML211BL Rebel 4 5.0
LG GSM	L-04E Optimus G Pro
LG GSM	F240S Optimus G Pro
LG GSM	F240S Optimus VU
LG GSM	KG220
LG GSM	KG240
LG GSM	MG220
LG GSM	CG225
LG GSM	KG225
LG GSM	GB230 Julia
LG GSM	GU230 Dimsun
LG GSM	KP230

LG GSM	MG230
LG GSM	KP235
LG GSM	A250
LG GSM	GB250
LG GSM	GB250g
LG GSM	GB255G Madison
LG GSM	F260S Optimus LTE III
LG GSM	KP260
LG GSM	KP265d
LG GSM	KP270
LG GSM	GU280
LG GSM	GU282
LG GSM	GU285
LG GSM	A290
LG GSM	GS290 Cookie Fresh
LG GSM	GU290F Blue
LG GSM	KG290
LG GSM	GU290V Koodo
LG GSM	GU292
LG GSM	GU295 Popcorn
LG GSM	MG295
LG GSM	GU297 Wink
LG GSM	CG300
LG GSM	F120L Optimus LTE Tag
LG GSM	F120K Optimus LTE Tag
LG GSM	F120S Optimus LTE Tag
LG GSM	D213c L50
LG GSM	D213N L50
LG GSM	L51AL Treasure
LG GSM	L56VL X Style
LG GSM	L61AL Premier LTE
LG GSM	X145 L60 Dual
LG GSM	X147 L60 Dual
LG GSM	M160 K4 2017
LG GSM	M160E K4 2017
LG GSM	M200n K8
LG GSM	LG-SP200 Tribute Dynasty
LG GSM	LML212VL Rebel 4 PREPAID
LG GSM	LG-SP320 X Charge
LG GSM	D280n L65
LG GSM	D285 L65
LG GSM	D290n L Fino
LG GSM	D290g L70+ L Fino
LG GSM	D295 L Fino
LG GSM	F300K Optimus Vu III
LG GSM	GD300s
LG GSM	GW300 Etna 2
LG GSM	GW300 Sm@rt
LG GSM	GW300FD
LG GSM	KF300e
LG GSM	KF300
LG GSM	T300 Cookie Lite
LG GSM	T320
LG GSM	T320G Flick
LG GSM	TM300

LG GSM	C300
LG GSM	U300
LG GSM	LG KF301
LG GSM	C305
LG GSM	A310F
LG GSM	C310 Cookie Duet
LG GSM	LG-306G (USB)
LG GSM	LG-306G (BT)
LG GSM	F310L GX
LG GSM	T310i Cookie Emmetro
LG GSM	KF310
LG GSM	C320 Vertslider
LG GSM	CU320
LG GSM	M320G X Power 2
LG GSM	F320L G2
LG GSM	F320S G2
LG GSM	KG320
LG GSM	H345
LG GSM	H440
LG GSM	H440F Spirit
LG GSM	H440N
LG GSM	D120 L30 Sporty
LG GSM	D125g L30 Sporty
LG GSM	D150 L35
LG GSM	D160 L40
LG GSM	H221g Joy
LG GSM	H222g Joy
LG GSM	K240F X Max
LG GSM	M250N K10 2017
LG GSM	M250Y K10 2017
LG GSM	M250E K10 2017
LG GSM	M250ds K10 Novo 2017
LG GSM	M255 K20
LG GSM	MP260 K20 Plus
LG GSM	TP260 K20 Plus
LG GSM	D170 L40
LG GSM	D320 L70
LG GSM	D320N L70
LG GSM	H320 Leon
LG GSM	H320mb Leon
LG GSM	D321 Optimus L70
LG GSM	MS330
LG GSM	D331 L Bello
LG GSM	D335 L Bello Dual
LG GSM	AS330 K7
LG GSM	K330 K7
LG GSM	K371 Phoenix 2
LG GSM	K373 Escape 3
LG GSM	GD330
LG GSM	TU330
LG GSM	A340 F4
LG GSM	H343 Risio
LG GSM	F350K G Pro 2
LG GSM	D838 G Pro 2
LG GSM	K210 X Power

LG GSM	K220Z X Power
LG GSM	F350S G Pro 2
LG GSM	A380 F5
LG GSM	F340K G Flex
LG GSM	F340L G Flex
LG GSM	F340S G Flex
LG GSM	H340n Leon
LG GSM	A341
LG GSM	L341i
LG GSM	L342i
LG GSM	L343i
LG GSM	MS345 Leon LTE
LG GSM	GT350 Town
LG GSM	GT350F
LG GSM	K350ds K8 Dual
LG GSM	K350n K8
LG GSM	P350 Optimus Me
LG GSM	P350 Pecan
LG GSM	C360
LG GSM	CF360
LG GSM	GM360 Viewty Snap
LG GSM	GT360
LG GSM	KS360
LG GSM	G350
LG GSM	G360
LG GSM	C365
LG GSM	GT365 Neon
LG GSM	KS365
LG GSM	TE365
LG GSM	TE365F
LG GSM	S367
LG GSM	T370 Cookie Smart
LG GSM	GW370 Neon II
LG GSM	GW370B
LG GSM	GW382F
LG GSM	D373 L80
LG GSM	T375
LG GSM	KM380
LG GSM	KU380
LG GSM	T385
LG GSM	GS390 Prime (USB cable (100))
LG GSM	KF390
LG GSM	D390 F60
LG GSM	D390n F60
LG GSM	M210 Aristo
LG GSM	LM-X210APM
LG GSM	LM-X210MA (Aristo 2)
LG GSM	LM-X212TA Aristo 2 Plus
LG GSM	LM-X410AS Phoenix Plus
LG GSM	LM-X210CMR Risio 3
LG GSM	LM-X210CM Fortune 2
LG GSM	LM-Q610ZA Q7 Plus
LG GSM	LM-Q610MA Q7 Plus
LG GSM	LM-Q630EAW_DS K61
LG GSM	LM-K410ZMW_DS K41

LG GSM	LM-K510ZMW_DS K51S
LG GSM	LM-X420AS K40
LG GSM	LM-V600TM V60 ThinQ 5G
LG GSM	LM-X420MM K40
LG GSM	LM-Q910UM G7 One
LG GSM	LM-X525ZAW Q60
LG GSM	LM-X525ZA Q60
LG GSM	LM-X440IM W30
LG GSM	LM-X210WM K9
LG GSM	LM-G810EA G8S ThinQ
LG GSM	LM-G820UM G8 ThinkQ
LG GSM	LM-G850EMW G8X ThinkQ
LG GSM	L322DL Journey Lte
LG GSM	L423DL Solo
LG GSM	LMX130IM_DS W10
LG GSM	LM-X440ZMW_DS W30
LG GSM	LM-G900N VELVET
LG GSM	LM-G710TM G7 ThinQ
LG GSM	LM-G710EM G7 ThinQ
LG GSM	G710EMW G7 ThinQ
LG GSM	LM-Q710 (FGN) Stylo 4
LG GSM	LM-Q710MS_DS Stylo 4
LG GSM	LM-Q710US Stylo 4
LG GSM	LM-Q710.FG Stylo 4
LG GSM	LM-Q710ULM Stylo 4
LG GSM	LM-V350AWM
LG GSM	MS210 Aristo
LG GSM	MS395 Optimus F60
LG GSM	C395 Xpression
LG GSM	CU400
LG GSM	E400 Optimus L3
LG GSM	E400F Optimus L3
LG GSM	V400 G Tablet 7.0
LG GSM	E400b Optimus L3
LG GSM	E400R Optimus L3
LG GSM	GT400 Viewty Smile
LG GSM	U400
LG GSM	E405 Optimus L3
LG GSM	D405n L90
LG GSM	LM-V409N V40 ThinQ
LG GSM	LM-V405UA_DS V40 ThinQ
LG GSM	C410 Xpression 2
LG GSM	D410 L90
LG GSM	D410h L90
LG GSM	E410f Optimus L1 II
LG GSM	E420 Optimus L1
LG GSM	H422 Spirit
LG GSM	V410 G Pad 7.0 LTE
LG GSM	K410f K10
LG GSM	K410g Q10
LG GSM	MS428 K10
LG GSM	402LG F60S
LG GSM	440G
LG GSM	C441
LG GSM	B460 True

LG GSM	MS450
LG GSM	MS550 Stylo 2 Plus
LG GSM	K550 Stylo 2 Plus
LG GSM	L81AL Stylo 2
LG GSM	V480 G Tablet 8.0
LG GSM	V490 G Tablet 8.0 4G
LG GSM	E431g Optimus L3
LG GSM	E465g Optimus L4 II
LG GSM	E425f Optimus L3 II
LG GSM	E430 Optimus L3 2
LG GSM	D400hn L90
LG GSM	F400S G3
LG GSM	F460L G3 Cat.6
LG GSM	F460K G3
LG GSM	D415 Optimus L90
LG GSM	D315 F70
LG GSM	D320g8 L70
LG GSM	D325 L70 Dual
LG GSM	F370L F70
LG GSM	F370K F70
LG GSM	F370S F70
LG GSM	H410 Wine Smart
LG GSM	H420 Spirit
LG GSM	H420F Spirit
LG GSM	K420n K10
LG GSM	K425
LG GSM	K428
LG GSM	K430H K10
LG GSM	K430Y K10
LG GSM	K430T K10
LG GSM	K430TV K10 TV
LG GSM	K450 X Power
LG GSM	TFLG420GB
LG GSM	E435 L3 Dual II
LG GSM	F440L Ice Cream Smart
LG GSM	F480K Wine Smart
LG GSM	D486 Wine Smart
LG GSM	E440 Optimus L4 II
LG GSM	H443 Escape 2
LG GSM	E450 L5 II
LG GSM	E450g L5 II
LG GSM	E445 Optimus L4 II Dual
LG GSM	KU450
LG GSM	E460 L5 II
LG GSM	E460 Optimus V5
LG GSM	LG-B470
LG GSM	B471
LG GSM	V496 G Pad F 8.0
LG GSM	CU500
LG GSM	GS500 Cookie Plus
LG GSM	GS500g
LG GSM	GT500 Puccini
LG GSM	GR500 (USB)
LG GSM	GR500FD Xenon
LG GSM	GR500R Xenon

LG GSM	GX500
LG GSM	KS500
LG GSM	H500f Magna
LG GSM	H812 G4
LG GSM	H502f Magna
LG GSM	P500 Optimus One
LG GSM	GR501 Xenon
LG GSM	LG500
LG GSM	KM500
LG GSM	KP500
LG GSM	KP501
LG GSM	V495 G Pad F 8.0
LG GSM	V500 G Pad 8.3
LG GSM	E510 Univa
LG GSM	T500 Dakota
LG GSM	D500 Optimus F6
LG GSM	TU500
LG GSM	TU500S
LG GSM	KP502 Cookie
LG GSM	P504
LG GSM	GS505 Sentio
LG GSM	GT505 Pathfinder
LG GSM	P505 Phoenix
LG GSM	P505CH
LG GSM	P505R
LG GSM	P506 Thrive
LG GSM	P509 Optimus T
LG GSM	P509RD Optimus T
LG GSM	LG509TN
LG GSM	F510K Flex 2
LG GSM	GD510 Pop
LG GSM	KF510
LG GSM	CU515
LG GSM	TU515
LG GSM	GW520
LG GSM	V520 G Pad X 8.0
LG GSM	D520 Optimus F3Q
LG GSM	H520g Magna
LG GSM	K520K Stylus 2
LG GSM	KT520
LG GSM	F500K G4
LG GSM	H522Y G4c
LG GSM	GW525
LG GSM	GW525g
LG GSM	H525n G4c
LG GSM	K500N X screen
LG GSM	B525
LG GSM	H540 G4 Stylus
LG GSM	GT540 Optimus
LG GSM	SU540 Prada
LG GSM	GT540R (Rogers)
LG GSM	GD550 Pure
LG GSM	GT550 Encore (USB)
LG GSM	US550 Logos
LG GSM	KC550

LG GSM	KM555R
LG GSM	TU550
LG GSM	C555 Optimus Chat
LG GSM	GD570 DLite
LG GSM	KM570 Cookie Gig
LG GSM	F570S Band Play
LG GSM	KP570Q
LG GSM	CU575 Trax
LG GSM	TU575
LG GSM	GD580 Lollipop
LG GSM	KU580
LG GSM	T580
LG GSM	600GB
LG GSM	G600S G6
LG GSM	G600K G6
LG GSM	G600L G6
LG GSM	F600L V10
LG GSM	F600S V10
LG GSM	LG-K600Y X Fast
LG GSM	KF600
LG GSM	US601 X
LG GSM	D605 Optimus L9 II
LG GSM	E610 Optimus L5
LG GSM	E612 Optimus L5
LG GSM	E612f Optimus L5
LG GSM	E612g Optimus L5
LG GSM	E615
LG GSM	E617G Optimus L5
LG GSM	D620 G2 Mini
LG GSM	D618 G2 Mini
LG GSM	D620k G2 Mini
LG GSM	D620r G2 mini
LG GSM	F620K Class
LG GSM	GW620
LG GSM	HB620T
LG GSM	D625 G2 Mini
LG GSM	CB630
LG GSM	H631TN
LG GSM	MS631 G Stylo
LG GSM	H631MX G Stylo
LG GSM	H630 G4 Stylus
LG GSM	H634 G Stylo
LG GSM	SU640 Optimus Vu
LG GSM	P659 Optimus F3
LG GSM	C660
LG GSM	C660R Gossip Pro
LG GSM	D680 G Pro Lite
LG GSM	F650K X Screen
LG GSM	D683 G Pro Lite
LG GSM	D685 Pro Light
LG GSM	D686 G Pro Lite
LG GSM	D690 G3 Stylus Dual
LG GSM	P690 Optimus Link
LG GSM	D693 G3 Stylus
LG GSM	D693n G3 Stylus

LG GSM	P690b Optimus Net
LG GSM	P690f Optimus Net
LG GSM	P699 Optimus Net
LG GSM	F700S G5
LG GSM	H700
LG GSM	V700 G Tablet 10.1
LG GSM	P700 Optimus L7
LG GSM	US700 Q6
LG GSM	P705 Optimus L7
LG GSM	P705f Optimus L7
LG GSM	P705g Optimus L7
LG GSM	KF700
LG GSM	F700L G5
LG GSM	P708g Optimus L7
LG GSM	C710H Shine Plus
LG GSM	GD710
LG GSM	LGMP450 Stylo 3 Plus
LG GSM	TP450 LG Stylo 3
LG GSM	P710 Optimus L7 II
LG GSM	P714 L7 II
LG GSM	P715 Optimus L7 II Dual
LG GSM	CU720 Shine
LG GSM	E720b Optimus Chic
LG GSM	P720 Optimus 3D Max
LG GSM	P720h
LG GSM	TU720 Shine
LG GSM	D631 G Vista
LG GSM	LM-Q710TS Stylo 4
LG GSM	LM-Q710WA Stylo 4
LG GSM	LM-Q850EAW G7 Fit
LG GSM	D722 G3 S
LG GSM	D722p G3 Beat
LG GSM	D722k G3 S
LG GSM	D724 G3 Beat
LG GSM	D725 G3 Vigor
LG GSM	H731 G4 Vigor
LG GSM	P725
LG GSM	C729 DoublePlay
LG GSM	C729 MyTouch
LG GSM	E730 Optimus Sol
LG GSM	E730f Optimus Sol
LG GSM	E739 myTouch
LG GSM	H740 G Vista 2
LG GSM	H735T G4 Beat
LG GSM	H736P G4 Beat
LG GSM	GM750
LG GSM	KF750 Secret
LG GSM	P760 Optimus L9
LG GSM	P768 Optimus L9
LG GSM	P768g Optimus L9
LG GSM	P769 Optimus L9
LG GSM	MS769 Optimus L9
LG GSM	KB770
LG GSM	ME770 Shine
LG GSM	H790 Nexus 5X

LG GSM	H791 Nexus 5X
LG GSM	MS790
LG GSM	C800 myTouch Q
LG GSM	LG800G
LG GSM	C800G Eclipse
LG GSM	D800 (G2)
LG GSM	KE800
LG GSM	KG800
LG GSM	MG800
LG GSM	KU800
LG GSM	D801 G2
LG GSM	D802 G2
LG GSM	D803 G2
LG GSM	D805 G2
LG GSM	CT810 Incite
LG GSM	KG810
LG GSM	MG810d
LG GSM	H810 G4
LG GSM	H811 G4
LG GSM	H815 G4
LG GSM	H815P G4
LG GSM	H818P G4
LG GSM	H820 G5
LG GSM	H830 G5
LG GSM	H831 G5
LG GSM	H860 G5
LG GSM	H840 G5 SE
LG GSM	H850 G5
LG GSM	H870 G6
LG GSM	H870DS G6
LG GSM	H871 G6
LG GSM	H872 G6
LG GSM	H873 G6
LG GSM	GW820 eXpo
LG GSM	KE820
LG GSM	D820 Nexus 5
LG GSM	D821 Nexus 5
LG GSM	GW825 IQ
LG GSM	KE850 Prada
LG GSM	L-01F G2
LG GSM	D850 G3
LG GSM	F800L V20
LG GSM	F800S V20
LG GSM	D852 G3
LG GSM	D855 G3
LG GSM	D855P G3
LG GSM	D855K G3
LG GSM	D851 G3
LG GSM	D858HK G3 Dual
LG GSM	H900 V10
LG GSM	H901 V10
LG GSM	H910 V20
LG GSM	H918 V20
LG GSM	H960 V10
LG GSM	H960A V10

LG GSM	H961N V10
LG GSM	H962 V10
LG GSM	H968 V10
LG GSM	VS985R G3
LG GSM	H990 V20
LG GSM	H930G V30+
LG GSM	H930DS V30+
LG GSM	H931 V30
LG GSM	LGM-V300L V30
LG GSM	H990DS V20
LG GSM	US991 G4
LG GSM	P870 Escape
LG GSM	SU870 Optimus 3D Cube
LG GSM	P875 Optimus F5
LG GSM	KD876 Swivel
LG GSM	KT878
LG GSM	GD880 Mini
LG GSM	P880 Optimus 4X
LG GSM	P880g Optimus 4X HD
LG GSM	U880
LG GSM	P895 Optimus Vu
LG GSM	C900 Quantum (USB)
LG GSM	C900 Quantum (BT)
LG GSM	E900 Optimus 7 (USB)
LG GSM	E900 Optimus 7 (BT)
LG GSM	GC900
LG GSM	GD900
LG GSM	KF900 Prada II
LG GSM	KM900 Arena
LG GSM	V900 Optimus Pad
LG GSM	V909 G-Slate
LG GSM	KC910Q Renoir
LG GSM	CU920 Vu
LG GSM	KG920
LG GSM	P920 Optimus 3D
LG GSM	VS920 Spectrum
LG GSM	P925 Thrill 4G
LG GSM	P925g Optimus 3D
LG GSM	P930 Nitro HD
LG GSM	V930 G Pad X
LG GSM	V935 G Pad II 10.1
LG GSM	P936 Optimus True HD LTE
LG GSM	P940 Prada
LG GSM	D950 G Flex
LG GSM	DM-01G Disney
LG GSM	GT950 Arena (Content)
LG GSM	M153 Fortune LTE
LG GSM	M150 Phoenix 3
LG GSM	M151 K4
LG GSM	D956 G Flex
LG GSM	D958 G Flex
LG GSM	D959 G Flex
LG GSM	E960 Nexus 4
LG GSM	E970 Optimus G
LG GSM	GD970 Versace

LG GSM	KE970 Shine
LG GSM	ME970d Shine
LG GSM	P970 Optimus Black
LG GSM	P970h Optimus Black
LG GSM	P970g Optimus
LG GSM	E971 Optimus G
LG GSM	E973 Optimus G
LG GSM	E975 Optimus G
LG GSM	E975K Optimus G
LG GSM	E980 Optimus G Pro
LG GSM	E989 Optimus G Pro
LG GSM	H950 G Flex 2
LG GSM	D955 G Flex
LG GSM	F520S AKA 4G
LG GSM	H788 AKA
LG GSM	H955 G Flex 2
LG GSM	H959 G Flex 2
LG GSM	LGL39C Optimus Dynamic II
LG GSM	KE990d
LG GSM	KU990 Viewty
LG GSM	P990 Optimus X2 Speed
LG GSM	P990H Optimus 2X
LG GSM	AS993 G6
LG GSM	LS993 G6
LG GSM	LS997 V20
LG GSM	AS998 V30
LG GSM	P999 GX2
LG GSM	A395
LG GSM	C1100
LG GSM	L1100
LG GSM	L1150
LG GSM	L1200
LG GSM	L1400
LG GSM	C1300
LG GSM	C1500
LG GSM	B2000
LG GSM	B2100
LG GSM	C2000
LG GSM	F2100
LG GSM	F2400
LG GSM	F2410
LG GSM	C3300
LG GSM	C3310
LG GSM	G4010
LG GSM	G4015
LG GSM	G4050
LG GSM	S5200
LG GSM	T5100
LG GSM	G5300
LG GSM	G5400
LG GSM	L-02D Prada 3.0
LG GSM	KU5400 Prada 3.0
LG GSM	M6100
LG GSM	G7100
LG GSM	P7200

LG GSM	U8100
LG GSM	U8110
LG GSM	U8120
LG GSM	U8180
LG GSM	U8210
LG GSM	U8330
LG GSM	U8360
LG GSM	U8500
M4Tel	SS220 VIBER (USB)
M4Tel	SS220 VIBER (BT)
MLS	iQ1950 Diamond
MLS	iQ3204 Magic 11.6
MLS	iQ1511 IQ Talk Spicy
MLS	IQ1551 iQTalk
MLS	iQ1850 Diamond
MLS	iQ9016 Grand 4G
MLS	iQ9610 Angel 3G
MTC	Beeline C201
MTC	975
MTC	978
MTC	970H
MTC	Smart Sprint
MTC	982
Chinese phones	Generic MTK
Chinese phones	Chinese Brand One_DS DTECH
Chinese phones	NGM Argo
Chinese phones	ECO Eco Senior_DS
Chinese phones	Chinese Brand KSR-01 Vitek Black
Chinese phones	Chinese Brand Ttine Y918_DS
Chinese phones	Ulcool V26
Chinese phones	Ulcool V2T
Chinese phones	Bontel V2
Chinese phones	Sonica M2
Chinese phones	Sonica M1
Chinese phones	Sonica M1 Plus
Chinese phones	AEKU I9
Chinese phones	Anica A16
Chinese phones	Anica A9
Chinese phones	AEKU C8
Chinese phones	Easyphone NP66
Chinese phones	Denver GSP-120
Chinese phones	Fake Nokia Ditel V30
Chinese phones	IMO Dash Basic
Chinese phones	A13 Discovery
Chinese phones	Vkworld V3S
Chinese phones	LART CM1-B Cardphone
Chinese phones	AIEK KK1
Chinese phones	Logicom L280
Chinese phones	YEZZ C23A
Chinese phones	LOGOS 222
Chinese phones	Binatone The Brick
Chinese phones	AG RAZOR
Chinese phones	Oyster S
Chinese phones	ECHO First
Chinese phones	IBall King 2 1.8B

Chinese phones	iPro Venus L
Chinese phones	Mini LONDON
Chinese phones	ZTC
Chinese phones	SIGMA
Chinese phones	Lake Tahoe I
Chinese phones	Mini Sidney
Chinese phones	Mint F1CR
Chinese phones	NOKAI D01A
Chinese phones	Fake Nokia C1-01(JX-589)
Chinese phones	NP-01 Easy Phone 3G
Chinese phones	AirPhone 4GS
Chinese phones	AT Hi Messenger
Chinese phones	MobiWire Ayasha
Chinese phones	Eco Simply
Chinese phones	Mojo Chat
Chinese phones	iOutdoor T1
Chinese phones	Truconnect Micro II
Chinese phones	Senseit L131
Chinese phones	TT110 TTfone
Chinese phones	STK R45i
Chinese phones	NewMind F15 Plus
Chinese phones	OBI F240_DS
Chinese phones	Rockr S242_DS Voda
Chinese phones	NewMind F15
Chinese phones	NewMind F8
Chinese phones	T130_DS TTsims
Chinese phones	K689_DS
Chinese phones	Chinese Brand A02 Shino
Chinese phones	Chinese Brand X2-01
Chinese phones	X2-02 Fake Nokia
Chinese phones	China iPhone 3G
Chinese phones	iPhone 4G+++
Chinese phones	Nassau
Chinese phones	F1
Chinese phones	Mparty LT2
Chinese phones	Blue Candy 235
Chinese phones	Q2
Chinese phones	Rockstar S2
Chinese phones	CPPC V2
Chinese phones	A3v
Chinese phones	G3 KE02
Chinese phones	WG3
Chinese phones	WG3J
Chinese phones	F003 China iPhone
Chinese phones	F003 Fly Ying
Chinese phones	iPhone A3
Chinese phones	Q3
Chinese phones	LC C4
Chinese phones	A4
Chinese phones	NOKA C6
Chinese phones	A5
Chinese phones	A5V Xperia
Chinese phones	NOKIA E5
Chinese phones	Alfatel H5A
Chinese phones	PX i5

Chinese phones	A8 Mini_DS
Chinese phones	I867 Ferrari
Chinese phones	WG5
Chinese phones	iRadish Y6 Smart Watch
Chinese phones	iPro I7
Chinese phones	TV Mobile A007+
Chinese phones	Chinese Brand V7
Chinese phones	CPPQ X7
Chinese phones	A8
Chinese phones	Nokia N8 IDEM
Chinese phones	Mphone Q8
Chinese phones	Opopo Q8
Chinese phones	Chinese Brand KU9 Konka
Chinese phones	WG9
Chinese phones	BlackBerry F006
Chinese phones	Tubi T6
Chinese phones	Newman C9S
Chinese phones	Dano I7
Chinese phones	Dano I8
Chinese phones	K007 HKTEL
Chinese phones	Ferrari Ti
Chinese phones	C8
Chinese phones	Q8 Watch Phone
Chinese phones	Ferrari F8
Chinese phones	CPPC JH08
Chinese phones	Vision H8
Chinese phones	DTNO A9
Chinese phones	iPhone i9
Chinese phones	K9
Chinese phones	V9
Chinese phones	Toshiba V9+
Chinese phones	OPQC F16
Chinese phones	Switel M16D ROMA
Chinese phones	Q16 Fake Blackberry 9320
Chinese phones	HOTOLO N18
Chinese phones	JV 21M
Chinese phones	C23A
Chinese phones	YEZZ C21
Chinese phones	Evertex E25 Dual Sim
Chinese phones	Admet B30
Chinese phones	HYTLL H30
Chinese phones	T33+ Eiroga
Chinese phones	EMPORIA V50
Chinese phones	Slider W50B
Chinese phones	X8
Chinese phones	C12_DS Yuntab
Chinese phones	Nokia E52
Chinese phones	M55 G'Five
Chinese phones	Nokia E58
Chinese phones	E62 iPro
Chinese phones	ES65
Chinese phones	Nokia E66
Chinese phones	Nokia E66i
Chinese phones	Nokia E71
Chinese phones	E71++ Morgan

Chinese phones	Nokia E72 Sanno Gowin
Chinese phones	Nokla E81 TV Mobile
Chinese phones	NCKIA N86
Chinese phones	NOKLA N86
Chinese phones	FoxPhone F88 Brand
Chinese phones	mini N82
Chinese phones	Nokla N95
Chinese phones	Leady MM95
Chinese phones	MM96 Leady
Chinese phones	N96i Smadl
Chinese phones	Nokia N97
Chinese phones	Fake Nokia N98
Chinese phones	Nokia E81 TV mobile
Chinese phones	MOTCRCLA U99
Chinese phones	D100 Argom (USB)
Chinese phones	D100 Argom (BT)
Chinese phones	X100 XKSSTEL
Chinese phones	Pictor BC 101
Chinese phones	Hitech Micra 101
Chinese phones	Amgoo AM102
Chinese phones	Hitech Micra 105
Chinese phones	T106i
Chinese phones	JTEL DJ J109
Chinese phones	KM119
Chinese phones	Chinese Brand U180 Ushining
Chinese phones	ROCKR Max Kosher
Chinese phones	WX181
Chinese phones	EX124G
Chinese phones	Telme C155
Chinese phones	IFOE P168C
Chinese phones	K520
Chinese phones	Mini Iphone 168 Hello Kitty
Chinese phones	K169
Chinese phones	K189 Glamour
Chinese phones	BESWIN BS218
Chinese phones	A200 NKTEL MTK
Chinese phones	Telme F210
Chinese phones	Coral 255
Chinese phones	RM-266V
Chinese phones	A300 NKTEL MACH
Chinese phones	A300 NKTEL MAXUS
Chinese phones	S300 SpiderMan
Chinese phones	S311 NONY
Chinese phones	CVABB M419 Mini Car
Chinese phones	P528 Giorgio Armami
Chinese phones	ShengBao 98+
Chinese phones	Shaop KN608
Chinese phones	K619 Ksanilli
Chinese phones	Coral 680
Chinese phones	T912 F912
Chinese phones	Wind DUO 2100 (Camera side)
Chinese phones	Wind DUO 2200 (Bluetooth (no multimedia))
Chinese phones	DUALSIM MINI
Chinese phones	Chinese Brand T19 Cectdigi
Chinese phones	Kux T99

Chinese phones	DUALSIM SLIDER
Chinese phones	ChangJiang A968
Chinese phones	2008 Nktel
Chinese phones	ZTC ZT2008
Chinese phones	SD3600
Chinese phones	D6000
Chinese phones	BlackBerry 8900
Chinese phones	BlackBerry C9000
Chinese phones	Blackberry W9530
Chinese phones	Blackberry W9630 G-TIDE
Chinese phones	Blackberry 9650+
Chinese phones	TCL Q3
Chinese phones	Nokia N97i
Chinese phones	BBK i530 (USB)
Chinese phones	BBK i530 (BT)
Chinese phones	SHAPR SH920
Chinese phones	Z9 Korean
Chinese phones	MOTCPCLA V8
Chinese phones	MOKIA 8830e
Chinese phones	SUMSANG XP100
Chinese phones	MOTOCCLA V14W
Chinese phones	NOKIA C6+
Chinese phones	NCKIA N98
Chinese phones	NOKIA N88i
Chinese phones	HELLO KITTY S100
Chinese phones	iPhone A380
Chinese phones	BRK I606
Chinese phones	BBK i588
Chinese phones	KoJeonJeokIn F608
Chinese phones	Panascnio GD88+
Chinese phones	NOKIA C7-00
Chinese phones	iPhone 4GS
Chinese phones	NCKLA C5-03
Chinese phones	Cartier MINI002
Chinese phones	NOKIA 6700S+
Chinese phones	obbo S266
Chinese phones	NOKIA E71
Chinese phones	Everttek E300
Chinese phones	ePhone FM500
Chinese phones	Cartier
Chinese phones	iPhone I4S
Chinese phones	NOKIA N89
Chinese phones	iPhone4 K668
Chinese phones	NOKLA C5-03
Chinese phones	Icnevo i6
Chinese phones	iPhone i86
Chinese phones	BDK i270
Chinese phones	iPhcne G16
Chinese phones	SUNSAMG F1
Chinese phones	Anycool M11
Chinese phones	SNAHP 08A
Chinese phones	BKK K203
Chinese phones	SICT GD276
Chinese phones	MCTCRCLA 809
Chinese phones	Magic

Chinese phones	AnyColl S860
Chinese phones	KICCY KR999 Classical Retro
Chinese phones	music S506
Chinese phones	BlackBerry 9900
Chinese phones	Slider S1
Chinese phones	L9_DS
Chinese phones	20170319_DS Liaolajiao G2
Chinese phones	NP-11 EasyPhone 3G
Chinese phones	Slider W60i
Chinese phones	Souy Eriossn W888
Chinese phones	NCKIA C5
Chinese phones	SCNY Q9
Chinese phones	Nexian NX-G508
Chinese phones	DOVO S600
Chinese phones	cbbc A202
Chinese phones	DOOA S868
Chinese phones	Scny Eriossn H18
Chinese phones	FHILIPS X080
Chinese phones	NCKLA C6-00
Chinese phones	NOKAI X6
Chinese phones	X671
Chinese phones	EASTCOM EA500
Chinese phones	Sony Ericson J20
Chinese phones	iphono A518
Chinese phones	ScellPhone i68+
Chinese phones	Nckia N8
Chinese phones	VERTU F9
Chinese phones	G717
Chinese phones	SAMSUNC
Chinese phones	X5
Chinese phones	NOKIA E7-00
Chinese phones	NOKIA E9
Chinese phones	iPhone 4G (G2000)
Chinese phones	DCCA S630
Chinese phones	Nokia L700
Chinese phones	L1668 LINYING
Chinese phones	Chinese Brand X1818
Chinese phones	TV-1800
Chinese phones	W3000
Chinese phones	G5000
Chinese phones	W5000
Chinese phones	Nokia 5800
Chinese phones	DaPeng Tphone T7000
Chinese phones	Blackberry 8520W
Chinese phones	NCKIA N10
Chinese phones	NCKIA C6
Chinese phones	HYNUIOAI H800
Chinese phones	ponpo V100
Chinese phones	hTc G7
Chinese phones	VERTU
Chinese phones	iPhone G8000 Star
Chinese phones	NCKIA 8900e
Chinese phones	Nokia 8860E
Chinese phones	Blackberry 9000C WiFi
Chinese phones	BlackBerry 9000C+

Chinese phones	Blackberry 9700
Chinese phones	Blackberry 9700++
Chinese phones	Blackberry W9700
Chinese phones	Blackberry H9800
Chinese phones	SUMSUNG M560
Chinese phones	GPRS F8
Chinese phones	RDTECH N88
Chinese phones	Ferrari RM-F101
Chinese phones	Suny Ericsson S596
Chinese phones	MOTOROLA A900
Chinese phones	SAny Ericsson S600
Chinese phones	QWERTY
Chinese phones	SHRAP 8088
Chinese phones	ROLEX K18
Chinese phones	MOLOTOTA V18+
Chinese phones	VERSAOE U6
Chinese phones	Nokia N99
Chinese phones	Scny Ericsson W915
Chinese phones	L.M.D Telecom T10
Chinese phones	LC KU4000
Chinese phones	lencvo E809
Chinese phones	Portable V99
Chinese phones	Positivo P20
Chinese phones	Positivo P30
Chinese phones	iPhone ip 709
Chinese phones	Sony Ericsson X10
Chinese phones	Suny Ericsson E708
Chinese phones	NOKIA C5-03
Chinese phones	Nokia E79
Chinese phones	Fake Nokia E79+
Chinese phones	Samgle 3G 3310
Chinese phones	NOKIA 5800
Chinese phones	MCTCRCLA H701
Chinese phones	iPhone W818
Chinese phones	google Hero
Chinese phones	SANSVNG K520
Chinese phones	NOKIA X6
Chinese phones	SunCorp K530
Chinese phones	NOKIA N708
Chinese phones	cqqc U520
Chinese phones	DOOV S990
Chinese phones	Audioline MT 1000
Chinese phones	SCNY 1000
Chinese phones	MOTOROLA 6288+
Chinese phones	BESWIN F589
Chinese phones	DaoShun F589
Chinese phones	BRK F800
Chinese phones	HEDY M960
Chinese phones	iPhone E800
Chinese phones	China iPhone 911
Chinese phones	NCKIA X8
Chinese phones	NOKIA 5250
Chinese phones	NOKIA G9
Chinese phones	UKING A330
Chinese phones	RRK i730

Chinese phones	Anycoll X8
Chinese phones	SANSUNG Q7+
Chinese phones	84H-3 Gps Navigation
Chinese phones	NCKLA N96
Chinese phones	Suny Ericssom T18
Chinese phones	BBR 802
Chinese phones	NOKLA N7
Chinese phones	iPhone5
Chinese phones	Fake iPhone 5S (A1530)
Chinese phones	Phone5G P5
Chinese phones	NOKAI 500
Chinese phones	KISS 520
Chinese phones	Corporation N8-01
Chinese phones	Aaycull S530
Chinese phones	MOTOPOLA M810
Chinese phones	NOKIA N8-01
Chinese phones	DCCV S800
Chinese phones	NCKIA X7
Chinese phones	JinPeng JP168
Chinese phones	NOMI i246
Chinese phones	K380 CARELAND
Chinese phones	Fadar C865
Chinese phones	Geemarc CL8350-3G (USB)
Chinese phones	Geemarc CL8350-3G (BT)
Chinese phones	GIHCE M600
Chinese phones	SVMSnNG F318
Chinese phones	Slider T20
Chinese phones	Slider W30C Premium
Chinese phones	Slider W20C_DS
Chinese phones	SMART N7
Chinese phones	Smooth SNAP Amigo
Chinese phones	Coolgen HD7
Chinese phones	Oeina XP7
Chinese phones	Fadar C867
Chinese phones	YeonYeonMos F6
Chinese phones	DOVO M8
Chinese phones	OBBC V058
Chinese phones	NOKIA N97
Chinese phones	IMD m618
Chinese phones	DOOV X1
Chinese phones	cpcc K3
Chinese phones	LanJiXing JL838
Chinese phones	TELSDA T662
Chinese phones	NCBC U303
Chinese phones	Lingyun E191
Chinese phones	Beswin F618
Chinese phones	Beswin BS200
Chinese phones	LINWON T288
Chinese phones	SANCHIN S988
Chinese phones	SANCHIN S788
Chinese phones	SANCHIN i519
Chinese phones	YEPEN YP939
Chinese phones	YEPEN YP963
Chinese phones	SICT GS6119
Chinese phones	SICT GF-F2

Chinese phones	SICT F1
Chinese phones	SICT GD3112
Chinese phones	SICT F88
Chinese phones	SICT GD3113
Chinese phones	AILISHUN A96
Chinese phones	SICT GD368
Chinese phones	SICT GD88
Chinese phones	E241S_DS
Chinese phones	SICT GS6109
Chinese phones	SICT F6000
Chinese phones	AINKIN S798
Chinese phones	AILISHUN A6
Chinese phones	YEPEN YP928
Chinese phones	Fake Nokia 2610 (RH-86)
Chinese phones	Lingyun S8388
Chinese phones	elitek C1000
Chinese phones	NCKIA T880
Chinese phones	JINHAN JH-1866
Chinese phones	OCCO OK333
Chinese phones	elitek H6
Chinese phones	TELSDA T660
Chinese phones	GOFEEEL HJ5568
Chinese phones	IceMobile C89 Rock Lite
Chinese phones	FADAR FDT C899
Chinese phones	PULID D2838
Chinese phones	PULID D1858
Chinese phones	PULID D2658
Chinese phones	PULID D1589
Chinese phones	ZOYE E97
Chinese phones	CoolGen HD8
Chinese phones	android G7+
Chinese phones	Iphcne I9
Chinese phones	YEPEN YP968
Chinese phones	SICT GF-F8
Chinese phones	YIHEYUAN Y992
Chinese phones	OBEE 165
Chinese phones	elitek 6622
Chinese phones	LanJiXing JLS110
Chinese phones	YEPEN Y66
Chinese phones	YEPEN P400
Chinese phones	hantel HT8681
Chinese phones	IMD E800
Chinese phones	Fadar FDT C858
Chinese phones	Egltel E71-1
Chinese phones	TELSDA T882
Chinese phones	LG X10
Chinese phones	G13 Phone Watch
Chinese phones	NCKIA C08
Chinese phones	SAGA V8
Chinese phones	hantel LX689
Chinese phones	DONXON A8
Chinese phones	NCKIA E89
Chinese phones	SAMSUNG S100
Chinese phones	AOLE 978
Chinese phones	Z&K ZK-K1

Chinese phones	Mercedes M8
Chinese phones	YAS YAS-F706
Chinese phones	NOKIA N86i
Chinese phones	SHAPb E369
Chinese phones	PULID K289
Chinese phones	NOKIA 8830e
Chinese phones	M560 Newman
Chinese phones	LT F18
Chinese phones	MOTQRQLA V10
Chinese phones	SAMSUNG GT-B7732
Chinese phones	iPhane A9
Chinese phones	NCKLA E73
Chinese phones	CHANCHONC E16
Chinese phones	NCKIA 6800S
Chinese phones	MOTOLARO M7
Chinese phones	KINGK K206
Chinese phones	sins S60
Chinese phones	CBT K488
Chinese phones	SunCorp Y518
Chinese phones	LC K700
Chinese phones	NOKIA V86
Chinese phones	PULID D202
Chinese phones	BBE M707
Chinese phones	R800 D-One
Chinese phones	EASTCOM ET888
Chinese phones	GUOQIAN GQ500
Chinese phones	NCKIA N900
Chinese phones	TELSDA T883
Chinese phones	HYUNDAI H708
Chinese phones	MT-F777
Chinese phones	4GS A8
Chinese phones	HYUNDAI H-E58
Chinese phones	Fake Nokia 1100 (RM-352)
Chinese phones	Itel it2060
Chinese phones	Itel it2090
Chinese phones	SIGMA S3500_DS X-Style
Chinese phones	XP3600
Chinese phones	Itel it5010
Chinese phones	Itel it5020
Chinese phones	Itel it5300
Chinese phones	Itel it5620
Chinese phones	Itel it5606
Chinese phones	Itel it5616
Chinese phones	AEKU i5S
Chinese phones	X-TIGI G20_DS
Chinese phones	SIGMA X-style 28 Flip
Chinese phones	B201i Lemon
Chinese phones	Itel it5022
Chinese phones	Itel it5630
Chinese phones	Itel it2171
Chinese phones	HQ-U2011
Chinese phones	W6000
Chinese phones	W6000+
Chinese phones	SHAPR SH9020G
Chinese phones	YEPEN Y18

Chinese phones	SICT GD3106
Chinese phones	GT-S5830
Chinese phones	Q6010
Chinese phones	Chinese Brand Qmart Q3
Chinese phones	V15 SOS Elder Phone
Chinese phones	S600
Chinese phones	Chinese Brand 6700
Chinese phones	Amplicomms Powertel M7000
Chinese phones	Amplicomms Power Tel M8000 (USB)
Chinese phones	Amplicomms Power Tel M8000 (BT)
Chinese phones	Fake Samsung I9300
Chinese phones	J9300
Chinese phones	Fake Blackberry K9300 Kimfly
Chinese phones	L913
Chinese phones	YXTEL K5000 C3303i
Chinese phones	Fysic FM-9800
Chinese phones	jFONE CC6TV
Chinese phones	Heisense HS-N51
Chinese phones	MANTA TEL1711
Chinese phones	MANTA MS1701
Chinese phones	Chinese Brand 9981
Chinese phones	X-TIGI S23
Chinese phones	Spice Style 240
Chinese phones	Voda Rockr F180 2G
Chinese phones	True Super 3 Extra
Chinese phones	Zizo Z101 Z180
Chinese phones	BLK 52126 Joy
Chinese phones	Telefunken TM9.1 Classy
Chinese phones	VKworld V3 Plus
Chinese phones	Online X45
Chinese phones	Online X46
Chinese phones	Uniwa V708
Chinese phones	K07_DS Servo
Chinese phones	AK007_DS Hope
Chinese phones	Xiaolajiao G-109_DS W11
Chinese phones	Xiaolajiao G-660_DS A6 (F6)
Chinese phones	Xiaolajiao G-660_DS L9
Chinese phones	Xiaolajiao G-666_DS V5
Chinese phones	Vkworld Z3
Chinese Android phones	Android MTK Bluetooth Fast Phonebook
Chinese Android phones	Android MTK
Chinese Android phones	AllCall Rio
Chinese Android phones	Soyes XS
Chinese Android phones	X27 Owwo
Chinese Android phones	Xgody S10
Chinese Android phones	Xgody Mate 20 Mini_DS
Chinese Android phones	Xgody M30s
Chinese Android phones	Xgody NOTE 7_DS
Chinese Android phones	Chinese Brand 20190718Q Hong La Jiao 9 Red Chili Phone
Chinese Android phones	Matsunichi M97
Chinese Android phones	VLE5 Hot Pepper Poblano
Chinese Android phones	Nubia NX627J_DS Z20
Chinese Android phones	Infocus IF9031 Vision 3
Chinese Android phones	Infocus M260
Chinese Android phones	Smartron T5511

Chinese Android phones	Infocus M535
Chinese Android phones	Jazz Aspera
Chinese Android phones	D5.5 Dual Camera Bush Spira
Chinese Android phones	Nuu Mobile NUU_A3 A3
Chinese Android phones	AllCall Alpha
Chinese Android phones	Swift
Chinese Android phones	GO JL621 M4
Chinese Android phones	Ployer MOMO21 3G
Chinese Android phones	Onyx Mobicel
Chinese Android phones	Fake China iPhone cphone 4
Chinese Android phones	20181225 Red Chillli 7R Xiaolajiao
Chinese Android phones	GS100_DS Gigaset
Chinese Android phones	imo Q3 Plus
Chinese Android phones	imo Q2 Plus
Chinese Android phones	Chinese Brand S9 TEENO VMobile
Chinese Android phones	UMIDIGI A3 Pro_DS
Chinese Android phones	Easyphone NP-10
Chinese Android phones	iVooMi Me 5
Chinese Android phones	iVooMi Me 3
Chinese Android phones	LeEco Le X620 Le2 Pro
Chinese Android phones	YEZZ Andy 5E
Chinese Android phones	Itel A12
Chinese Android phones	Xiaolajiao 20190325D_DS 8X
Chinese Android phones	Meitu MP1801 V7
Chinese Android phones	Orange Melrose S9P
Chinese Android phones	Inoi 3 Lite
Chinese Android phones	R17_DS
Chinese Android phones	360 180-A01 Phone N7
Chinese Android phones	IRBIS TZ725e
Chinese Android phones	Inoi 2 Lite
Chinese Android phones	Wileyfox Swift 2
Chinese Android phones	Kenxinda S9
Chinese Android phones	FREETEL FTJ17A00 REI 2
Chinese Android phones	Truconnect X444 Drive II
Chinese Android phones	YEZZ Andy 4E
Chinese Android phones	LeEco LEX626 Le S3
Chinese Android phones	LeEco Le X622
Chinese Android phones	LEMFO LEM5Pro
Chinese Android phones	ANS UL40
Chinese Android phones	Vortex Beat 8
Chinese Android phones	Meitu MP1603 M8
Chinese Android phones	Meitu MP1602 T8
Chinese Android phones	Meitu MP1503 M6
Chinese Android phones	MP1709 M8S
Chinese Android phones	MEITU MP1605 V6
Chinese Android phones	MEITU MP1718 T9
Chinese Android phones	Meitu MP180 V7 Tonino Lamborghini
Chinese Android phones	Switel eSmart M3
Chinese Android phones	U25GT-C4YT
Chinese Android phones	U27GT-S
Chinese Android phones	Fake iPhone 5C Ai383
Chinese Android phones	Chungha
Chinese Android phones	Fake Xiaomi MI NOTE LTE
Chinese Android phones	iRULU MID
Chinese Android phones	Mapan MX710B-3G MID

Chinese Android phones	Argom E550 Tech
Chinese Android phones	Gphone F23
Chinese Android phones	Itel A11
Chinese Android phones	Itel it1408
Chinese Android phones	Itel it1508
Chinese Android phones	Xphone
Chinese Android phones	Fake Xiaomi HM NOTE 1TD
Chinese Android phones	Fake Xiaomi HM 1STD Redmi
Chinese Android phones	JIAYU JY-G1
Chinese Android phones	NGM Action
Chinese Android phones	NGM E506 Plus
Chinese Android phones	Nyx N1 Discovery
Chinese Android phones	HTM M1
Chinese Android phones	FP1
Chinese Android phones	Pipo S1 Pro
Chinese Android phones	Rivo PZ1 Phantom
Chinese Android phones	JIAYU JY-G2
Chinese Android phones	JIAYU JY-G2S
Chinese Android phones	Freelander PX2
Chinese Android phones	A3Q IDEM
Chinese Android phones	Inoi 1 Lite
Chinese Android phones	Chinese Brand N1
Chinese Android phones	Chinese M-Net Power 1
Chinese Android phones	Fake Samsung Lafone SIII Mini S3
Chinese Android phones	Tesco Hudl HT7S3
Chinese Android phones	Tesco HTFA4W Hudl 2
Chinese Android phones	Tesco HT7D16S3 Hudl 2
Chinese Android phones	Nabi 2 MGTB-MT7A
Chinese Android phones	iBall Andi4a Projector
Chinese Android phones	Fake Xiaomi MI-4LTE
Chinese Android phones	S4 Fake
Chinese Android phones	Adcom Icon4
Chinese Android phones	Amgoo AM402 Pronto
Chinese Android phones	Amgoo AM450 Swift
Chinese Android phones	S5
Chinese Android phones	One A5ENZE
Chinese Android phones	A5Q Xperia
Chinese Android phones	Alphone I6G iPad Mini
Chinese Android phones	iPhone A6
Chinese Android phones	Goophone 6S
Chinese Android phones	Pendo PP4MT-7 Pad 7
Chinese Android phones	Astro +7 Cyclone Voyager
Chinese Android phones	A7
Chinese Android phones	Fake ME7 CCTV (MA75)
Chinese Android phones	Fake M70 YFinside (MA75)
Chinese Android phones	Maze Alpha
Chinese Android phones	mt75 DEC
Chinese Android phones	mt75 UniStrong
Chinese Android phones	Fake Samsung Note 8
Chinese Android phones	Xiaocai Ebest S8 G6
Chinese Android phones	W8s ThL
Chinese Android phones	A9 8377 Tablet 3G
Chinese Android phones	Z18 Mini
Chinese Android phones	W11 ThL
Chinese Android phones	Pulid F15

Chinese Android phones	GF60
Chinese Android phones	Chinese Brand Mini iPad18 Coolgen E72 Note 8W
Chinese Android phones	Aoson M73T
Chinese Android phones	Teclast P80h tPad
Chinese Android phones	Essential PH-1
Chinese Android phones	Razer Phone RZ35-0215
Chinese Android phones	Razer RZ35-0259 Phone 2
Chinese Android phones	EL W40
Chinese Android phones	EL W45
Chinese Android phones	TP-Link TP706A Neffos C9A
Chinese Android phones	V89
Chinese Android phones	Vernee Apollo
Chinese Android phones	Vernee Mix 2
Chinese Android phones	Vernee Thor E
Chinese Android phones	Vernee Thor Plus
Chinese Android phones	06_V89 U920\K920
Chinese Android phones	Xgody D100
Chinese Android phones	Bird XL100 (Bluetooth)
Chinese Android phones	Budget Mobile X401
Chinese Android phones	Bird XL100 (USB)
Chinese Android phones	W100S ThL
Chinese Android phones	D101 Zoom
Chinese Android phones	W101
Chinese Android phones	SPHS on Hsdroid K166
Chinese Android phones	Fake Samsung GW-P308+\S600 S4
Chinese Android phones	Xolo A500S
Chinese Android phones	N501
Chinese Android phones	T612
Chinese Android phones	U650 Quad Core
Chinese Android phones	Digiland DL701Q
Chinese Android phones	Chinese Brand S750L
Chinese Android phones	GoTab GT785X X Mini
Chinese Android phones	Shinco FD790
Chinese Android phones	S801\V511M S801 MXNEC
Chinese Android phones	ONDA V819i Intel Bay Trail-T
Chinese Android phones	K820 820S
Chinese Android phones	Fake Samsung SM-G900F Galaxy S5
Chinese Android phones	Fake Samsung SM-G9006V Galaxy S5
Chinese Android phones	SM-N900 mini
Chinese Android phones	Digma LT4049PG Linx Atom 3G
Chinese Android phones	Smartab ST1009
Chinese Android phones	S901 Fake HTC Butterfly
Chinese Android phones	JCB TP909\HW-T18D
Chinese Android phones	920 mini
Chinese Android phones	U920 Fake Butterfly
Chinese Android phones	Fake Samsung SM-G920F Galaxy S6
Chinese Android phones	SPHS on Hsdroid i928
Chinese Android phones	U930 Fake Butterfly
Chinese Android phones	Unihertz Jelly Pro
Chinese Android phones	Zopo ZP980
Chinese Android phones	Q999
Chinese Android phones	JXD P1000
Chinese Android phones	Juning A8
Chinese Android phones	Juning K1
Chinese Android phones	Juning M9

Chinese Android phones	Denver SDQ-55024L
Chinese Android phones	Bluboo S8a
Chinese Android phones	GoClever Quantum II 500 N
Chinese Android phones	Juning T5
Chinese Android phones	Juning X6
Chinese Android phones	Juning Z8
Chinese Android phones	KNC MD-1008
Chinese Android phones	Kogan KHPHN3GQCA Agora Lite (USB)
Chinese Android phones	Kogan KHPHN3GQCA Agora Lite
Chinese Android phones	UHANS A101S
Chinese Android phones	Fake Lumia 1020
Chinese Android phones	B3000
Chinese Android phones	B3000 [HQ]
Chinese Android phones	T3000 JY131C
Chinese Android phones	GD Ippo rk3026
Chinese Android phones	Energy Phone Max 4000
Chinese Android phones	E4001 Life
Chinese Android phones	Qcom QS5509A QS5509QL
Chinese Android phones	Q5830
Chinese Android phones	S6500A S560
Chinese Android phones	SOYES 6S Mini iPhone 6S
Chinese Android phones	6802 Fake mini 7100
Chinese Android phones	GT-A7100 hTM
Chinese Android phones	H19 Fake Galaxy Note II
Chinese Android phones	i7100
Chinese Android phones	N7300 Note 3
Chinese Android phones	SPHS on Hsdroid 7562
Chinese Android phones	C8751M V75 Telephone Pad
Chinese Android phones	Tesla Smartphone 6.1
Chinese Android phones	TP-Link TP701B Neffos C5
Chinese Android phones	F9002
Chinese Android phones	MPI9082
Chinese Android phones	Mpie X800
Chinese Android phones	i9100
Chinese Android phones	Fake Samsung SM-N9100 Galaxy Note 4
Chinese Android phones	F9192 Fake Mini S4
Chinese Android phones	H9295 hTm
Chinese Android phones	9300
Chinese Android phones	9300 Fake Galaxy S 3
Chinese Android phones	Fake I9300 S3 Mini
Chinese Android phones	Fake Samsung BP-I9300 Galaxy S3
Chinese Android phones	S9300
Chinese Android phones	SPHS on Hsdroid 9500 BML
Chinese Android phones	9500 Fake S4 mini
Chinese Android phones	GT-A9500 HTM
Chinese Android phones	GT-I9500 Fake Samsung Galaxy S4
Chinese Android phones	Positivo S420 One
Chinese Android phones	Positivo S421 Life
Chinese Android phones	Power Tel M9000
Chinese Android phones	N9500
Chinese Android phones	Fake Samsung N9589 Note 2
Chinese Android phones	Coby MID9742 Kyros
Chinese Android phones	Nexbit Robin
Chinese Android phones	Siyata Mobile CP250
MTT	Smart Max 4G

Marshall	Marshall London
Mass Storage Device	USB Drive
Mass Storage Device	Memory Card
Mass Storage Device	Other MSD
Maxcom	MM139_DS
Maxcom	MK241
Maxcom	MS457
Maxcom	MM238 3G
Maxcom	MM320_DS
Maxcom	MM721 3G
Maxcom	MM760
Maxwest	Uno Flip
Maxwest	Vice 3G
Maxwest	6200 Orbit
Maxwest	X55 Astro
Maxwest	Nitro_55R
Meizu	MX M032
Meizu	MX2 M040
Meizu	MX2 M045
Meizu	MX3 M351
Meizu	M682Q M3X
Meizu	M571 m2 note
Meizu	M621H Meilan M5 Note
Meizu	Pro 6
Meizu	PRO 6 Plus
Meizu	M792H Pro 7
Meizu	PRO 7 Plus
Meizu	PRO 7S
Meizu	M822Q M1822 Note 8
Meizu	16th
Meizu	15
Meizu	16 Plus
Meizu	M852H X8
Meizu	M926Q 16Xs
Meizu	M923Q Note 9
Meizu	M891H 15 Plus
Meizu	M928Q_DS 16T
Meizu	M973Q 16s Pro
Meizu	16X
Meizu	M681H M3 Note
Meizu	Y685H M3S
Meizu	M688C M3
Meizu	M710H M5c
Meizu	MX4 MX460
Meizu	MX4 MX461
Meizu	M463C m1 note
Meizu	M463M m1 note
Meizu	M576 Pro 5
Meizu	M576H Pro 5
Meizu	M611A M5
Meizu	M611Y M5
Meizu	M A5 Meilan
Meizu	M5s Meilan
Meizu	MS6 Meilan
Meizu	M712Q Meilan S6

Meizu	MEILAN E3
Meizu	M811Q 6T
Meizu	M811H M6T
Meizu	M818H_DS C9
Meizu	M871H 15 Lite
Meizu	M881H 15
Meizu	M712H M6S
Meizu	M6 Meilan
Meizu	M6 Note
Meizu	M741A Meilan E2
Meizu	MX5
Meizu	U20
Micromax	Q5 eypad
Micromax	Q7 eypad
Micromax	Q413 Canvas Xpress 4G
Micromax	Q412 Canvas Fire 4G Plus
Micromax	Q417 Canvas Mega 4G
Micromax	Q426 Canvas Mega 2
Micromax	Canvas blaze Q400
Micromax	HS1_DS
Micromax	Q462 Canvas 5 Lite
Micromax	Q4101 Vdeo 2
Micromax	Q450 Canvas Silver 5
Micromax	Q55
Micromax	A60 Andro
Micromax	A61 Bolt
Micromax	X084
Micromax	A092 Unite
Micromax	A114R Canvas Beat
Micromax	A118R Canvas Tube
Micromax	A120 Canvas 2 Colors
Micromax	A121 Canvas Elanza 2
Micromax	A106 Unite 2
Micromax	A36 Bolt
Micromax	A59 Bolt
Micromax	A350 Canvas Knight
Micromax	A69 Bolt
Micromax	HS2 Canvas Infinity
Micromax	Q381 Bolt
Micromax	A093 Canvas Fire
Micromax	A096 Canvas Fire 3
Micromax	A190 Canvas HD Plus
Micromax	A104 Canvas Fire
Micromax	E484 Canvas 6 Pro
Micromax	X265
Micromax	X295
Micromax	X281
Micromax	X337
Micromax	X352
Micromax	X556
Micromax	X600 Gravity
Micromax	X605
Micromax	X1800
Micromax	X2400
Microsoft	Lumia 435 (RM-1068) (USB)

Microsoft	Lumia 435 (RM-1068) (BT)
Microsoft	Lumia 435 (RM-1070) (USB)
Microsoft	Lumia 435 (RM-1070) (BT)
Microsoft	Lumia 435 (RM-1071) (USB)
Microsoft	Lumia 435 (RM-1071) (BT)
Microsoft	Lumia 430 (RM-1099) (USB)
Microsoft	Lumia 430 (RM-1099) (BT)
Microsoft	Lumia 532 (RM-1034) (USB)
Microsoft	Lumia 532 (RM-1034) (BT)
Microsoft	Lumia 535 (RM-1089) (USB)
Microsoft	Lumia 535 (RM-1089) (BT)
Microsoft	Lumia 540 (RM-1141) (USB)
Microsoft	Lumia 540 (RM-1141) (BT)
Microsoft	Lumia 550 (RM-1127) (USB)
Microsoft	Lumia 550 (RM-1127) (BT)
Microsoft	Lumia 550 (RM-1128) (USB)
Microsoft	Lumia 550 (RM-1128) (BT)
Microsoft	Lumia 638 (RM-1010) (USB)
Microsoft	Lumia 638 (RM-1010) (BT)
Microsoft	Lumia 640 XL (RM-1066) (USB)
Microsoft	Lumia 640 XL (RM-1066) (BT)
Microsoft	Lumia 640 (RM-1072) (USB)
Microsoft	Lumia 640 (RM-1072) (BT)
Microsoft	Lumia 640 (RM-1073) (USB)
Microsoft	Lumia 640 (RM-1073) (BT)
Microsoft	Lumia 640 XL (RM-1063) (USB)
Microsoft	Lumia 640 XL (RM-1063) (BT)
Microsoft	Lumia 650 (RM-1154) (USB)
Microsoft	Lumia 650 (RM-1154) (BT)
Microsoft	Lumia 735 (RM-1041) (USB)
Microsoft	Lumia 735 (RM-1041) (BT)
Microsoft	Lumia 950 (RM-1105) (USB)
Microsoft	Lumia 950 (RM-1105) (BT)
Microsoft	Lumia 950 XL (RM-1085) (USB)
Microsoft	Lumia 950 XL (RM-1085) (BT)
Microsoft	Lumia 950 (RM-1118) (USB)
Microsoft	Lumia 950 (RM-1118) (BT)
MobiWire	Klah
MobiWire	Sakari
MobiWire	STARXTREM 3
MobiWire	STARACTIVE
MobiWire	STARNAUTE 3
MobiWire	STARNAUTE 4
MobiWire	STARSHINE 5
MobiWire	Startrail 7
MobiWire	Pictor
Mobistel	Cynus T2
Mobistel	Cynus T5
Mobistel	Cynus F6
Mobistel	Cynus T6
Mobistel	Cynus F8
Mobistel	Cynus T8
Atelier HC/ModeLabs	TAG Heuer Racer Meridiist II
Atelier HC/ModeLabs	TAG Heuer Racer
Atelier HC/ModeLabs	Dior Phone CD1-S

Atelier HC/ModeLabs	TAG Heuer TH01M Meridiist
Atelier HC/ModeLabs	Dior Phone CD02
Atelier HC/ModeLabs	TAG Heuer TH02M Link
Atelier HC/ModeLabs	HUMMER HT-5
Atelier HC/ModeLabs	MTV 3.3
Atelier HC/ModeLabs	Versace GD970
Modems	GlobeTrotter
Modems	O2 E161 Surfstick 3
Modems	E3372 Megafon
Modu	modu
Motorola CDMA	Generic Android (Logical Bypassing Lock)
Motorola CDMA	Generic Android (Logical ADB Normal(Recommended))
Motorola CDMA	XT1042 Moto G LTE
Motorola CDMA	Crush (UScellular)
Motorola CDMA	Crush (CellSouth)
Motorola CDMA	K1m KRZR (IL)
Motorola CDMA	K1m KRZR (CellSouth)
Motorola CDMA	K1m Krzr
Motorola CDMA	K1m MOTOKRZR (Verizon)
Motorola CDMA	RAZR MAXX Ve
Motorola CDMA	V3a RAZR
Motorola CDMA	V3c RAZR (CellSouth)
Motorola CDMA	V3c RAZR (Canada)
Motorola CDMA	V3c RAZR
Motorola CDMA	V3c RAZR (IL)
Motorola CDMA	V3c RAZR (Verizon)
Motorola CDMA	V3m RAZR (CellSouth)
Motorola CDMA	V3m RAZR (MetroPCS)
Motorola CDMA	V3m RAZR (Sprint)
Motorola CDMA	V3m RAZR
Motorola CDMA	V3s RAZR
Motorola CDMA	QA4 Evoke
Motorola CDMA	ZN4 Krave (Verizon)
Motorola CDMA	Z6m ROKR (Alltel)
Motorola CDMA	Z6m ROKR (Cricket)
Motorola CDMA	Z6m ROKR (CellSouth)
Motorola CDMA	Z6m ROKR (MetroPCS)
Motorola CDMA	Z6m ROKR (Sprint)
Motorola CDMA	Z6m ROKR (US Cellular)
Motorola CDMA	Z6c World (Verizon)
Motorola CDMA	RIZR Z6cx (Verizon)
Motorola CDMA	Z6tv MOTORIZR (Verizon)
Motorola CDMA	L7c SLVR
Motorola CDMA	L7c (Cellsouth)
Motorola CDMA	L7c (IL)
Motorola CDMA	Q9c
Motorola CDMA	Q9m
Motorola CDMA	V9m RAZR2 (Bell)
Motorola CDMA	V9m RAZR2(IL)
Motorola CDMA	V9m RAZR2 (Sprint)
Motorola CDMA	V9m MOTORAZR2 (Verizon)
Motorola CDMA	V9m RAZR2 (Alltel)
Motorola CDMA	VE20
Motorola CDMA	VE20 (USCellular)
Motorola CDMA	Mot. VE20 (Alltel)

Motorola CDMA	Mot. VE20 (CellSouth)
Motorola CDMA	AN30
Motorola CDMA	QA30 Hint (Alltel)
Motorola CDMA	QA30 Hint (CellSouth)
Motorola CDMA	QA30 Hint
Motorola CDMA	WX404
Motorola CDMA	QA30 Raspberry (Bell)
Motorola CDMA	QA30 Hint (UScellular)
Motorola CDMA	VU30 Rapture
Motorola CDMA	V.Series v60
Motorola CDMA	V.Series v60p
Motorola CDMA	V60v
Motorola CDMA	V65p
Motorola CDMA	V.Series v120
Motorola CDMA	V.Series v200
Motorola CDMA	VU204
Motorola CDMA	VE240
Motorola CDMA	v262
Motorola CDMA	v265
Motorola CDMA	Timeport 270c
Motorola CDMA	v276
Motorola CDMA	C290
Motorola CDMA	T300P
Motorola CDMA	E310
Motorola CDMA	W315
Motorola CDMA	V323
Motorola CDMA	V325
Motorola CDMA	V325xi
Motorola CDMA	V325i
Motorola CDMA	C333
Motorola CDMA	C341
Motorola CDMA	C343
Motorola CDMA	W385
Motorola CDMA	W385 (Boost)
Motorola CDMA	W385 (Verizon)
Motorola CDMA	ES400S (USB)
Motorola CDMA	ES400S (BT)
Motorola CDMA	WX400 Rambler
Motorola CDMA	WX430 Theory
Motorola CDMA	WX435 Triumph
Motorola CDMA	VE440
Motorola CDMA	WX445 Citrus
Motorola CDMA	A455 Rival
Motorola CDMA	VE465 (Alltel)
Motorola CDMA	VE465 (CellSouth)
Motorola CDMA	VE465 (Cricket)
Motorola CDMA	VE465 (Telus)
Motorola CDMA	MB512 Picasso
Motorola CDMA	XT536 Defy XT
Motorola CDMA	A555 Devour
Motorola CDMA	XT557D Defy
Motorola CDMA	XT603 Admiral
Motorola CDMA	MZ609 XYBoard 8.2
Motorola CDMA	XT553
Motorola CDMA	XT555C

Motorola CDMA	XT556
Motorola CDMA	XT609 Milestone Plus
Motorola CDMA	XT610 Droid Pro
Motorola CDMA	MB612 XPRT
Motorola CDMA	MZ617 XYBoard 10.1
Motorola CDMA	XT681 Moto
Motorola CDMA	V710
Motorola CDMA	T720
Motorola CDMA	T730
Motorola CDMA	V720 (IL)
Motorola CDMA	V750 Adventure (Telus)
Motorola CDMA	V750 Adventure
Motorola CDMA	W755
Motorola CDMA	W766 Entice
Motorola CDMA	XT788
Motorola CDMA	M800
Motorola CDMA	XT800+
Motorola CDMA	MB810 Droid X
Motorola CDMA	MB809 Milestone X
Motorola CDMA	V810
Motorola CDMA	E815
Motorola CDMA	E815 (IL)
Motorola CDMA	E816
Motorola CDMA	XT830C Moto E
Motorola CDMA	A840
Motorola CDMA	W840
Motorola CDMA	W845 (CellSouth)
Motorola CDMA	W845 (UScellular)
Motorola CDMA	W845 (MetroPCS)
Motorola CDMA	A854 Milestone
Motorola CDMA	A855 Droid
Motorola CDMA	MB853 Electrify
Motorola CDMA	MB855 Photon 4G
Motorola CDMA	XT855
Motorola CDMA	V860 Barage PTT
Motorola CDMA	XT861 Milestone 3
Motorola CDMA	XT862 Droid 3
Motorola CDMA	XT865 Droid Bionic
Motorola CDMA	MB867 Milestone X2
Motorola CDMA	MB870 Droid X2
Motorola CDMA	XT875 Droid Bionic
Motorola CDMA	XT881 Electrify 2
Motorola CDMA	MB886 Atrix HD LTE
Motorola CDMA	XT894 Droid 4
Motorola CDMA	XT897
Motorola CDMA	XT901 Solstice
Motorola CDMA	XT907 Droid RAZR M
Motorola CDMA	XT908 RAZR MAXX
Motorola CDMA	XT912 Droid RAZR
Motorola CDMA	XT912 Droid RAZR Maxx
Motorola CDMA	XT912M Droid RAZER MAXX
Motorola CDMA	XT926 Droid RAZR HD
Motorola CDMA	XT928
Motorola CDMA	A955 Droid 2
Motorola CDMA	A956 Droid 2 Global

Motorola CDMA	A957 R2D2
Motorola CDMA	V950 Renegade
Motorola CDMA	XT1019 Moto E
Motorola CDMA	XT1526 Moto E 2nd Gen
Motorola CDMA	XT1528 Moto E
Motorola CDMA	XT1548 Moto G
Motorola CDMA	XT1028 Moto G
Motorola CDMA	XT1030 Droid Mini
Motorola CDMA	XT1031 Moto G
Motorola CDMA	XT1607 Moto G Play
Motorola CDMA	XT1774 Moto G Play
Motorola CDMA	XT1031 Moto G [UScellular]
Motorola CDMA	XT1049 Moto X
Motorola CDMA	XT1055 Moto X
Motorola CDMA	XT1053 Moto X
Motorola CDMA	XT1056 Moto X
Motorola CDMA	XT1060 Moto X
Motorola CDMA	XT1650-01 Moto Z Droid
Motorola CDMA	XT1650-02 Moto Z Force
Motorola CDMA	XT1093 Moto X (2nd Gen)
Motorola CDMA	XT1096 Moto X
Motorola CDMA	Q
Motorola CDMA	Spirit CAR (C18)
Motorola CDMA	XT1080 Droid Ultra
Motorola CDMA	XT1080M Droid Ultra MAXX
Motorola CDMA	XT1103 Nexus 6
Motorola CDMA	XT1254 Droid Turbo
Motorola CDMA	XT1565 Droid Maxx 2
Motorola CDMA	XT1585 Droid Turbo 2
Motorola CDMA	XT1609 Moto G4 Play
Motorola CDMA	XT1635-01 Moto Z Play
Motorola CDMA	XT1701 Moto Z2 Play
Motorola CDMA	XT1765 Moto E
Motorola CDMA	XT1767 Moto E4
Motorola CDMA	XT1768 Moto E
Motorola CDMA	XT1775 Moto E4 Plus
Motorola CDMA	XT1789 Moto Z2 Force
Motorola CDMA	XT1929-4 Moto Z3 Play
Motorola CDMA	XT1924-7 Moto E5 Plus
Motorola GSM	Generic Android (Logical Bypassing Lock)
Motorola GSM	Generic Android (Logical ADB Normal(Recommended))
Motorola GSM	Aura
Motorola GSM	M03F Gleam+
Motorola GSM	MB220 Dext
Motorola GSM	Gleam
Motorola GSM	E1 ROKR
Motorola GSM	K1 KRZR
Motorola GSM	K1 (IL)
Motorola GSM	QA1
Motorola GSM	L2 SLVR
Motorola GSM	K3 Sumba
Motorola GSM	U3 PEBL
Motorola GSM	V3 RAZR
Motorola GSM	V3i
Motorola GSM	V3i (IL)

Motorola GSM	V3r RAZR
Motorola GSM	V3t RAZR
Motorola GSM	V3x
Motorola GSM	V3xx
Motorola GSM	Z3 RIZR
Motorola GSM	Z3 (Vivo)
Motorola GSM	W5 ROKR (USB)
Motorola GSM	W5 ROKR (BT)
Motorola GSM	ZN5 MOTOZINE
Motorola GSM	ZN5 (China Mobile)
Motorola GSM	NZ5X MOTOZINE
Motorola GSM	E6 ROKR
Motorola GSM	L6i iMode
Motorola GSM	L6 SLVR
Motorola GSM	U6 PEBL
Motorola GSM	V6 RAZR MAXX
Motorola GSM	Z6 ROKR
Motorola GSM	L7 SLVR
Motorola GSM	L7e RIZR
Motorola GSM	L7i iMode
Motorola GSM	E8 ROKR
Motorola GSM	Q8
Motorola GSM	V8 RAZR2
Motorola GSM	V8 Luxury
Motorola GSM	Z8
Motorola GSM	L9
Motorola GSM	Q9
Motorola GSM	Q9H
Motorola GSM	U9
Motorola GSM	U9 Jewel
Motorola GSM	V9
Motorola GSM	V9x
Motorola GSM	V9 Razr 2
Motorola GSM	Z9
Motorola GSM	Z10
Motorola GSM	Q11
Motorola GSM	EM25
Motorola GSM	EM28
Motorola GSM	EM30
Motorola GSM	V60
Motorola GSM	V66
Motorola GSM	VE66
Motorola GSM	V70
Motorola GSM	L71
Motorola GSM	VA76R Tundra
Motorola GSM	V80
Motorola GSM	EX211 Gleam
Motorola GSM	C113
Motorola GSM	C115
Motorola GSM	EX115 Starling
Motorola GSM	EX116 Motokey (USB)
Motorola GSM	EX116 Motokey (BT)
Motorola GSM	EX117
Motorola GSM	C117
Motorola GSM	C118

Motorola GSM	C119
Motorola GSM	EX122
Motorola GSM	EX124G
Motorola GSM	EX128
Motorola GSM	C139 (ATT)
Motorola GSM	C139 (TIM)
Motorola GSM	C140
Motorola GSM	V150
Motorola GSM	C168
Motorola GSM	V180
Motorola GSM	V186
Motorola GSM	V188
Motorola GSM	WX181
Motorola GSM	W419G
Motorola GSM	T191
Motorola GSM	V190
Motorola GSM	V191
Motorola GSM	XT2025-2 Moto E6s
Motorola GSM	XT2041-1 Moto g8 Power
Motorola GSM	XT1941-3_DS One
Motorola GSM	XT2055-2_DS Moto G8 Power Lite
Motorola GSM	XT2019-1 Moto G8 Plus
Motorola GSM	XT2013-4 One Action
Motorola GSM	XT2041-1 Moto G8 Power
Motorola GSM	XT2016-2 One Macro
Motorola GSM	XT2013-2 One Action
Motorola GSM	XT1970-3 One Vision
Motorola GSM	XT2029-1_DS E6 Play
Motorola GSM	XT2027-1 One Hyper
Motorola GSM	XT2019-2 Moto G8 Plus
Motorola GSM	XT1922-3_DS Moto G6 Play
Motorola GSM	V195
Motorola GSM	V197
Motorola GSM	MB200 CLIQ
Motorola GSM	MPx220
Motorola GSM	ZN200
Motorola GSM	201M(RAZR M)
Motorola GSM	V220
Motorola GSM	W220
Motorola GSM	W233
Motorola GSM	V235
Motorola GSM	C250
Motorola GSM	C260
Motorola GSM	V270
Motorola GSM	V280
Motorola GSM	WX290
Motorola GSM	WX295
Motorola GSM	MB300 Backflip
Motorola GSM	MB300 Enzo
Motorola GSM	V300
Motorola GSM	XT300 Spice
Motorola GSM	XT303 MotoSmart Me
Motorola GSM	XT311 Fire
Motorola GSM	XT319
Motorola GSM	XT320 Defy Mini

Motorola GSM	EM325
Motorola GSM	EM326g
Motorola GSM	C330
Motorola GSM	C33x
Motorola GSM	EM330
Motorola GSM	V330
Motorola GSM	C350
Motorola GSM	V360
Motorola GSM	V365
Motorola GSM	C370
Motorola GSM	W377
Motorola GSM	E378
Motorola GSM	C380
Motorola GSM	E380
Motorola GSM	C390
Motorola GSM	XT390
Motorola GSM	WX395
Motorola GSM	E398
Motorola GSM	ES400
Motorola GSM	V400
Motorola GSM	W409G
Motorola GSM	WX416CH Go Flip
Motorola GSM	EX431G
Motorola GSM	C450
Motorola GSM	W450 MOTOACTV
Motorola GSM	W490
Motorola GSM	V500
Motorola GSM	V505
Motorola GSM	MB501 CLIQ XT
Motorola GSM	MB501 QUENCH
Motorola GSM	XT5
Motorola GSM	MB502 Charm
Motorola GSM	XT502 XT3 Quench
Motorola GSM	MB508 FlipSide
Motorola GSM	W510
Motorola GSM	MB511 FlipOut (O2)
Motorola GSM	MB511 FlipOut
Motorola GSM	MB520 Diablo
Motorola GSM	MB525 Defy
Motorola GSM	ME525+ Defy
Motorola GSM	MB526 Defy+
Motorola GSM	V525
Motorola GSM	V535
Motorola GSM	XT535 Defy
Motorola GSM	VE538
Motorola GSM	V540
Motorola GSM	V545
Motorola GSM	V547
Motorola GSM	C550
Motorola GSM	E550
Motorola GSM	V550
Motorola GSM	V551
Motorola GSM	V555
Motorola GSM	V557
Motorola GSM	V600

Motorola GSM	V620
Motorola GSM	V635L
Motorola GSM	MZ601 XOOM
Motorola GSM	XT530 Fire XT
Motorola GSM	XT531 Spice XT
Motorola GSM	XT532
Motorola GSM	XT550 Motosmart MIX
Motorola GSM	XT560
Motorola GSM	XT605 Master
Motorola GSM	MB611 Cliq 2
Motorola GSM	XT615
Motorola GSM	XT615 Motoluxe
Motorola GSM	XT621
Motorola GSM	XT621 Ferrari
Motorola GSM	XT627 Kairos
Motorola GSM	XT626 Iron Rock
Motorola GSM	A630
Motorola GSM	C650
Motorola GSM	C651
Motorola GSM	XT702
Motorola GSM	MT716
Motorola GSM	XT720 Milestone
Motorola GSM	T720
Motorola GSM	T720i
Motorola GSM	T722i
Motorola GSM	E770
Motorola GSM	XT800
Motorola GSM	A835
Motorola GSM	A845
Motorola GSM	A853 MILESTONE
Motorola GSM	Fake I867 Ferrari
Motorola GSM	XT885 RAZR V
Motorola GSM	XT886 Razr V
Motorola GSM	XT890 RAZR I
Motorola GSM	A953 Milestone 2
Motorola GSM	MB860 Atrix 4G
Motorola GSM	MB865 Atrix 2
Motorola GSM	ME865 Atrix 2
Motorola GSM	MB886 Atrix HD
Motorola GSM	XT908 Milestone MAXX
Motorola GSM	XT909
Motorola GSM	XT910 Spyder RAZR
Motorola GSM	XT915 RAZR D1
Motorola GSM	XT919 RAZR D3
Motorola GSM	XT925 RAZR
Motorola GSM	XT926 DROID RAZR HD
Motorola GSM	M900
Motorola GSM	M930 Spirit
Motorola GSM	C975
Motorola GSM	V975
Motorola GSM	C980
Motorola GSM	V980
Motorola GSM	M990
Motorola GSM	E1000
Motorola GSM	XT1003 Moto G Ferrari Edition

Motorola GSM	XT1008 Moto G Forte
Motorola GSM	XT1019 Moto E
Motorola GSM	XT1021 Moto E
Motorola GSM	XT1022 Moto E
Motorola GSM	XT1023 Moto E
Motorola GSM	XT1032 Moto G
Motorola GSM	XT1033 Moto G Dual
Motorola GSM	XT1565B Droid Maxx 2
Motorola GSM	XT1557 Moto G Turbo
Motorola GSM	XT1032Z Moto G
Motorola GSM	XT1034 Moto G
Motorola GSM	XT1040 Moto G
Motorola GSM	XT1039 Moto G
Motorola GSM	XT1045 Moto G
Motorola GSM	XT1068 Moto G
Motorola GSM	XT1700 Moto E3
Motorola GSM	XT1710-02 Moto Z2 Play
Motorola GSM	XT1723 Moto C Plus
Motorola GSM	XT1726 Moto C Plus
Motorola GSM	XT1754 Moto C
Motorola GSM	XT1944-4_DS Moto E5
Motorola GSM	XT2015-2 Moto G8 Play
Motorola GSM	XT2025-1 Moto E6 Plus
Motorola GSM	XT1920-15 Moto E5 Play
Motorola GSM	XT1925-12 Motorola G6
Motorola GSM	XT1980-4 Moto Z4
Motorola GSM	XT1925-5_DS Motorola Moto G6
Motorola GSM	XT1925-13_DS Moto G6
Motorola GSM	XT1970-1 One Vision
Motorola GSM	XT1662 Moto M
Motorola GSM	XT1965-3_DS Moto G7 Plus
Motorola GSM	XT1965-2_DS Moto G7 Plus
Motorola GSM	XT1962-4_DS Moto G7
Motorola GSM	XT1922-6 Moto G6 Play
Motorola GSM	XT1926-7_DS Moto G6 Plus
Motorola GSM	XT1097 Moto X 2nd Gen
Motorola GSM	XT1761 Moto E4
Motorola GSM	T1926-6 Moto G6 Plus
Motorola GSM	XT1952-2 Moto G7 Play
Motorola GSM	XT1955-2 Moto g7 Power
Motorola GSM	XT2010-1 One Zoom
Motorola GSM	XT1929-6 Moto Z3 Play
Motorola GSM	XT1955-4_DS Moto G7 Power
Motorola GSM	XT1762 Moto E4
Motorola GSM	XT1766 Moto E4
Motorola GSM	XT1920DL Moto E5 TracFone
Motorola GSM	XT1921-2 Moto E5 Cruise
Motorola GSM	V1050
Motorola GSM	XT1055 Moto X
Motorola GSM	XT1058 Moto X
Motorola GSM	E1070
Motorola GSM	V1100
Motorola GSM	XT1053 Moto X
Motorola GSM	XT1625 Moto G4
Motorola GSM	LEX L10ig

Motorola GSM	XT1063 Moto G
Motorola GSM	XT1115 Moto X Pro
Motorola GSM	XT1621 Moto G4
Motorola GSM	XT1622 Moto G4
Motorola GSM	XT1626 Moto G4
Motorola GSM	XT1635-02 Moto Z Play
Motorola GSM	XT1601
Motorola GSM	XT1640 Moto G4 Plus Dual
Motorola GSM	XT1641 Moto G4 Plus
Motorola GSM	XT1642 Moto G4 Plus
Motorola GSM	XT1644 Moto G4 Plus
Motorola GSM	XT1670 Moto G5
Motorola GSM	XT1672 G5
Motorola GSM	XT1675 Moto G5
Motorola GSM	XT1676 Moto G5
Motorola GSM	XT1671 Moto G5
Motorola GSM	XT1680 Moto G5 Plus
Motorola GSM	XT1681 Moto G5 Plus
Motorola GSM	XT1683 Moto G5
Motorola GSM	XT1684 Moto G5 Plus
Motorola GSM	XT1685 Moto G5 Plus
Motorola GSM	XT1686 Moto G5
Motorola GSM	XT1687 Moto G5 Plus
Motorola GSM	XT1064 Moto G 2nd Gen
Motorola GSM	XT1072 Moto G 2nd gen
Motorola GSM	XT1900-1 Moto X4
Motorola GSM	XT1925DL Moto g6 Prepaid
Motorola GSM	XT1925-6 Moto G6
Motorola GSM	XT1900-2 Moto X4
Motorola GSM	XT1085 Moto X 2nd Gen
Motorola GSM	XT1092 Moto X 2nd Gen
Motorola GSM	XT1100 Nexus 6
Motorola GSM	XT1103 Nexus 6
Motorola GSM	A1200
Motorola GSM	XT1255 Moto Maxx
Motorola GSM	A1600
Motorola GSM	XT1514 Moto E 2nd Gen Dual
Motorola GSM	XT1078 Moto E 2nd Gen Dual
Motorola GSM	XT1524 Moto E 2nd Gen
Motorola GSM	XT1526 Moto E 2nd Gen
Motorola GSM	XT1527 Moto E 2nd Gen
Motorola GSM	XT1540 Moto G 3rd Gen
Motorola GSM	XT1541 Moto G 3rd Gen
Motorola GSM	XT1542 Moto G 3rd gen
Motorola GSM	XT1543 Moto G 3rd Gen
Motorola GSM	XT1550 Moto G 3rd Gen
Motorola GSM	XT1650-03 Moto Z
Motorola GSM	XT1770 Moto E4 Plus
Motorola GSM	XT1771 Moto E4 Plus
Motorola GSM	XT1772 Moto E4 Plus
Motorola GSM	XT1776 Moto E4 Plus
Motorola GSM	XT1789 Moto Z2 Force
Motorola GSM	XT1793 Moto G5S
Motorola GSM	XT1802 Moto G5S Plus
Motorola GSM	XT1805 Moto G5S Plus

Motorola GSM	XT1806 Moto G5S Plus
Motorola GSM	Moto G6
Motorola GSM	XT1926-9 Moto G6 Plus
Motorola GSM	Moto G Play
Motorola GSM	XT1922 Moto G Play
Motorola GSM	XT1941-2 Moto P30 Play
Motorola GSM	XT1941-4 One
Motorola GSM	XT1942-1 Moto P30 Note
Motorola GSM	XT1922-9 G6
Motorola GSM	XT1922-9 G6 Play
Motorola GSM	XT1922-5 G6 Play
Motorola GSM	XT-1929-17 Moto Z3
Motorola GSM	XT1924-6 Moto E5 Plus
Motorola GSM	XT1921-1 Moto e5 Play
Motorola GSM	XT1921-2 Moto e5 Play
Motorola GSM	XT1580 Moto X Force
Motorola GSM	XT1562 Moto X Play
Motorola GSM	XT1563 Moto X Play
Motorola GSM	XT1572 Moto X Style
Motorola GSM	XT1575 Moto X Style
Motorola GSM	XT1575 Moto X Pure
Motorola GSM	XT1921-3 Moto E5 Play
Motorola GSM	XT1921-6 Moto E5 Play
Motorola GSM	XT1920-19 Moto E5 Play
Motorola GSM	XT1921-5 Moto E5 Play
Motorola iDen	Generic Android
Motorola iDen	i1
Motorola iDen	i1x Titanium
Motorola iDen	i9 Stature
Motorola iDen	i30sx
Motorola iDen	i35
Motorola iDen	i55
Motorola iDen	i60c
Motorola iDen	i80
Motorola iDen	i85
Motorola iDen	i90c
Motorola iDen	i95cl
Motorola iDen	i205
Motorola iDen	i215
Motorola iDen	i275
Motorola iDen	i265
Motorola iDen	i285
Motorola iDen	i290
Motorola iDen	i296
Motorola iDen	i305
Motorola iDen	i315
Motorola iDen	i325
Motorola iDen	i335
Motorola iDen	i355
Motorola iDen	i365
Motorola iDen	ic402 Blend (IL)
Motorola iDen	ic402 Blend
Motorola iDen	i410
Motorola iDen	i412
Motorola iDen	i415

Motorola iDen	i425
Motorola iDen	i450
Motorola iDen	i455
Motorola iDen	i460
Motorola iDen	i465 Clutch
Motorola iDen	i475 Clutch+
Motorola iDen	ic502 Buzz (IL)
Motorola iDen	ic502 Buzz
Motorola iDen	i530
Motorola iDen	i560
Motorola iDen	i570
Motorola iDen	i576
Motorola iDen	i580
Motorola iDen	ic602 Buzz+
Motorola iDen	XT626
Motorola iDen	XT627
Motorola iDen	i650
Motorola iDen	i670
Motorola iDen	i680 Submerge
Motorola iDen	i686 Brute
Motorola iDen	i730
Motorola iDen	i733
Motorola iDen	i760
Motorola iDen	i776
Motorola iDen	i830
Motorola iDen	i833
Motorola iDen	i835
Motorola iDen	i836
Motorola iDen	i850
Motorola iDen	i855
Motorola iDen	i856 Debut
Motorola iDen	i867
Motorola iDen	i890
Motorola iDen	i860
Motorola iDen	i870
Motorola iDen	i876
Motorola iDen	i877
Motorola iDen	i880
Motorola iDen	i885
Motorola iDen	i886
Motorola iDen	ic902 Deluxe
Motorola iDen	i940
MyPhone	1065 Spectrum
MyPhone	IP67 Hammer
MyPhone	myPhone 3310
MyPhone	Luna II
MyPhone	Fun 5
MyPhone	Cube
Myria	MY9004_DS Myria Grand
Myria	MY9039_DS Myria Five
Myria	MY9076_DS L500
Myria	MY9078_DS Myria L600
Myria	Brand MY9053_DS Myria Wide 2
NEC	N411i
NEC	NE-201A1A

NEC	N-05E Medias W
NEC	N-06E MEDIAS X
NTT Docomo	iPhone 5S (USB cable)
NTT Docomo	iPhone 5S (Bluetooth (fast phonebook))
NTT Docomo	iPhone 5C (USB cable)
NTT Docomo	iPhone 5C (Bluetooth (fast phonebook))
NTT Docomo	iPad Air (GSM)
NTT Docomo	iPad mini
NTT Docomo	Memory Card
NTT Docomo	D704i
NTT Docomo	F702iD
NTT Docomo	F801i
NTT Docomo	N901iC
NTT Docomo	P-01A
NTT Docomo	SH700i
NTT Docomo	P904i
NTT Docomo	SH-01B
NTT Docomo	P903iTV
NTT Docomo	F900i
NTT Docomo	SH702iD
NTT Docomo	N904i
NTT Docomo	N706i2
NTT Docomo	P902i
NTT Docomo	N900iG
NTT Docomo	D905i
NTT Docomo	SA702i
NTT Docomo	D705i
NTT Docomo	F884i
NTT Docomo	SH704i
NTT Docomo	P706iu
NTT Docomo	P704iu
NTT Docomo	SO706i
NTT Docomo	N704iu
NTT Docomo	SO905i
NTT Docomo	SH906i
NTT Docomo	P903iX HIGH-SPEED
NTT Docomo	P703i
NTT Docomo	F900iT
NTT Docomo	F902i
NTT Docomo	P905i
NTT Docomo	P901i
NTT Docomo	F705i
NTT Docomo	F700iS
NTT Docomo	N701i ECO
NTT Docomo	SH902iSL(DOLCE SL)
NTT Docomo	SH903i
NTT Docomo	D702iF
NTT Docomo	D904i
NTT Docomo	SH904i
NTT Docomo	SH905i
NTT Docomo	SH905iTV
NTT Docomo	SH906iTV
NTT Docomo	F904i
NTT Docomo	F906i
NTT Docomo	F-01A

NTT Docomo	N905i
NTT Docomo	N905iu
NTT Docomo	SO905iCS
NTT Docomo	SH705i
NTT Docomo	SH705i2
NTT Docomo	SH706i
NTT Docomo	N705i
NTT Docomo	N705iu
NTT Docomo	D705iu
NTT Docomo	P704i
NTT Docomo	P705iu
NTT Docomo	F704i
NTT Docomo	F706i
NTT Docomo	SO704i
NTT Docomo	SO705i
NTT Docomo	SH903iTV
NTT Docomo	SO903iTV
NTT Docomo	P903i
NTT Docomo	D903i
NTT Docomo	D903iTV
NTT Docomo	F903i
NTT Docomo	F903iX HIGH-SPEED
NTT Docomo	N903i
NTT Docomo	F902iS
NTT Docomo	D902i
NTT Docomo	D902iS
NTT Docomo	P902iS
NTT Docomo	N902iS
NTT Docomo	N902i
NTT Docomo	SH902i
NTT Docomo	N902iX HIGH-SPEED
NTT Docomo	P706ie
NTT Docomo	SH706iw
NTT Docomo	SH902iS
NTT Docomo	SH703i
NTT Docomo	F703i
NTT Docomo	SO703i
NTT Docomo	N703iD
NTT Docomo	P703iu
NTT Docomo	D703i
NTT Docomo	N703iu
NTT Docomo	N706i
NTT Docomo	P-09A
NTT Docomo	N702iS
NTT Docomo	D702i
NTT Docomo	N702iD
NTT Docomo	SH702iS
NTT Docomo	N706ie
NTT Docomo	P702i
NTT Docomo	P702iD
NTT Docomo	N901iS
NTT Docomo	D851iWM
NTT Docomo	D901i
NTT Docomo	SA800i
NTT Docomo	F884iES

NTT Docomo	F901iS
NTT Docomo	F901iC
NTT Docomo	P900iV
NTT Docomo	P901iTV
NTT Docomo	P851i(PRO SOLID2)
NTT Docomo	P901iS
NTT Docomo	P900i
NTT Docomo	D901iS
NTT Docomo	D800iDS
NTT Docomo	SH706ie
NTT Docomo	SH700iS
NTT Docomo	F700i
NTT Docomo	D701i
NTT Docomo	D701iWM
NTT Docomo	N700i
NTT Docomo	N701i
NTT Docomo	P700i
NTT Docomo	P701iD
NTT Docomo	SA700iS
NTT Docomo	SH-01A
NTT Docomo	SH-04A
NTT Docomo	N906i
NTT Docomo	N-01A
NTT Docomo	F-03A
NTT Docomo	P905iTV
NTT Docomo	SO906i
NTT Docomo	P-02A
NTT Docomo	P906i
NTT Docomo	F-09A
NTT Docomo	F905i
NTT Docomo	N906iu
NTT Docomo	P705i
NTT Docomo	P705iCL(PRO SOLIDu)
NTT Docomo	SH-02A
NTT Docomo	SH-07A
NTT Docomo	SH-08A
NTT Docomo	SH-02B(marimekko)
NTT Docomo	SH-03B
NTT Docomo	SH-05B
NTT Docomo	SH-04B
NTT Docomo	SH-03A
NTT Docomo	SH-06A
NTT Docomo	SH-05A
NTT Docomo	F-02A
NTT Docomo	F-02E(Arrows X)
NTT Docomo	F-04A
NTT Docomo	F-05A
NTT Docomo	P-04A
NTT Docomo	F-07A
NTT Docomo	F-08A
NTT Docomo	F-10A
NTT Docomo	F-02B
NTT Docomo	F-03B
NTT Docomo	F-01B
NTT Docomo	P-02B

NTT Docomo	P-03A
NTT Docomo	P-10A
NTT Docomo	P-03B
NTT Docomo	P-08A
NTT Docomo	P-07A
NTT Docomo	P-06A
NTT Docomo	P-05A
NTT Docomo	N-06A
NTT Docomo	N-07A
NTT Docomo	N-05A
NTT Docomo	N-04A
NTT Docomo	N-08A
NTT Docomo	N-09A
NTT Docomo	N-03B
NTT Docomo	N-02A
NTT Docomo	N906iL onefone
NTT Docomo	N-03A
NTT Docomo	F883iS
NTT Docomo	F883iESS
NTT Docomo	P-01B
NTT Docomo	HT-01A
NTT Docomo	HT-02A
NTT Docomo	HT-03A
NTT Docomo	NM705i (No Client)
NTT Docomo	NM706i (No Client)
NTT Docomo	NM850iG (No Client)
NTT Docomo	Blackberry 9000 Bold
NTT Docomo	N-06B
NTT Docomo	P-04B
NTT Docomo	SH-06B
NTT Docomo	SH-07B
NTT Docomo	SH-08B
NTT Docomo	N900i
NTT Docomo	N900iS
NTT Docomo	SH901iS
NTT Docomo	SH901iC
NTT Docomo	SO903i
NTT Docomo	F880iES
NTT Docomo	F881iES
NTT Docomo	F882iES
NTT Docomo	F883i
NTT Docomo	F883iES
NTT Docomo	SH851i(DOLCE)
NTT Docomo	N601i(SIMPURE N1)
NTT Docomo	F-04B
NTT Docomo	SO-01B(Xperia)
NTT Docomo	T-01A
NTT Docomo	SC-01B
NTT Docomo	T-01B(dynapocket)
NTT Docomo	P-05B
NTT Docomo	F-06B
NTT Docomo	F-07B
NTT Docomo	F-08B
NTT Docomo	P-06B
NTT Docomo	SH-09B

NTT Docomo	Blackberry 8707h
NTT Docomo	HT1100
NTT Docomo	N-01B
NTT Docomo	N-02B
NTT Docomo	N-04B
NTT Docomo	N-05B
NTT Docomo	N-07B
NTT Docomo	N-08B
NTT Docomo	L705i
NTT Docomo	L705iX
NTT Docomo	L706ie
NTT Docomo	L704i
NTT Docomo	L852i(PRADA)
NTT Docomo	L-01A
NTT Docomo	L-03A
NTT Docomo	P-07B
NTT Docomo	P-01C
NTT Docomo	P-02C
NTT Docomo	F-09B
NTT Docomo	F-01C
NTT Docomo	F-02C
NTT Docomo	F-03C
NTT Docomo	N-01C
NTT Docomo	N-02C
NTT Docomo	SH-01C
NTT Docomo	SH-02C
NTT Docomo	SH-04C
NTT Docomo	BlackBerry 9700 Bold
NTT Docomo	BlackBerry 9300 Curve
NTT Docomo	SH-10B(LYNX)
NTT Docomo	SH-03C(LYNX 3D)
NTT Docomo	SC-01C Galaxy Tab
NTT Docomo	SC-01E(Galaxy Tab 7.7 Plus)
NTT Docomo	SC-02B (Galaxy S)
NTT Docomo	T-01C(REGZA)
NTT Docomo	F-04C
NTT Docomo	SH-05C
NTT Docomo	N-03C
NTT Docomo	P-03C
NTT Docomo	L-04A
NTT Docomo	L-06A
NTT Docomo	L-01B
NTT Docomo	L-02B
NTT Docomo	L-03B
NTT Docomo	L-04B
NTT Docomo	L-01C
NTT Docomo	L-03C
NTT Docomo	F-05C
NTT Docomo	F-08C
NTT Docomo	SH-06C
NTT Docomo	L-04C(Optimus chat)
NTT Docomo	SO-01C Xperia arc
NTT Docomo	F-09C
NTT Docomo	F-10C
NTT Docomo	F-11C

NTT Docomo	N-05C
NTT Docomo	CA-01C
NTT Docomo	P-04C
NTT Docomo	P-05C
NTT Docomo	P-06C
NTT Docomo	SH-08C(TOUCH WOOD)
NTT Docomo	SH-09C
NTT Docomo	SH-10C
NTT Docomo	SH-11C
NTT Docomo	BlackBerry 9780 Bold
NTT Docomo	L-07C(Optimus bright)
NTT Docomo	N-04C(MEDIAS)
NTT Docomo	N-06C(MEDIAS WP)
NTT Docomo	SH-12C
NTT Docomo	SO-02C(Xperia acro)
NTT Docomo	SC-02C(GALAXY S2)
NTT Docomo	F-02D
NTT Docomo	F-04D
NTT Docomo	F-06D
NTT Docomo	N-02D
NTT Docomo	N-03D
NTT Docomo	P-03D
NTT Docomo	SH-03D
NTT Docomo	L-10C
NTT Docomo	F-12C
NTT Docomo	F-01D(ARROWS Tab LTE)
NTT Docomo	F-03D(ARROWS kiss)
NTT Docomo	F-03D Girls'
NTT Docomo	F-05D(ARROWS X LTE)
NTT Docomo	F-07D(ARROWS Micro)
NTT Docomo	N-01D(MEDIAS PP)
NTT Docomo	P-07C
NTT Docomo	P-01D
NTT Docomo	P-02D(LUMIX Phone)
NTT Docomo	SH-13C
NTT Docomo	SH-01D
NTT Docomo	SH-02D
NTT Docomo	SO-03C(XperiaTM ray)
NTT Docomo	SO-01D(XperiaTM PLAY)
NTT Docomo	T-01D(REGZA Phone)
NTT Docomo	SC-03D(GALAXY S2 LTE)
NTT Docomo	SC-04D(GALAXY NEXUS)
NTT Docomo	SH-05D
NTT Docomo	N-04D(MEDIAS LTE)
NTT Docomo	SH-04D (Q-pot.Phone)
NTT Docomo	L-01D(Optimus LTE)
NTT Docomo	L-02D(PRADA phone)
NTT Docomo	SO-02D(XperiaTM NX)
NTT Docomo	SO-03D Xperia acro HD
NTT Docomo	F-08D(Disney Mobile)
NTT Docomo	P-05D(Disney Mobile)
NTT Docomo	P-04D(Next series)
NTT Docomo	N-05D(MEDIAS ES)
NTT Docomo	N-06D(MEDIAS Tab)
NTT Docomo	BlackBerry 9900 Bold

NTT Docomo	SH-06D
NTT Docomo	L-05D(Optimus it)
NTT Docomo	SC-05D GALAXY NOTE
NTT Docomo	SC-06D(GALAXY SIII)
NTT Docomo	F-09D(ANTEPRIMA)
NTT Docomo	SH-07D
NTT Docomo	F-10D
NTT Docomo	F-11D
NTT Docomo	F-12D
NTT Docomo	P-06D(ELUGA)
NTT Docomo	P-07D
NTT Docomo	SO-04D
NTT Docomo	SO-05D
NTT Docomo	T-02D
NTT Docomo	L-06D
NTT Docomo	N-07D MEDIAS
NTT Docomo	N-08D Medias Tab UL
NTT Docomo	P-08D Eluga
NTT Docomo	SH-10D
NTT Docomo	SH-01E
NTT Docomo	L-01E
NTT Docomo	F-04E Arrows V
NTT Docomo	F-03E
NTT Docomo	F-05E
NTT Docomo	N-02E
NTT Docomo	N-03E
NTT Docomo	SH-02E
NTT Docomo	L-02E
NTT Docomo	SO-01E
NTT Docomo	SO-02E(Xperia Z)
NTT Docomo	P-02E Eluga
NTT Docomo	N-05E
NTT Docomo	SH-04E
NTT Docomo	SC-02E(GALAXY NOTE II)
NTT Docomo	SC-03E(GALAXY SIII Alfa)
NTT Docomo	L-04E
NTT Docomo	SO-03E
NTT Docomo	HW-01E Ascend
NTT Docomo	F-10B
NTT Docomo	F-01E
NTT Docomo	N-01E
NTT Docomo	P-01E
NTT Docomo	SH-03E
NTT Docomo	SC-04E Galaxy S IV
NTT Docomo	SH-05E
NTT Docomo	SH-06E(AQUOS PHONE ZETA)
NTT Docomo	SH-07E(AQUOS PHONE si)
NTT Docomo	SH-08E(AQUOS PAD)
NTT Docomo	SO-04E(Xperia A)
NTT Docomo	N-06E(MEDIAS X)
NTT Docomo	P-03E(ELUGA P)
NTT Docomo	SH-06D NERV
NTT Docomo	SH-09D
NTT Docomo	HW-03E
NTT Docomo	N-04E

NTT Docomo	F-06E(ARROWS NX)
NTT Docomo	F-07E(Disney Mobile)
NTT Docomo	F-08E
NTT Docomo	L-05E(Optimus it)
NTT Docomo	F-01F
NTT Docomo	F-02F(ARROWS Tab)
NTT Docomo	N-01F
NTT Docomo	P-01F
NTT Docomo	SH-01F
NTT Docomo	L-01F G2
NTT Docomo	SO-01F(Xperia Z1)
NTT Docomo	SC-01F(GALAXY Note3)
NTT Docomo	SC-02F(GALAXY J)
NTT Docomo	F-09E
NTT Docomo	F-03F(Disney)
NTT Docomo	F-04F(ARROWS NX)
NTT Docomo	SO-02F(Xperia Z1f)
NTT Docomo	SC-01D (GALAXY Tab 10.1 LTE)
NTT Docomo	Fujitsu F-05F Arrows NX
NTT Docomo	SH-04F(AQUOS ZETA)
NTT Docomo	SH-05F
NTT Docomo	SO-03F(Xperia Z2)
NTT Docomo	SC-04F(GALAXY S5)
NTT Docomo	SH-02F(AQUOS PHONE EX)
NTT Docomo	F-06F
NTT Docomo	SH-06F
NTT Docomo	SO-04F(Xperia A2)
NTT Docomo	SO-05F(Xperia Z2 Tablet)
NTT Docomo	iPhone 6
NTT Docomo	iPhone 6 Plus
NTT Docomo	SO-01G
NTT Docomo	SC-01G Galaxy Note Edge
NTT Docomo	SC-02G(GALAXY S5)
NTT Docomo	SH-03F
NTT Docomo	SH-01G (AQUOS ZETA)
NTT Docomo	SH-02G
NTT Docomo	SO-02G
NTT Docomo	SC-03G
NTT Docomo	F-07F
NTT Docomo	F-01G
NTT Docomo	F-05G
NTT Docomo	SO-03G (Xperia Z4)
NTT Docomo	SO-04G (Xperia A4)
NTT Docomo	SO-05G (Xperia Z4 Tablet)
NTT Docomo	SH-04G (AQUOS EVER)
NTT Docomo	SH-05G (AQUOS PAD)
NTT Docomo	F-08F
NTT Docomo	D-01G (dtab)
NTT Docomo	F-04G (Arrows NX)
NTT Docomo	SC-04G (Galaxy S6 Edge)
NTT Docomo	SC-05G (Galaxy S6)
NTT Docomo	SH-03G AQUOS ZETA
NTT Docomo	iPhone 6s
NTT Docomo	iPhone 6s Plus
NTT Docomo	iPhone SE

NTT Docomo	iPhone 7
NTT Docomo	iPhone 7 Plus
NTT Docomo	L-06C
NTT Docomo	F-03G (ARROWS Tab)
NTT Docomo	DM-01G
NTT Docomo	SH-01H (AQUOS ZETA)
NTT Docomo	SO-01H (Xperia Z5)
NTT Docomo	SO-02H (Xperia Z5 Compact)
NTT Docomo	SO-03H (Xperia Z5 Premium)
NTT Docomo	SC-01H (Galaxy Active neo)
NTT Docomo	F-02H (arrows NX)
NTT Docomo	d-02H (dtab Compact)
NTT Docomo	DM-01H
NTT Docomo	P-01G
NTT Docomo	P-01H
NTT Docomo	N-01G
NTT Docomo	DM-02H
NTT Docomo	F-03H(arrows SV)
NTT Docomo	P-01J
NTT Docomo	SH-01J
NTT Docomo	SO-04H(Xperia X Performance)
NTT Docomo	SO-02G Xperia Z3 Compact
NTT Docomo	SC-02H (Galaxy S7 edge)
NTT Docomo	F-04H(arrows Tab)
NTT Docomo	SO-01J(Xperia XZ)
NTT Docomo	SO-02J(Xperia X Compact)
NTT Docomo	SO-03J(Xperia XZs)
NTT Docomo	SO-04J(Xperia XZ Premium)
NTT Docomo	F-01J(arrows NX)
NTT Docomo	F-02J
NTT Docomo	F-04J
NTT Docomo	F-05J(arrows Be)
NTT Docomo	SH-02J(AQUOS EVER)
NTT Docomo	SH-03J(AQUOS R)
NTT Docomo	DM-01J
NTT Docomo	SC-02J(Galaxy S8)
NTT Docomo	SC-03J(Galaxy S8+)
NTT Docomo	SC-04J(Galaxy Feel)
NTT Docomo	L-01J(V20 PRO)
NTT Docomo	MO-01J(MONO)
NTT Docomo	SC-01K(Galaxy Note8)
NTT Docomo	SO-01K(Xperia XZ1)
NTT Docomo	SO-02K(Xperia XZ1 Compact)
NTT Docomo	SH-01K(AQUOS sense)
NTT Docomo	MO-01K
NTT Docomo	SC-02K(Galaxy S9)
NTT Docomo	SC-03K(Galaxy S9+)
NTT Docomo	SO-03K(Xperia XZ2)
NTT Docomo	SO-04K(Xperia XZ2 Premium)
NTT Docomo	F-02L arrows Be3
NTT Docomo	SO-05K(Xperia XZ2 Compact)
NTT Docomo	L-01K(V30+)
NTT Docomo	L-03K(LG style)
NTT Docomo	DM-01K
NTT Docomo	F-01K(arrows NX)

NTT Docomo	F-03K
NTT Docomo	F-04K(arrows Be)
NTT Docomo	SH-03K(AQUOS R2)
NTT Docomo	M Z-01K
NTT Docomo	HW-01K(P20 Pro)
NYX	Orbis
NYX	Join
Nextel	V V.45
NiU	Generic Android
NiU	4D2 Tek 4D2
NiU	AC4E3I043 Andy 4E
NiU	TC5DI043 Tek 5D
NiU	Andy 5.5E
Nokia CDMA	610C (USB)
Nokia CDMA	610C (BT)
Nokia CDMA	Lumia 822 (RM-845) (USB)
Nokia CDMA	Lumia 822 (RM-845) (BT)
Nokia CDMA	Lumia 928 (RM-860) (USB)
Nokia CDMA	Lumia 928 (RM-860) (BT)
Nokia CDMA	Lumia 929 (RM-927) (USB)
Nokia CDMA	Lumia 929 (RM-927) (BT)
Nokia CDMA	Lumia 635 (RM-1078) (USB)
Nokia CDMA	Lumia 635 (RM-1078) (BT)
Nokia CDMA	1006
Nokia CDMA	1606
Nokia CDMA	2112
Nokia CDMA	2116
Nokia CDMA	2118
Nokia CDMA	2125i
Nokia CDMA	2126
Nokia CDMA	2126i
Nokia CDMA	2128
Nokia CDMA	2135
Nokia CDMA	2270
Nokia CDMA	2275
Nokia CDMA	2280
Nokia CDMA	2285
Nokia CDMA	2366
Nokia CDMA	2605 Mirage
Nokia CDMA	2705 Shade
Nokia CDMA	2855i
Nokia CDMA	2865i
Nokia CDMA	3105
Nokia CDMA	3125
Nokia CDMA	3155
Nokia CDMA	3205
Nokia CDMA	3280
Nokia CDMA	3285
Nokia CDMA	3570
Nokia CDMA	3585
Nokia CDMA	3585i
Nokia CDMA	3586i
Nokia CDMA	3587i
Nokia CDMA	3588
Nokia CDMA	3589i

Nokia CDMA	3606
Nokia CDMA	5170
Nokia CDMA	5180
Nokia CDMA	5185
Nokia CDMA	6012
Nokia CDMA	6015i
Nokia CDMA	6016
Nokia CDMA	6019
Nokia CDMA	6016i (Sprint)
Nokia CDMA	6155
Nokia CDMA	6165i
Nokia CDMA	6185
Nokia CDMA	6188
Nokia CDMA	6205
Nokia CDMA	6215i
Nokia CDMA	6225
Nokia CDMA	6225(Sprint)
Nokia CDMA	6235
Nokia CDMA	6236i
Nokia CDMA	6235i (UScellular)
Nokia CDMA	6255(UScellular)
Nokia CDMA	6255
Nokia CDMA	6256
Nokia CDMA	6265i
Nokia CDMA	6275i
Nokia CDMA	6305
Nokia CDMA	6315i
Nokia CDMA	6385
Nokia CDMA	6585
Nokia CDMA	7205
Nokia CDMA	7705 Twist
Nokia CDMA	8280
Nokia GSM	Famous (USB)
Nokia GSM	Famous (BT)
Nokia GSM	F1 lke
Nokia GSM	C1-00 (RM-689)
Nokia GSM	C1-01 (RM-607)
Nokia GSM	Fake Nokia C1-01(JX-589)
Nokia GSM	C1-01.1 (RM-608)
Nokia GSM	C1-02 (RM-643)
Nokia GSM	X1-01 (RM-713)
Nokia GSM	Nokia 150 (RM-1189)
Nokia GSM	C2-00 (RM-704)
Nokia GSM	C2-01 Hally (RM-721)
Nokia GSM	C2-01.5 Warm Silver (RM-722)
Nokia GSM	C2-02 (RM-692)
Nokia GSM	C2-02.1 (RM-693)
Nokia GSM	C2-03 (RM-702)
Nokia GSM	C2-05 (RM-724)
Nokia GSM	C2-06 (RM-702)
Nokia GSM	C3-00 (RM-614)
Nokia GSM	X2-00 (RM-618)
Nokia GSM	X2-01.1 (RM-717)
Nokia GSM	X2-02 (RM-694)
Nokia GSM	X2-05 (RM-772)

Nokia GSM	C3-01 Ronald (RM-640)
Nokia GSM	C3-01.5 (RM-776)
Nokia GSM	X3-00 (RM-540)
Nokia GSM	X3-01 Lasse (RM-687)
Nokia GSM	X3-02 Touch and Type (RM-639)
Nokia GSM	C5-00 (RM-645) (No Client)
Nokia GSM	C5-00 (RM-645) (Using Client)
Nokia GSM	C5-03 Kitty (RM-697) (No Client)
Nokia GSM	C5-03 Kitty (RM-697) (Using Client)
Nokia GSM	C5-04 (RM-720) (No Client)
Nokia GSM	C5-04 (RM-720) (Using Client)
Nokia GSM	E5-00 (RM-632) (No Client)
Nokia GSM	E5-00 (RM-632) (Using Client)
Nokia GSM	E5-00.2 (RM-634) (No Client)
Nokia GSM	E5-00.2 (RM-634) (Using Client)
Nokia GSM	X5-00 (RM-678) (No Client)
Nokia GSM	X5-00 (RM-678) (Using Client)
Nokia GSM	C6-00 (RM-612) (No Client)
Nokia GSM	C6-00 (RM-612) (Using Client)
Nokia GSM	C6-00.1 (RM-624) (No Client)
Nokia GSM	C6-00.1 (RM-624) (Using Client)
Nokia GSM	C6-01.3 (RM-718) (No Client)
Nokia GSM	C6-01.3 (RM-718) (Using Client)
Nokia GSM	C6-01 (RM-601) (Using Client)
Nokia GSM	C6-01 (RM-601) (No Client)
Nokia GSM	E6-00 (RM-609) (No Client)
Nokia GSM	E6-00 (RM-609) (Using Client)
Nokia GSM	X6-00 32GB (RM-559) (No Client)
Nokia GSM	X6-00 32GB (RM-559) (Using Client)
Nokia GSM	X6-00 (RM-559)
Nokia GSM	C7-00 Astound (RM-675) (No Client)
Nokia GSM	C7-00 Astound (RM-675) (Using Client)
Nokia GSM	E7-00 Striker (RM-626) (No Client)
Nokia GSM	E7-00 Striker (RM-626) (Using Client)
Nokia GSM	X7-00.1 (RM-659) (Rogers) (No Client)
Nokia GSM	X7-00.1 (RM-659) (Rogers) (Using Client)
Nokia GSM	X7-00 Journey (RM-707) (No Client)
Nokia GSM	X7-00 Journey (RM-707) (Using Client)
Nokia GSM	N8-00 (RM-596) (No Client)
Nokia GSM	N8-00 (RM-596) (Using Client)
Nokia GSM	TA-1022
Nokia GSM	TA-1052 Nokia 8
Nokia GSM	TA-1053 Nokia 5
Nokia GSM	TA-1024 Nokia 5
Nokia GSM	N9-00 (RM-696)
Nokia GSM	E50 (RM-170) (No Client)
Nokia GSM	E50 (RM-170) (Using Client)
Nokia GSM	E51-1 (RM-244) (No Client)
Nokia GSM	E51-1 (RM-244) (Using Client)
Nokia GSM	E52-1 (RM-469) (No Client)
Nokia GSM	E52-1 (RM-469) (Using Client)
Nokia GSM	E55-1 (RM-482) (No Client)
Nokia GSM	E55-1 (RM-482) (Using Client)
Nokia GSM	E60-1 (RM-49) (No Client)
Nokia GSM	E60-1 (RM-49) (Using Client)

Nokia GSM	E61-1 (RM-89) (No Client)
Nokia GSM	E61-1 (RM-89) (Using Client)
Nokia GSM	E62-1 (RM-88) (No Client)
Nokia GSM	E62-1 (RM-88) (Using Client)
Nokia GSM	E63-1 (RM-437) (No Client)
Nokia GSM	E63-1 (RM-437) (Using Client)
Nokia GSM	E65-1 (RM-208) (No Client)
Nokia GSM	E65-1 (RM-208) (Using Client)
Nokia GSM	E66-1 (RM-343) (No Client)
Nokia GSM	E66-1 (RM-343) (Using Client)
Nokia GSM	E70 (RM-24) (No Client)
Nokia GSM	E70 (RM-24) (Using Client)
Nokia GSM	E70-1 (RM-10) (No Client)
Nokia GSM	E70-1 (RM-10) (Using Client)
Nokia GSM	N70-1 (RM-84)
Nokia GSM	E71-1 (RM-346) (No Client)
Nokia GSM	E71x (RM-462)
Nokia GSM	Fake Nokia Ditel V30
Nokia GSM	E71x (RM-462) (Using Client)
Nokia GSM	E71-1 (RM-346) (Using Client)
Nokia GSM	N71-1 (RM-67) (No Client)
Nokia GSM	N71-1 (RM-67) (Using Client)
Nokia GSM	E72-1 (RM-530) (No Client)
Nokia GSM	E72-1 (RM-530) (Using Client)
Nokia GSM	N72-5 (RM-180)
Nokia GSM	E73 Mode (RM-658) (No Client)
Nokia GSM	E73 Mode (RM-658) (Using Client)
Nokia GSM	N73-1 (RM-133) (No Client)
Nokia GSM	N73-1 (RM-133) (Using Client)
Nokia GSM	E75-1 (RM-412) (No Client)
Nokia GSM	E75-1 (RM-412) (Using Client)
Nokia GSM	N75-3 (RM-128) (No Client)
Nokia GSM	N75-3 (RM-128) (Using Client)
Nokia GSM	N76-1 (RM-135) (No Client)
Nokia GSM	N76-1 (RM-135) (Using Client)
Nokia GSM	N78-1 (RM-235) (No Client)
Nokia GSM	N78-1 (RM-235) (Using Client)
Nokia GSM	Fake Nokia E79+
Nokia GSM	N79-1 (RM-348) (No Client)
Nokia GSM	N79-1 (RM-348) (Using Client)
Nokia GSM	N80-1 (RM-92) (No Client)
Nokia GSM	N80-1 (RM-92) (Using Client)
Nokia GSM	N81-1 (RM-256) (No Client)
Nokia GSM	N81-1 (RM-256) (Using Client)
Nokia GSM	N81-1 8GB (RM-179) (No Client)
Nokia GSM	N81-1 8GB (RM-179) (Using Client)
Nokia GSM	N82-1 (RM-313) (No Client)
Nokia GSM	N82-1 (RM-313) (Using Client)
Nokia GSM	N85-1 (RM-333) (No Client)
Nokia GSM	N85-1 (RM-333) (Using Client)
Nokia GSM	N86-1 8MP (RM-484) (No Client)
Nokia GSM	N86-1 8MP (RM-484) (Using Client)
Nokia GSM	E90-1 (RA-6) (No Client)
Nokia GSM	E90-1 (RA-6) (Using Client)
Nokia GSM	N90-1 (RM-42)

Nokia GSM	N91-1 (RM-43) (No Client)
Nokia GSM	N91-1 (RM-43) (Using Client)
Nokia GSM	N93-1 (RM-55) (No Client)
Nokia GSM	N93-1 (RM-55) (Using Client)
Nokia GSM	N95-1 (RM-159) (No Client)
Nokia GSM	N95-1 (RM-159) (Using Client)
Nokia GSM	N95-2 8GB (RM-320) (No Client)
Nokia GSM	N95-2 8GB (RM-320) (Using Client)
Nokia GSM	N96-1 (RM-247) (No Client)
Nokia GSM	N96-1 (RM-247) (Using Client)
Nokia GSM	N97-1 (RM-505) (No Client)
Nokia GSM	N97-1 (RM-505) (Using Client)
Nokia GSM	N97-1 (RM-505) (Bell) (No Client)
Nokia GSM	N97-1 (RM-505) (Bell) (Using Client)
Nokia GSM	N97-4 mini (RM-555) (No Client)
Nokia GSM	N97-4 mini (RM-555) (Using Client)
Nokia GSM	100 (RH-130)
Nokia GSM	100.1 (RH-131)
Nokia GSM	101 (RM-769)
Nokia GSM	103 (RM-647)
Nokia GSM	105 (RM-1133)
Nokia GSM	105 (RM-1134)
Nokia GSM	105 (RM-1135)
Nokia GSM	105 (TA-1037)
Nokia GSM	105 (TA-1034)
Nokia GSM	130 (TA-1019)
Nokia GSM	107(RM-961)
Nokia GSM	106.1(RM-962)
Nokia GSM	106.3 (RM-963)
Nokia GSM	108 (RM-944)
Nokia GSM	108 (RM-945)
Nokia GSM	106(TA-1114)
Nokia GSM	Asha 503 (RM-947)
Nokia GSM	130 (RM-1035)
Nokia GSM	130 (RM-1037)
Nokia GSM	215 (RM-1110)
Nokia GSM	220 (RM-969)
Nokia GSM	220 (RM-970)
Nokia GSM	110 (RM-827)
Nokia GSM	114 (RM-827)
Nokia GSM	111.1 (RM-811)
Nokia GSM	112 (RM-873)
Nokia GSM	113 (RM-871)
Nokia GSM	150 (RM-1190)
Nokia GSM	Asha 201 (RM-799)
Nokia GSM	Asha 200 (RM-761)
Nokia GSM	Asha 201.2 (RM-800)
Nokia GSM	Asha 202 (RM-834)
Nokia GSM	Asha 203 (RM-832)
Nokia GSM	Asha 205.1 (RM-863)
Nokia GSM	Asha 205 (RM-862)
Nokia GSM	Asha 206 (RM-872)
Nokia GSM	Asha 206.1 (RM-873)
Nokia GSM	207.1 (RM-954)
Nokia GSM	X (RM-980)

Nokia GSM	Lumia 530 (RM-1018) (USB)
Nokia GSM	Lumia 530 (RM-1018) (BT)
Nokia GSM	Lumia 530 (RM-1019) (USB)
Nokia GSM	Lumia 530 (RM-1019) (BT)
Nokia GSM	Lumia 530 (RM-1017) (USB)
Nokia GSM	Lumia 530 (RM-1017) (BT)
Nokia GSM	XL (RM-1030)
Nokia GSM	Asha 208.1 (RM-948)
Nokia GSM	208.4 (RM-957)
Nokia GSM	Asha 210 (RM-924)
Nokia GSM	Asha 210.2 (RM-928)
Nokia GSM	Asha 210.4 (RM-929)
Nokia GSM	Asha 210.5 (RM-926)
Nokia GSM	216 (RM-1187)
Nokia GSM	220 (RM-971)
Nokia GSM	222 (RM-1136)
Nokia GSM	222 (RM-1137)
Nokia GSM	225 (RM-1011)
Nokia GSM	Asha 230 (RM-986)
Nokia GSM	230 (RM-1172)
Nokia GSM	Asha 300 (RM-781)
Nokia GSM	208.3 (RM-950)
Nokia GSM	Asha 515 (RM-952)
Nokia GSM	Asha 515 (RM-953)
Nokia GSM	Lumia 1020 (RM-877) (USB)
Nokia GSM	Lumia 1020 (RM-877) (BT)
Nokia GSM	Lumia 1520 (RM-938) (USB)
Nokia GSM	Lumia 1520 (RM-938) (BT)
Nokia GSM	Lumia 1520 (RM-940) (USB)
Nokia GSM	Lumia 1520 (RM-940) (BT)
Nokia GSM	Lumia 1520.1 (RM-937) (USB)
Nokia GSM	Lumia 1520.1 (RM-937) (BT)
Nokia GSM	Asha 302 (RM-813)
Nokia GSM	Asha 303 (RM-763)
Nokia GSM	Asha 305 (RM-766) (USB)
Nokia GSM	Asha 305 (RM-766) (BT)
Nokia GSM	Asha 306 (RM-767) (USB)
Nokia GSM	Asha 306 (RM-767) (BT)
Nokia GSM	Asha 306.1 (RM-768) (USB)
Nokia GSM	Asha 306.1 (RM-768) (BT)
Nokia GSM	Asha 301 (RM-839) (USB)
Nokia GSM	Asha 301 (RM-839) (BT)
Nokia GSM	Asha 308 (RM-838)
Nokia GSM	Asha 309 (RM-843)
Nokia GSM	Asha 310 (RM-911) (USB)
Nokia GSM	Asha 310 (RM-911) (BT)
Nokia GSM	Asha 311 (RM-714) (USB)
Nokia GSM	Asha 311 (RM-714) (BT)
Nokia GSM	500 (RM-750) Fancy (No Client)
Nokia GSM	500 (RM-750) Fancy (Using Client)
Nokia GSM	Asha 500 (RM-934)
Nokia GSM	500 (RM-750) (No Client)
Nokia GSM	500 (RM-750) (Using Client)
Nokia GSM	Asha 503 (RM-920)
Nokia GSM	Lumia 505 (RM-923) (USB)

Nokia GSM	Lumia 505 (RM-923) (BT)
Nokia GSM	Lumia 510 (RM-889) (USB)
Nokia GSM	Lumia 510 (RM-889) (BT)
Nokia GSM	Lumia 520 (RM-914) (USB)
Nokia GSM	Lumia 520 (RM-914) (BT)
Nokia GSM	Lumia 520.2 (RM-915) (USB)
Nokia GSM	Lumia 520.2 (RM-915) (BT)
Nokia GSM	Lumia 521 (RM-917) (USB)
Nokia GSM	Lumia 521 (RM-917) (BT)
Nokia GSM	Lumia 525 (RM-998) (USB)
Nokia GSM	Lumia 525 (RM-998) (BT)
Nokia GSM	603 (RM-779) (No Client)
Nokia GSM	603 (RM-779) (Using Client)
Nokia GSM	Lumia 610 (RM-835) (USB)
Nokia GSM	Lumia 610 (RM-835) (BT)
Nokia GSM	Lumia 620 (RM-846) (USB)
Nokia GSM	Lumia 620 (RM-846) (BT)
Nokia GSM	Lumia 625 (RM-941) (USB)
Nokia GSM	Lumia 625 (RM-941) (BT)
Nokia GSM	Lumia 625 (RM-942) (USB)
Nokia GSM	Lumia 625 (RM-942) (BT)
Nokia GSM	Lumia 630 (RM-976) (USB)
Nokia GSM	Lumia 630 (RM-976) (BT)
Nokia GSM	Lumia 630 (RM-977) (USB)
Nokia GSM	Lumia 630 (RM-977) (BT)
Nokia GSM	Lumia 630 (RM-978) (USB)
Nokia GSM	Lumia 630 (RM-978) (BT)
Nokia GSM	Lumia 635 (RM-974) (USB)
Nokia GSM	Lumia 635 (RM-974) (BT)
Nokia GSM	Lumia 820.2 (RM-824) (USB)
Nokia GSM	Lumia 820.2 (RM-824) (BT)
Nokia GSM	Lumia 909 (RM-875) (USB)
Nokia GSM	Lumia 909 (RM-875) (BT)
Nokia GSM	Lumia 909.1 (RM-875) (USB)
Nokia GSM	Lumia 909.1 (RM-875) (BT)
Nokia GSM	Lumia 635 (RM-975) (USB)
Nokia GSM	Lumia 635 (RM-975) (BT)
Nokia GSM	700 Benji (RM-670) (No Client)
Nokia GSM	700 Benji (RM-670) (Using Client)
Nokia GSM	701 (RM-675) (No Client)
Nokia GSM	701 (RM-675) (Using Client)
Nokia GSM	Lumia 710 (RM-803) (USB)
Nokia GSM	Lumia 710 (RM-803) (BT)
Nokia GSM	Lumia 710.1 (RM-809) (USB)
Nokia GSM	Lumia 710.1 (RM-809) (BT)
Nokia GSM	Lumia 720 (RM-855) (USB)
Nokia GSM	Lumia 720 (RM-855) (BT)
Nokia GSM	Lumia 720 (RM-885) (USB)
Nokia GSM	Lumia 720 (RM-885) (BT)
Nokia GSM	Lumia 800 (RM-801) (USB)
Nokia GSM	Lumia 800 (RM-801) (BT)
Nokia GSM	808 PureView (RM-807) (No Client)
Nokia GSM	808 PureView (RM-807) (Using Client)
Nokia GSM	Lumia 730 (RM-1040) (USB)
Nokia GSM	Lumia 730 (RM-1040) (BT)

Nokia GSM	Lumia 735 (RM-1038) (USB)
Nokia GSM	Lumia 735 (RM-1038) (BT)
Nokia GSM	Lumia 810 (RM-878) (USB)
Nokia GSM	Lumia 810 (RM-878) (BT)
Nokia GSM	Lumia 820 (RM-825) (USB)
Nokia GSM	Lumia 820 (RM-825) (BT)
Nokia GSM	Lumia 820.1 (RM-825) (USB)
Nokia GSM	Lumia 820.1 (RM-825) (BT)
Nokia GSM	Lumia 830 (RM-983) (USB)
Nokia GSM	Lumia 830 (RM-983) (BT)
Nokia GSM	Lumia 830 (RM-984) (USB)
Nokia GSM	Lumia 830 (RM-984) (BT)
Nokia GSM	Lumia 830 (RM-985) (USB)
Nokia GSM	Lumia 830 (RM-985) (BT)
Nokia GSM	Asha 301.1 (RM-840)
Nokia GSM	Asha 501.1 (RM-900)
Nokia GSM	Lumia 900 (RM-823) (USB)
Nokia GSM	Lumia 900 (RM-823) (BT)
Nokia GSM	Lumia 920 (RM-820) (USB)
Nokia GSM	Lumia 920 (RM-820) (BT)
Nokia GSM	Lumia 920.2 (RM-821) (USB)
Nokia GSM	Lumia 920.2 (RM-821) (BT)
Nokia GSM	TA-1000 Nokia 6
Nokia GSM	TA-1025 Nokia 6
Nokia GSM	TA-1029 Nokia 2
Nokia GSM	TA-1100 7.1
Nokia GSM	TA-1035 Nokia 2
Nokia GSM	TA-1047_DS Nokia 1
Nokia GSM	TA-1060 Nokia 1 Dark Blue
Nokia GSM	TA-1068 Nokia 6.1
Nokia GSM	TA-1099 6.1 Plus
Nokia GSM	TA-1125 3.1 Plus
Nokia GSM	TA-1087 9 PureView
Nokia GSM	TA-1082 9 PureView
Nokia GSM	TA-1096 7.1
Nokia GSM	TA-1085 7.1
Nokia GSM	TA-1033 Nokia 6
Nokia GSM	TA-1003 Nokia 6
Nokia GSM	TA-1046 Nokia 7 Plus
Nokia GSM	TA-1062 7 Plus
Nokia GSM	TA-1010
Nokia GSM	TA-1012 Nokia 8
Nokia GSM	TA-1004_DS Nokia 8
Nokia GSM	TA-1117_DS 3.1 Plus
Nokia GSM	N1 Tablet
Nokia GSM	TA-1041 7
Nokia GSM	TA-1172 X71
Nokia GSM	TA-1179 2.2
Nokia GSM	TA-1196 7.2
Nokia GSM	TA-1020 Nokia 3
Nokia GSM	TA-1032 Nokia 3
Nokia GSM	TA-1049 3.1
Nokia GSM	TA-1109 X5
Nokia GSM	N900 (RX-51)
Nokia GSM	Lumia 930 (RM-1045) (USB)

Nokia GSM	Lumia 930 (RM-1045) (BT)
Nokia GSM	Lumia 925 (RM-892) (USB)
Nokia GSM	Lumia 925 (RM-892) (BT)
Nokia GSM	Lumia 925 (RM-893) (USB)
Nokia GSM	Lumia 925 (RM-893) (BT)
Nokia GSM	1010 (RM-769)
Nokia GSM	105 (RM-908)
Nokia GSM	1050 (RM-908)
Nokia GSM	1100 (RH-18)
Nokia GSM	Fake Nokia 1100 (RM-352)
Nokia GSM	1100b (RH-36)
Nokia GSM	1101 (RH-75)
Nokia GSM	1110 (RH-70)
Nokia GSM	1112 (RH-93)
Nokia GSM	1200 (RH-99)
Nokia GSM	1208 (RH-105)
Nokia GSM	1200b (RH-100)
Nokia GSM	1202-2 (RH-112)
Nokia GSM	1208b (RH-106)
Nokia GSM	1209 (RH-105)
Nokia GSM	1280 (RM-647)
Nokia GSM	TA-1103 6.1 Plus
Nokia GSM	TA-1105 5.1 Plus
Nokia GSM	TA-1116_DS 6.1 Plus
Nokia GSM	TA-1131 X7
Nokia GSM	TA-1119 8.1
Nokia GSM	TA-1234_DS 5.3
Nokia GSM	Lumia 1320 (RM-994) (USB)
Nokia GSM	Lumia 1320 (RM-994) (BT)
Nokia GSM	Lumia 1320.1 (RM-995) (USB)
Nokia GSM	Lumia 1320.1 (RM-995) (BT)
Nokia GSM	1600 (RH-64)
Nokia GSM	1616-2 (RH-125)
Nokia GSM	1616-2c (RH-129)
Nokia GSM	1650 (RM-305)
Nokia GSM	1661-2 (RH-122)
Nokia GSM	1661-2b (RH-121)
Nokia GSM	1662-2 (RH-122)
Nokia GSM	1680c-2 Classic (RM-394)
Nokia GSM	1680c-2 Classic (RM-394) (China)
Nokia GSM	1681c (RH-118)
Nokia GSM	1800 (RM-653)
Nokia GSM	2100 (NAM-2)
Nokia GSM	2220 slide (RM-590)
Nokia GSM	2300 (RM-4)
Nokia GSM	2310 (RM-189)
Nokia GSM	2320c-2 Classic (RM-514)
Nokia GSM	2323c-2 Classic (RM-543)
Nokia GSM	2330c-2 Classic (RM-512)
Nokia GSM	2330C-2b (RM-513)
Nokia GSM	2600 (RH-59)
Nokia GSM	2600b (RH-60)
Nokia GSM	2600c-2 Classic (RM-340)
Nokia GSM	2610 (RH-86)
Nokia GSM	Fake Nokia 2610 (RH-86)

Nokia GSM	2626 (RM-291)
Nokia GSM	2630 (RM-298)
Nokia GSM	2650 (RH-53)
Nokia GSM	2651 (RH-54)
Nokia GSM	2652 (RH-53)
Nokia GSM	2660 (RM-292)
Nokia GSM	2680s-2 Slide (RM-392)
Nokia GSM	2680s-2b Slide (RM-500)
Nokia GSM	2690 (RM-635)
Nokia GSM	2700c-2 Classic (RM-561)
Nokia GSM	2710c-2 Navigation Edition (RM-586)
Nokia GSM	2720a-2 fold (RM-519)
Nokia GSM	2720a-2b fold (RM-520)
Nokia GSM	TA-1170 DS 2720 Flip
Nokia GSM	TA-1175 DS 2720 Flip
Nokia GSM	TA-1071 8110 4G
Nokia GSM	TA-1173 2720 Flip
Nokia GSM	800 Tough
Nokia GSM	2730c-1 Classic (RM-578)
Nokia GSM	2730c-1b Classic (RM-579)
Nokia GSM	2760 (RM-258)
Nokia GSM	5030c-2 XpressRadio (RM-524)
Nokia GSM	5030c-2b XpressRadio (RM-525)
Nokia GSM	3100 (RH-19)
Nokia GSM	3109c Classic (RM-274)
Nokia GSM	3110c Classic (RM-237)
Nokia GSM	3120 (RH-19)
Nokia GSM	3120c-1c Classic (RM-364) (USB)
Nokia GSM	3120c-1c Classic (RM-364) (BT)
Nokia GSM	3200 (RH-30)
Nokia GSM	3208c Classic (RM-572)
Nokia GSM	3220 (RH-37)
Nokia GSM	3230 (RH-51)
Nokia GSM	3250 (RM-38) (No Client)
Nokia GSM	3250 (RM-38) (Using Client)
Nokia GSM	3300a (NEM-1)
Nokia GSM	3310 (NHM-5NX)
Nokia GSM	3310 (2017)
Nokia GSM	TA-1008 3310 (2017)
Nokia GSM	Nokia 210 (TA-1139)
Nokia GSM	TA-1030 3310 (2017)
Nokia GSM	3310 TA-1006
Nokia GSM	3310 3G TA-1036
Nokia GSM	3330 (NHM-6NX)
Nokia GSM	3390 (NPB-1NB)
Nokia GSM	3395 (NPB-1BB)
Nokia GSM	33xx (Legacy Models)
Nokia GSM	34xx (Legacy Models)
Nokia GSM	3500c Classic (RM-272)
Nokia GSM	3500cb Classic (RM-273)
Nokia GSM	3510i (RH-9)
Nokia GSM	35xx (Legacy Models)
Nokia GSM	3555b (RM-257)
Nokia GSM	3600s Slide (RM-352)
Nokia GSM	3610a fold (RM-429)

Nokia GSM	3710a-1 fold (RM-509)
Nokia GSM	3720c-2 Classic (RM-518)
Nokia GSM	5000d-2 (RM-362)
Nokia GSM	5070 (RM-166)
Nokia GSM	5100 (NPM-6)
Nokia GSM	5110 (NSE-1NX)
Nokia GSM	5130c-2 (RM-495) XpressMusic
Nokia GSM	5140 (NPL-5)
Nokia GSM	5190 (NSB-1NX)
Nokia GSM	51xx (Legacy Models)
Nokia GSM	5200 (RM-174)
Nokia GSM	5210 (NSM-5)
Nokia GSM	5220 (RM-411) XpressMusic
Nokia GSM	5230 (RM-588) Nuron (No Client)
Nokia GSM	5230 (RM-588) Nuron (Using Client)
Nokia GSM	5230-1c (RM-593) Nuron (No Client)
Nokia GSM	5230-1c (RM-593) Nuron (Using Client)
Nokia GSM	5228 (RM-625) (No Client)
Nokia GSM	5228 (RM-625) (Using Client)
Nokia GSM	5233 (RM-625) (No Client)
Nokia GSM	5233 (RM-625) (Using Client)
Nokia GSM	5300 (RM-146)
Nokia GSM	5310 (RM-303)
Nokia GSM	3711a-1 Cooper (RM-511)
Nokia GSM	5250 (RM-684) (No Client)
Nokia GSM	5250 (RM-684) (Using Client)
Nokia GSM	5320d-1 XpressMusic (RM-409) (No Client)
Nokia GSM	5320d-1 XpressMusic (RM-409) (Using Client)
Nokia GSM	5500d Sport (RM-86) (No Client)
Nokia GSM	5500d Sport (RM-86) (Using Client)
Nokia GSM	5530 XpressMusic (RM-504) (No Client)
Nokia GSM	5530 XpressMusic (RM-504) (Using Client)
Nokia GSM	5610d-2b XpressMusic (RM-359)
Nokia GSM	5630d-1 XpressMusic (RM-431) (No Client) (USB)
Nokia GSM	5630d-1 XpressMusic (RM-431) (No Client) (BT)
Nokia GSM	5630d-1 XpressMusic (RM-431) (Using Client)
Nokia GSM	5700 XpressMusic (RM-230) (No Client) (USB)
Nokia GSM	5700 XpressMusic (RM-230) (No Client) (BT)
Nokia GSM	5700 XpressMusic (RM-230) (Using Client)
Nokia GSM	5730s-1 XpressMusic (RM-465) (No Client)
Nokia GSM	5730s-1 XpressMusic (RM-465) (Using Client)
Nokia GSM	5800d-1 XpressMusic (RM-356) (No Client) (USB)
Nokia GSM	5800d-1 XpressMusic (RM-356) (No Client) (BT)
Nokia GSM	5800d-1 XpressMusic (RM-356) (Using Client)
Nokia GSM	5800d-1b XpressMusic (RM-428) (No Client) (USB)
Nokia GSM	5800d-1b XpressMusic (RM-428) (No Client) (BT)
Nokia GSM	5800d-1b XpressMusic (RM-428) (Using Client)
Nokia GSM	5802 XpressMusic (RM-427) (No Client)
Nokia GSM	5802 XpressMusic (RM-427) (Using Client)
Nokia GSM	6010 (NPM-10X)
Nokia GSM	6020 (RM-30)
Nokia GSM	6021 (RM-94)
Nokia GSM	6030
Nokia GSM	6060 (RH-73)
Nokia GSM	6061 (RH-74)

Nokia GSM	6070 (RM-166)
Nokia GSM	6080 (RM-166)
Nokia GSM	6085 (RM-198)
Nokia GSM	6086 (RM-188)
Nokia GSM	6100 (NPL-2)
Nokia GSM	6101 (RM-76)
Nokia GSM	6102i (RM-162)
Nokia GSM	6101b (RM-77)
Nokia GSM	6102b (RM-77)
Nokia GSM	6103 (RM-161)
Nokia GSM	6108 (RH-4)
Nokia GSM	6110 Navigator (RM-122) (No Client)
Nokia GSM	6111 (RM-82)
Nokia GSM	6120c-1 classic (RM-243) (No Client)
Nokia GSM	6120c-1 classic (RM-243) (Using Client)
Nokia GSM	6121 (No Client)
Nokia GSM	6121 (Using Client)
Nokia GSM	6122 (No Client)
Nokia GSM	6122 (Using Client)
Nokia GSM	6124 Classic (No Client)
Nokia GSM	6124 Classic (Using Client)
Nokia GSM	6125 (RM-178)
Nokia GSM	6126 (RM-126)
Nokia GSM	6131 (RM-115) (USB)
Nokia GSM	6131 (RM-115) (BT)
Nokia GSM	6133 (RM-126) (USB)
Nokia GSM	6133 (RM-126) (BT)
Nokia GSM	6151 (RM-200)
Nokia GSM	6170 (RM-47)
Nokia GSM	61xx (Legacy Models)
Nokia GSM	6200 (NPL-3)
Nokia GSM	6208c (RH-6)
Nokia GSM	6210 (NPE-3NX)
Nokia GSM	6210s-1 Navigator (RM-367) (No Client)
Nokia GSM	6210s-1 Navigator (RM-367) (Using Client)
Nokia GSM	6220 (Legacy)
Nokia GSM	6220c-1 Classic (RM-328) (No Client)
Nokia GSM	6220c-1 Classic (RM-328) (Using Client)
Nokia GSM	6230 (RH-12)
Nokia GSM	6230i (RM-72)
Nokia GSM	6233 (RM-145)
Nokia GSM	6234 (RM-123)
Nokia GSM	6260 (RM-25)
Nokia GSM	6260s-1 Slide (RM-368)
Nokia GSM	6263 (RM-207)
Nokia GSM	6267 (RM-210)
Nokia GSM	6270 (RM-56)
Nokia GSM	6280 (RM-78)
Nokia GSM	6288 (RM-78)
Nokia GSM	6290 (RM-176) (No Client)
Nokia GSM	6290 (RM-176) (Using Client)
Nokia GSM	62xx (Legacy Models)
Nokia GSM	6300 (RM-217)
Nokia GSM	6301 (RM-322)
Nokia GSM	6303c Classic (RM-443)

Nokia GSM	6303ci Classic (RM-638)
Nokia GSM	6310i (NPL-1)
Nokia GSM	6340i (RH-13)
Nokia GSM	6350 Blink
Nokia GSM	6350-1d
Nokia GSM	63xx (Legacy Models)
Nokia GSM	6500c Classic (RM-265)
Nokia GSM	6500 Slide (RM-278)
Nokia GSM	6555 (RM-271)
Nokia GSM	6600 Fold (RM-325)
Nokia GSM	6600 Slide
Nokia GSM	6600i Slide (RM-570)
Nokia GSM	6610 (NHL-4U)
Nokia GSM	6610i (RM-37)
Nokia GSM	6620 (NHL-12)
Nokia GSM	6630 (RM-1)
Nokia GSM	6650 Mercury (Tmobile) (NHM-1) (No Client)
Nokia GSM	6650 Mercury (Tmobile) (NHM-1) (Using Client)
Nokia GSM	6650 Silver (RM-324) (No Client)
Nokia GSM	6650 Silver (RM-324) (Using Client)
Nokia GSM	6650d-1bh (RM-324) (No Client)
Nokia GSM	6650d-1bh (RM-324) (Using Client)
Nokia GSM	6650 Red (ATT) (RM-400) (No Client)
Nokia GSM	6650 Red (ATT) (RM-400) (Using Client)
Nokia GSM	6650
Nokia GSM	6651 (Legacy)
Nokia GSM	651 (Legacy)
Nokia GSM	6670 (RH-67)
Nokia GSM	6670b (RH-68)
Nokia GSM	6680 (RM-36)
Nokia GSM	6681 (RM-75)
Nokia GSM	6682 (RM-58)
Nokia GSM	6700 Classic
Nokia GSM	6700c
Nokia GSM	6700c-1 Classic
Nokia GSM	6700 Slide (RM-576) (No Client)
Nokia GSM	6700 Slide (RM-576) (Using Client)
Nokia GSM	6710 Navigator (RM-491) (No Client)
Nokia GSM	6710 Navigator (RM-491) (Using Client)
Nokia GSM	6720 Classic (RM-424) (No Client)
Nokia GSM	6720 Classic (RM-424) (Using Client)
Nokia GSM	6730 Classic (RM-566) (No Client) (USB)
Nokia GSM	6730 Classic (RM-566) (No Client) (BT)
Nokia GSM	6730 Classic (RM-566) (Using Client)
Nokia GSM	6750 Mural (RM-381)
Nokia GSM	6760 Slide (RM-573) (No Client)
Nokia GSM	6760 Slide (RM-573) (Using Client)
Nokia GSM	6788 (RM-567) (No Client)
Nokia GSM	6788 (RM-567) (Using Client)
Nokia GSM	6790 Surge (RM-492) (No Client)
Nokia GSM	6790 Surge (RM-492) (Using Client)
Nokia GSM	6790s-1c Surge (RM-599) (No Client)
Nokia GSM	6790s-1c Surge (RM-599) (Using Client)
Nokia GSM	6800 (NHL-6)
Nokia GSM	6820 (NHL-9)

Nokia GSM	6822 (RM-69)
Nokia GSM	68xx (Legacy Models)
Nokia GSM	7020 (RM-497)
Nokia GSM	7020a-2 (RM-497)
Nokia GSM	7070 Prism (RH-116)
Nokia GSM	71xx (Legacy Models)
Nokia GSM	7100 Supernova (RM-438)
Nokia GSM	7210
Nokia GSM	7210c Supernova
Nokia GSM	7230 (RM-604)
Nokia GSM	7230-1C (RM-598)
Nokia GSM	7250 (NHL-4)
Nokia GSM	7250i (NHL-4JX)
Nokia GSM	7260 (RM-17)
Nokia GSM	7270 (RM-8)
Nokia GSM	7280 (RM-14)
Nokia GSM	72xx (Legacy Models)
Nokia GSM	7310c (RM-379)
Nokia GSM	7360 (RM-127)
Nokia GSM	7370 (RM-70)
Nokia GSM	7373 (RM-209)
Nokia GSM	7380 (RM-111)
Nokia GSM	7390 (RM-140)
Nokia GSM	7500 Prism (RM-249)
Nokia GSM	7510 Supernova (RM-398)
Nokia GSM	7610 (RH-51)
Nokia GSM	7610 Supernova (RM-354)
Nokia GSM	7710 (RM-12)
Nokia GSM	7900 Prism (RM-264)
Nokia GSM	TA-1059 8110 4G
Nokia GSM	82xx (Legacy Models)
Nokia GSM	8600 Luna (RM-164)
Nokia GSM	8800 (RM-13)
Nokia GSM	8800 Arte (RM-233)
Nokia GSM	8800 Sapphire (RM-233)
Nokia GSM	8810 (NSE-6NX)
Nokia GSM	8850 (NSM-3DX)
Nokia GSM	8890 (NSB-6NY)
Nokia TDMA	1220 (NKC-1X)
Nokia TDMA	1260 (NKW-1X)
Nokia TDMA	2220 (RH-42)
Nokia TDMA	2260 (RH-39)
Nokia TDMA	3320 (NPC-1NB)
Nokia TDMA	3360 (NPW-1NB)
Nokia TDMA	3520 (RH-14)
Nokia TDMA	3560 (RH-14)
Nokia TDMA	5120 (NSC-1NX)
Nokia TDMA	5120i (NSC-1NX)
Nokia TDMA	5120ih (NSC-1NX)
Nokia TDMA	5125 (NSC-1NX)
Nokia TDMA	5160 (NSW-1NX)
Nokia TDMA	5165 (NSW-1NX)
Nokia TDMA	6120
Nokia TDMA	6120i
Nokia TDMA	6120ih

Nokia TDMA	6160 (NSW-1NY)
Nokia TDMA	6161 (NSW-3ND)
Nokia TDMA	6162 (NSW-3AF)
Nokia TDMA	6340i (RH-13)
Nokia TDMA	6360 (NPW-2NX)
Nokia TDMA	6560 (RH-25)
Nokia TDMA	7160 (NSW-5NY)
Nokia TDMA	8260
Nokia TDMA	8265
NuuMobile	NU-2S
NuuMobile	NU-3S
NuuMobile	Mobile X1
NuuMobile	Mobile X3
NuuMobile	Z8
OnePlus	One A0001
OnePlus	2 A2003
OnePlus	One E1001 X
OnePlus	One E1003 X
OnePlus	2 A2001
OnePlus	2 A2005
OnePlus	3 A3000
OnePlus	3 A3003
OnePlus	A6000 6
OnePlus	A6003 6
OnePlus	HD1910 7T Pro
OnePlus	HD1900 7T
OnePlus	GM1900_DS OnePlus 7
OnePlus	IN2010_DS 8
OnePlus	A6010 6T
OnePlus	A6013 6T_DS
OnePlus	A3010 3T
OnePlus	A5000 5
OnePlus	GM1913 7 Pro
OnePlus	A5010 5T
Oppo	F1f F1
Oppo	CPH1605 A39
Oppo	PBCM30 K1
Oppo	PBEM00 R17
Oppo	PBDM00 R17 Pro
Oppo	A31t
Oppo	CPH1943_DS A5 2020
Oppo	A30
Oppo	CPH1941_DS A9 2020
Oppo	A33m_DS
Oppo	R9km
Oppo	R11t
Oppo	3005_DS
Oppo	PCHM30_DS A11x
Oppo	PCEM00 A9x
Oppo	PBAM00 A5
Oppo	PCAM10 A9
Oppo	PDBM00_DS A8
Oppo	CPH1823_DS F9 Pro
Oppo	CPH1931_DS A5 2020
Oppo	PCHM10_DS A11

Oppo	PCLM10_DS Reno Ace
Oppo	PCAM00 Reno
Oppo	PCGM00_DS K3
Oppo	PCNM00_DS K5
Oppo	CPH1851 AX5
Oppo	CPH1920_DS AX5s
Oppo	CPH1923_DS A1k
Oppo	PBBM30 A5
Oppo	CPH1945_DS Reno2 Z
Oppo	CPH1907 Reno 2
Oppo	CPH1909_DS A5s
Oppo	CPH1969 F11 Pro
Oppo	CPH1613 F3 Plus
Oppo	CPH1803_DS A3s
Oppo	A53m
Oppo	PBBM00 A7X
Oppo	CPH1609 F3
Oppo	CPH1701 A57
Oppo	CPH1723 F5
Oppo	N1
Oppo	R9 Plusm A
Oppo	R9s
Oppo	R9s (Bluetooth)
Oppo	R9st
Oppo	R9tm
Oppo	R7
Oppo	R7c
Oppo	R7sm
Oppo	R7s Plus
Oppo	R7st_DS R7
Oppo	R7Plus R7 Plus
Oppo	R11
Oppo	R11 Pluskt
Oppo	R11s
Oppo	R11s Plus
Oppo	R11st
Oppo	R11 (Bluetooth)
Oppo	A31
Oppo	R7 Plus
Oppo	R9m
Oppo	1107
Oppo	N5117 N1 Mini
Oppo	A1601 F1s
Oppo	A83
Oppo	PCPM00_DS A91
Oppo	A59s
Oppo	A59s (Bluetooth)
Oppo	A59m
Oppo	A53
Oppo	A33F
Oppo	A33
Oppo	A33t_DS
Oppo	A73t_DS
Oppo	OPPO A79t_DS
Oppo	A37fw

Oppo	A37M
Oppo	6607 U3
Oppo	C50
Oppo	A73
Oppo	CPH1725 A73
Oppo	CPH1801 A71
Oppo	CPH1819 F7
Oppo	CPH1893 R17 Neo
Oppo	PADM00 A3
Oppo	PBFM00 A7
Oppo	PAFM00 FIND X
Oppo	A77
Oppo	A79
Oppo	A79k
Oppo	A79kt_DS
Oppo	PCRM00_DS Reno 3 Pro 5G
Oppo	PCKM00 Reno2
Oppo	PDCM00_DS Reno3 5G
Oppo	PDPM00_DS Reno4 5G
Oppo	A115
Oppo	U539
Oppo	U705T Ulike
Oppo	U707T
Oppo	R8007 R1S
Oppo	R8106 R5
Oppo	PACM00 R15
Oppo	PBCM10 R15x
Oppo	R809T
Oppo	R811_DS Real
Oppo	R813T Real
Oppo	R819
Oppo	R819T
Oppo	R821T
Oppo	R823T
Oppo	R827T Find 5
Oppo	R829T R1
Oppo	R830 Neo
Oppo	R815T
Oppo	R831T Neo
Oppo	R833T
Oppo	X907 Finder
Oppo	X909 Find 5
Oppo	X909T Find 5
Oppo	R6007
Oppo	R7007
Oppo	R831S
Oppo	R8207_DS
Oppo	X9007 Find 7
Oukitel	K9
Oukitel	Y1000
Oukitel	C16_DS
Oukitel	K7 Pro
Oukitel	C17 Pro
Oukitel	U2
Oukitel	U16 Max

Oukitel	U20 Plus
Oukitel	U22
Oysters	T72X 3G
POSH	A100 (Lynx)
POSH	E500A Titan HD
POSH	L500A Ultra 5.0 LTE
POSH	S500A Revel
POSH	X510B Revel Pro
POSH	S240B Micro X
POSH	S240 Micro X
MIO (POZ)	A501
MIO (POZ)	A701
MIO (POZ)	A702
MIO (POZ)	W73C
MIO (POZ)	F610
MIO (POZ)	Mobix M5+
MIO (POZ)	TouchPad 7
Panasonic	Eluga A3 Pro
Panasonic	P-07D Eluga Power
Panasonic	T31
Panasonic	102P
Pantech	DM P100 (Disney)
Pantech	DM P205 (Disney)
Pantech	PN-205
Pantech	PN-210
Pantech	PN-215
Pantech	PN-218 (Alltel)
Pantech	PN-300
Pantech	IM-A730S Sky Vega S
Pantech	IM-A760S Vega Racer
Pantech	IM-A770K Vega Racer SKY
Pantech	IM-A800S Vega SKY
Pantech	PN-820
Pantech	TX-820
Pantech	IM-A830S Vega Racer II
Pantech	IM-A850S Vega R3
Pantech	IM-A860K Vega No 6
Pantech	IM-A870L VEGA Iron
Pantech	IM-A870S VEGA Iron
Pantech	IM-A880S Vega LTE-A
Pantech	IM-A890K Vega Secret Note
Pantech	IM-A900K Vega Secret Up
Pantech	ADR970LVW
Pantech	ADR910LVW Marauder
Pantech	ADR930LVW Perception
Pantech	P2000 Breeze II
Pantech	P2020 Ease
Pantech	P2030 Breeze 3
Pantech	PN-3200 (Telus)
Pantech	P5000 Link2
Pantech	P6010 Pursuit 2
Pantech	P6020 Swift
Pantech	P6030 Renue
Pantech	P6070 Vybe
Pantech	P7000 Impact

Pantech	P7040 Link
Pantech	P8000 Crossover
Pantech	P8010 Flex
Pantech	TXT-8035 Caper
Pantech	TXT-8045 Jest 2
Pantech	TXT-8045US
Pantech	CDM-8635 Coach
Pantech	CDM-8992 Hotshot
Pantech	ADR8995 Breakout
Pantech	CDM-8999 Crux
Pantech	P9020 Pursuit
Pantech	P9050 Laser
Pantech	P9060 Pocket
Pantech	P9070 Burst
Pantech	P9090
Pantech	UniMile PR-600
Pantech	P2050 Breeze 4
Philips	X116 Xenium
Philips	X130 Xenium
Philips	X188
Philips	K198
Philips	S308
Philips	E331 Xenium
Philips	X333 Xenium
Philips	X503 Xenium
Philips	X518 Xenium
Philips	X523 Xenium
Philips	F533 Xenium
Philips	E570 Xenium
Philips	W536 Xenium
Philips	K700 Xenium
Philips	W732 Xenium
Philips	W737 Xenium
Philips	X800 xenium
Philips	W832 Xenium
Philips	CTX2300 Xenium
Philips	W3568 Xenium
Philips	W6500 Xenium
Pidion	BM-150R
Plum	E200 Ram
Polaroid	A2_DS
Polaroid	A4
Polaroid	A400 Link A4
Polaroid	A500_DS
Polaroid	PROA54BPR003
Polaroid	PROM200PR001
Polaroid	PRO1021PR001
Polaroid	PROZ023PR001
Prestigio	MultiPad 7.0 PMP7170B Prime 3G
Prestigio	MultiPhone PSP3502DUO
Prestigio	MultiPhone PAP3540DUO
Prestigio	MultiPhone PAP4044DUO S1
Prestigio	MultiPhone PAP5400 DUO
Prestigio	MultiPhone PAP7600DUO
Prestigio	PSP7501DUO Grace R7

Prestigio	PFP1241DUO Muze A1
Prestigio	PFP1285DUO Muze D1_DS
Prestigio	PFP1286DUO_DS Muze K1
Prestigio	MultiPhone PSP8500DUO (USB)
Prestigio	MultiPhone PSP8500DUO (BT)
QMobile	CS1
QMobile	S2 Noir
QMobile	A3 Noir
QMobile	A8 Noir
QMobile	A8i Noir
QMobile	Z8 Noir Plus
QMobile	X800 Noir
QMobile	i6 Metal HD
QMobile	i7i Noir
QMobile	Z7 Noir
QMobile	Z10 Noir
QMobile	G400
QMobile	LT700 Noir
Qihoo 360	360 1801-A01 N6 PRO
Qihoo 360	1707-A01 N6
Qihoo 360	1605-A01 N5
RCA	CT9223W97 Pro 12
RCA	Q2_DS
RCA	RCT6203W46 Pro 10
RCA	RCT6303W87DK 10 Viking Pro
RCA	RCT6513W87 Galileo Pro
RCA	Q1
RCA	RCT6773W22 7 Voyager
Realme	RMX1809 2
Realme	RMX1991_DS X2
Realme	RMX1971_DS Q
Realme	RMX1931_DS X2 Pro
Realme	RMX1925_DS
Realme	RMX1921_DS XT
Realme	RMX833_DS U1
Realme	RMX1993_DS X2
Realme	RMX1851_DS X Lite
Realme	RMX1901 Realme X
Realme	RMX2025 X50 5G
Realme	RMX2040_DS 6i
RugGear	RG720
RugGear	RG730
SFR	S by SFR 102
SFR	SFR 103
SFR	STARADDICT 4
SFR	STARXTREM 4
SFR	S by SFR 1150
SFR	Android Edition StarAddict by SFR
SFR	STARADDICT II
SFR	StarAddict II Plus
SFR	STARTEXT by SFR
SFR	StarText II
SFR	Android Edition StarNaute by SFR
SFR	STARXTREAM II
SFR	STARSHINE by SFR

SFR	StarTrail by SFR
SFR	STARTRAIL II by SFR
SFR	StarTrail III by SFR
SFR	STARTRAIL 5
SFR	Startrail 6
SFR	Windows Phone Internet 7 by SFR (USB)
SFR	Windows Phone Internet 7 by SFR (BT)
SFR	S by SFR 114
SFR	S by SFR 115
SFR	S by SFR 117
SFR	S by SFR 121
SFR	S by SFR 122
SFR	S by SFR 123
SFR	Text Edition 152 by SFR
SFR	S by SFR 232
SFR	S by SFR 242
SFR	Text Edition by SFR 262
SFR	Messenger Edition 251 by SFR
SFR	Messenger Edition 261 by SFR
SFR	S by SFR 342
SFR	Doro PhoneEasy 612
SFR	S by SFR 344
SFR	SFR 552
SFR	S by SFR 3440
Sagem	myX2-2
Sagem	myX-3
Sagem	myX3-2
Sagem	myC3-2
Sagem	myC4-2
Sagem	myC5-2
Sagem	myC5-3
Sagem	myX-5
Sagem	MyX5-2
Sagem	myX5-2m
Sagem	myX6-2
Sagem	M52
Sagem	myV55
Sagem	myV75
Sagem	my201x
Sagem	my202c
Sagem	my400X
Sagem	my401c
Sagem	my401X
Sagem	my411Cv
Sagem	my411v
Sagem	my411x
Sagem	my421z
Sagem	my433v
Sagem	my501c
Sagem	my511x
Sagem	526
Sagem	527
Sagem	533
Sagem	my600X
Sagem	my700X

Sagem	my721x
Sagem	my800X
Sagem	my850
Sagem	P9521 Porsche
Sagem	P9522 Porsche
Sagem	DMTAB-NV08B
Samsung CDMA	Generic Android
Samsung CDMA	SCT21 Galaxy Tab S 10.5
Samsung CDMA	SM-N915R4 Galaxy Note Edge
Samsung CDMA	SCL21 Galaxy S III
Samsung CDMA	SM-N910R4 Galaxy Note 4
Samsung CDMA	SCH-i100 Gem (Verizon)
Samsung CDMA	SCH-i100 (CellSouth)
Samsung CDMA	SCH-i100 Gem
Samsung CDMA	SPH-P100 Galaxy Tab
Samsung CDMA	SCH-R100 (Bell)
Samsung CDMA	SCH-R100 Stunt
Samsung CDMA	SCH-R100 Stunt (Cricket)
Samsung CDMA	SCH-R100 Stunt (CellSouth)
Samsung CDMA	SM-J100V Galaxy J1
Samsung CDMA	SCH-i110 Illusion
Samsung CDMA	SM-B690V Convoy 4
Samsung CDMA	S179 (IL)
Samsung CDMA	SPH-N195
Samsung CDMA	SCH-i200 Galaxy Stellar
Samsung CDMA	SCH-I200PP Galaxy Legend
Samsung CDMA	SPH-N200
Samsung CDMA	SCH-R200 (Alltel)
Samsung CDMA	SCH-R210 Spex
Samsung CDMA	SCH-R210 Spex (Cricket)
Samsung CDMA	SPH-M210
Samsung CDMA	SCH-R211
Samsung CDMA	SM-T217S Galaxy Tab 3
Samsung CDMA	SM-T237P Galaxy Tab 4
Samsung CDMA	SCH-i220 Code
Samsung CDMA	SPH-M220
Samsung CDMA	SPH-M220 (Telus)
Samsung CDMA	SCH-i225 Exec
Samsung CDMA	SPH-M230 Phoenix (Bell)
Samsung CDMA	SCH-S239 Mpower TV
Samsung CDMA	SPH-M240
Samsung CDMA	SPH-N240
Samsung CDMA	SHV-E250S Galaxy Note II
Samsung CDMA	SCH-R250 Contour
Samsung CDMA	SCH-R250M
Samsung CDMA	SCH-W259
Samsung CDMA	SCH-W899
Samsung CDMA	SCH-R260U
Samsung CDMA	SCH-R261 Chrono
Samsung CDMA	SCH-R270
Samsung CDMA	SCH-R270A
Samsung CDMA	SCH-R270M
Samsung CDMA	SGH-S275G
Samsung CDMA	SPH-L300
Samsung CDMA	SPH-L300V

Samsung CDMA	SPH-M300
Samsung CDMA	SPH-N300
Samsung CDMA	SCH-R300
Samsung CDMA	SPH-T300
Samsung CDMA	SCH-A310
Samsung CDMA	SCH-R310 Byline
Samsung CDMA	SCH-U310 Knack
Samsung CDMA	SM-B311V Gusto 3
Samsung CDMA	SCH-U320 Haven
Samsung CDMA	SM-J320V Galaxy J3 2016
Samsung CDMA	SM-J320VPP Galaxy J3 2016
Samsung CDMA	SM-J320R4 Galaxy J3 2016
Samsung CDMA	SM-J327V Galaxy J3 2017
Samsung CDMA	SM-J327VPP Galaxy J3 2017
Samsung CDMA	SM-J327R4 Galaxy J3 2017
Samsung CDMA	SCH-R311 Axle
Samsung CDMA	SPH-M320 Cobra (Bell)
Samsung CDMA	SPH-M320
Samsung CDMA	SPH-i325 Ace
Samsung CDMA	SPH-M330
Samsung CDMA	SPH-M330 (Virgin)
Samsung CDMA	SCH-N330
Samsung CDMA	SCH-R330 (Bell)
Samsung CDMA	SM-S765C Galaxy Ace Style
Samsung CDMA	SCH-R330 Stride (UScellular)
Samsung CDMA	SM-T337V Galaxy Tab 4 8.0
Samsung CDMA	SGH-i337M Galaxy S4
Samsung CDMA	SCH-F339
Samsung CDMA	SCH-U340 Snap
Samsung CDMA	SCH-U340 (Verizon)
Samsung CDMA	SCH-U340 (Cricket)
Samsung CDMA	SCH-U340 (US Cellular)
Samsung CDMA	SCH-U340 (IL)
Samsung CDMA	SPH-N345
Samsung CDMA	SPH-i350 Intrepid
Samsung CDMA	SPH-M350 Seek (Bell)
Samsung CDMA	SPH-M350 Seek (Sprint,Boost)
Samsung CDMA	SCH-R350 Freeform (CellSouth)
Samsung CDMA	SCH-R350 Freeform (MetroPCS)
Samsung CDMA	SCH-U350 Smooth (Verizon)
Samsung CDMA	SCH-U350 Glint (Alltel)
Samsung CDMA	SM-G3509I Galaxy Trend 3
Samsung CDMA	SCH-R351 (Bell)
Samsung CDMA	SCH-R351 Freeform (Alltel)
Samsung CDMA	SCH-R351 FreeForm (UScellular)
Samsung CDMA	SCH-R351 Link (Virgin)
Samsung CDMA	SPH-M360
Samsung CDMA	SCH-R360 FreeForm 2
Samsung CDMA	SCH-R360M
Samsung CDMA	SCH-U360 Gusto
Samsung CDMA	SM-G360V Galaxy Core Prime
Samsung CDMA	SM-G360P Galaxy Core Prime
Samsung CDMA	SCH-U365 GUSTO II
Samsung CDMA	SPH-M370
Samsung CDMA	SCH-N370

Samsung CDMA	SCH-U370 Reality
Samsung CDMA	SM-T377V Galaxy Tab E 8.0
Samsung CDMA	SM-T377R4 Galaxy Tab E 8.0
Samsung CDMA	SCH-S379
Samsung CDMA	SPH-M380 Trender
Samsung CDMA	SCH-R380 Freeform III
Samsung CDMA	SM-G3819D Galaxy Win Pro
Samsung CDMA	SCH-R380 Freeform 3 (MetroPCS)
Samsung CDMA	SCH-U380 (Verizon)
Samsung CDMA	SPH-M390 Array (Sprint)
Samsung CDMA	SCH-R390 Comment 2
Samsung CDMA	SPH-A400
Samsung CDMA	SCH-i400 Continuum
Samsung CDMA	SGH-T399 Galaxy Light
Samsung CDMA	SPH-M400
Samsung CDMA	SPH-N400
Samsung CDMA	SPH-Z400
Samsung CDMA	SCH-R400 (Metro)
Samsung CDMA	SCH-R400 (US cellular)
Samsung CDMA	SCH-i405 Stratosphere
Samsung CDMA	SCH-I405U Matrix
Samsung CDMA	SCH-R410 (Metro)
Samsung CDMA	SCH-U410 (Verizon)
Samsung CDMA	SCH-U410T
Samsung CDMA	SCH-411
Samsung CDMA	SGH-C414
Samsung CDMA	SCH-i415
Samsung CDMA	SPH-A420
Samsung CDMA	SCH-R420 Tint(MetroPCS)
Samsung CDMA	SCH-R420 Tint(UScellular)
Samsung CDMA	SCH-U420 Nimbus(Alltel)
Samsung CDMA	SCH-i425
Samsung CDMA	SCH-R430 MyShot
Samsung CDMA	SCH-R430 MyShot (Alltel)
Samsung CDMA	SCH-R430 MyShot (CellSouth)
Samsung CDMA	SCH-U430 (Verizon)
Samsung CDMA	SCH-U430 (Telus)
Samsung CDMA	SCH-I435 Galaxy S4 Mini
Samsung CDMA	SCH-U440 Cleo (Bell)
Samsung CDMA	SCH-U440 Gloss (Verizon)
Samsung CDMA	SCH-U440 Gloss (US Cellular)
Samsung CDMA	SCH-R450 Messenger (Cricket)
Samsung CDMA	SCH-R450 Messenger (MetroPCS)
Samsung CDMA	SCH-U450 DoubleTake (Alltel)
Samsung CDMA	SCH-U450 Intensity (Verizon)
Samsung CDMA	SCH-U450 Intensity (Telus)
Samsung CDMA	SPH-A460
Samsung CDMA	SPH-A460 (Bell)
Samsung CDMA	SCH-R460 MyShotII (CellSouth)
Samsung CDMA	SCH-R460 MyShotII (Cricket)
Samsung CDMA	SCH-U460 Intensity II
Samsung CDMA	SCH-U470 Juke (Verizon)
Samsung CDMA	SCH-R470 TwoStep
Samsung CDMA	SCH-R480
Samsung CDMA	SCH-R480 Freeform 5

Samsung CDMA	SCH-U485 Intensity 3
Samsung CDMA	SCH-U490 Trance
Samsung CDMA	SPH-A500
Samsung CDMA	SPH-A500 (Bell)
Samsung CDMA	SPH-L500
Samsung CDMA	SCH-i500 Fascinate
Samsung CDMA	SCH-i500 Galaxy S
Samsung CDMA	SCH-i500 Mesmerize
Samsung CDMA	SPH-M500
Samsung CDMA	SPH-M500 (Bell)
Samsung CDMA	SPH-A523 [Telus]
Samsung CDMA	SPH-P500 Galaxy Tab 2 10.1
Samsung CDMA	SPH-P600 Galaxy Tab 10.1
Samsung CDMA	SPH-M510
Samsung CDMA	SCH-U510
Samsung CDMA	SCH-R500 Hue (Alltel)
Samsung CDMA	SCH-R500 (Telus Canada)
Samsung CDMA	SCH-R500 (US Cellular)
Samsung CDMA	SCH-R500 (IL)
Samsung CDMA	SCH-i510 Droid Charge
Samsung CDMA	SCH-R510 Wafer (Alltel)
Samsung CDMA	SCH-R510 (IL)
Samsung CDMA	SCH-i515 Galaxy Nexus
Samsung CDMA	SCH-B519
Samsung CDMA	SCH-M519
Samsung CDMA	SPH-A520 (Telus)
Samsung CDMA	SPH-A520
Samsung CDMA	SPH-i520
Samsung CDMA	SCH-I520
Samsung CDMA	SPH-M520
Samsung CDMA	SCH-R520 Trill
Samsung CDMA	SCH-U520 (Alltel)
Samsung CDMA	SCH-U520
Samsung CDMA	SPH-L520 Galaxy S4 Mini
Samsung CDMA	SCH-A530
Samsung CDMA	SPH-M530 (Bell)
Samsung CDMA	SCH-R530M Galaxy S III
Samsung CDMA	SCH-R530C Galaxy S III
Samsung CDMA	SCH-R530U Galaxy S III
Samsung CDMA	SCH-i535 Galaxy S III
Samsung CDMA	SCH-i535V Galaxy S III
Samsung CDMA	SM-T537R4 Galaxy Tab 4 10.1
Samsung CDMA	SM-T537V Galaxy Tab 4 10.1
Samsung CDMA	YP-G1 Yepp Galaxy Player
Samsung CDMA	YP-GS1 Galaxy Player 3.6
Samsung CDMA	YP-G50 Yepp Galaxy Player
Samsung CDMA	SM-G530P Galaxy Grand Prime
Samsung CDMA	SM-G530R4 Galaxy Grand Prime
Samsung CDMA	SM-G532F Galaxy J2 Grand Prime Plus Duos
Samsung CDMA	SM-G530R7 Galaxy Grand Prime
Samsung CDMA	SCH-540 (N362) (IL)
Samsung CDMA	SPH-A540 (Telus)
Samsung CDMA	SPH-A540
Samsung CDMA	SPH-M540 Rant (Boost Mobile)
Samsung CDMA	SPH-M540 Rant (Sprint)

Samsung CDMA	SPH-M540 Slyde (Telus)
Samsung CDMA	SPH-R540 Renaissance (Telus)
Samsung CDMA	SCH-U540 (Verizon)
Samsung CDMA	SCH-U540T (Telus)
Samsung CDMA	SCH-i545 Galaxy S4
Samsung CDMA	SCH-i545L Galaxy S4
Samsung CDMA	SPH-M550 Exclaim
Samsung CDMA	SCH-U550 (Verizon)
Samsung CDMA	SCH-R550 JetSet
Samsung CDMA	SPH-A560
Samsung CDMA	SPH-M560 Reclaim
Samsung CDMA	SCH-R560 MessengerII (Cricket)
Samsung CDMA	SCH-R560 MessengerII (MetroPCS)
Samsung CDMA	SPH-A561 (Telstra)
Samsung CDMA	SCH-R561 (Bell)
Samsung CDMA	SM-T567V Galaxy Tab E 9.6
Samsung CDMA	SCH-A570 (Telus)
Samsung CDMA	SCH-A570
Samsung CDMA	SPH-M570 Restore
Samsung CDMA	SCH-R570 Messenger 3
Samsung CDMA	SPH-A580 (Bell)
Samsung CDMA	SPH-A580
Samsung CDMA	SPH-M580 Replenish
Samsung CDMA	SCH-R580 (CellSouth)
Samsung CDMA	SCH-R580 M4
Samsung CDMA	SPH-A600 (Bell)
Samsung CDMA	SCH-A600 (Telus)
Samsung CDMA	SPH-A600 (Sprint)
Samsung CDMA	SPH-D600 Conquer 4G
Samsung CDMA	SCH-R600 Hue II
Samsung CDMA	SPH-L600 Galaxy Mega
Samsung CDMA	SCH-i605 Galaxy Note II
Samsung CDMA	SM-P605V Galaxy Note 10.1
Samsung CDMA	SCH-A610
Samsung CDMA	SPH-M610
Samsung CDMA	SCH-R610 (Bell)
Samsung CDMA	SCH-R610
Samsung CDMA	SCH-611
Samsung CDMA	SCH-620 (N182) (IL)
Samsung CDMA	SPH-A620
Samsung CDMA	VGA1000
Samsung CDMA	SPH-M620 UpStage
Samsung CDMA	SPH-M630 Highnote
Samsung CDMA	SCH-U620 (Verizon)
Samsung CDMA	SCH-A630 (Telus)
Samsung CDMA	SCH-A630
Samsung CDMA	SCH-A630 (660) (IL)
Samsung CDMA	SCH-R630 TwoThumb
Samsung CDMA	SCH-R631 Messenger Touch
Samsung CDMA	sch-r631 (cricket)
Samsung CDMA	SCH-640 (N392) (IL)
Samsung CDMA	SPH-A640
Samsung CDMA	SCH-R640 (UScellular)
Samsung CDMA	SCH-R640 (CellSouth)
Samsung CDMA	SCH-U640 Convoy

Samsung CDMA	SCH-R641
Samsung CDMA	SCH-A645 (Telus)
Samsung CDMA	SCH-A645 (MetroPCS)
Samsung CDMA	SCH-A645 (UScellular)
Samsung CDMA	SCH-A650
Samsung CDMA	SCH-A650 (Telus)
Samsung CDMA	SCH-U650 Sway
Samsung CDMA	SPH-A660 (Bell)
Samsung CDMA	SPH-A660 (Telus)
Samsung CDMA	SPH-A660
Samsung CDMA	VI660
Samsung CDMA	SCH-U660 Convoy 2
Samsung CDMA	SCH-I659
Samsung CDMA	SCH-A670 (Telus)
Samsung CDMA	SCH-A670 (Metro)
Samsung CDMA	SCH-A670
Samsung CDMA	SPH-A680 (Bell)
Samsung CDMA	SPH-A680
Samsung CDMA	SCH-R680
Samsung CDMA	SCH-U680 Convoy III
Samsung CDMA	SCH-A690
Samsung CDMA	SCH-I699
Samsung CDMA	SPH-A700
Samsung CDMA	SPH-D700 Galaxy S Epic 4G
Samsung CDMA	SPH-L700 Galaxy Nexus
Samsung CDMA	SCH-R700
Samsung CDMA	SCH-U700 Gleam (Verizon)
Samsung CDMA	SPH-D705 Epic 2
Samsung CDMA	SCH-i705 Galaxy Tab 2
Samsung CDMA	SCH-U706 Muse (Alltel)
Samsung CDMA	SCH-P709 Galaxy Mega 5.8
Samsung CDMA	SPH-D710 Epic 4G Touch(Sprint)
Samsung CDMA	SPH-D710 Galaxy S II
Samsung CDMA	SPH-D710 Galaxy S II Epic 4G
Samsung CDMA	SCH-R710
Samsung CDMA	SCH-L710 Galaxy S III
Samsung CDMA	SPH-L710 Galaxy S III
Samsung CDMA	SPH-D720 Nexus S 4G
Samsung CDMA	SPH-L720 Galaxy S4
Samsung CDMA	SPH-L720T Galaxy S4
Samsung CDMA	SCH-R720C Admire
Samsung CDMA	SCH-R720 Admire
Samsung CDMA	SCH-S720C Galaxy Proclaim
Samsung CDMA	SM-J727V Galaxy J7 (2017)
Samsung CDMA	SM-J727R4 Galaxy J7 2017
Samsung CDMA	SM-J737R4 Galaxy J7 Neo
Samsung CDMA	SM-G730V Galaxy S III Mini
Samsung CDMA	SCH-i730
Samsung CDMA	SCH-R730 Transfix
Samsung CDMA	SCH-S738C Galaxy Centura
Samsung CDMA	SCH-740 (V122) (IL)
Samsung CDMA	SCH-I739 Galaxy Trend II Duos
Samsung CDMA	SPH-A740
Samsung CDMA	SCH-R740C Galaxy Discover
Samsung CDMA	SPH-U740 Alias (Bell)

Samsung CDMA	SCH-U740 Alias (Verizon)
Samsung CDMA	SCH-U750 Alias 2
Samsung CDMA	SCH-U750 Zeal
Samsung CDMA	SM-W750V ATIV SE (USB)
Samsung CDMA	SM-W750V ATIV SE (BT)
Samsung CDMA	SPH-A760
Samsung CDMA	SCH-i760
Samsung CDMA	SCH-R760 Galaxy S II
Samsung CDMA	SCH-R760X Galaxy S II
Samsung CDMA	SCH-i770 Saga
Samsung CDMA	SCH-A790
Samsung CDMA	SCH-A795
Samsung CDMA	SCH-X799 (650) (IL)
Samsung CDMA	SPH-A800
Samsung CDMA	SCH-i800 Galaxy Tab
Samsung CDMA	SPH-I800 ATIV S Neo (USB)
Samsung CDMA	SPH-I800 ATIV S Neo (BT)
Samsung CDMA	SPH-M800 Instinct (Telus)
Samsung CDMA	SCH-R800 Delve
Samsung CDMA	SM-T807V Galaxy Tab S
Samsung CDMA	SM-T807P Galaxy Tab S
Samsung CDMA	SM-T807R4 Galaxy Tab S 10.5
Samsung CDMA	SPH-M810 Instinct S30
Samsung CDMA	SCH-R810 Finesse (MetroPCS)
Samsung CDMA	SCH-i815 Galaxy Tab 7.7
Samsung CDMA	SGH-M819N Galaxy Mega
Samsung CDMA	SPH-M820 Galaxy Prevail
Samsung CDMA	SCH-R820 Galaxy Admire 4G
Samsung CDMA	SCH-U820 Reality
Samsung CDMA	SCH-I829 Galaxy Style Duos
Samsung CDMA	SCH-R830 Axiom
Samsung CDMA	SCH-R830C Galaxy Admire 2
Samsung CDMA	SCH-R850
Samsung CDMA	SCH-R810 (CellSouth)
Samsung CDMA	SCH-U810 Renown
Samsung CDMA	SCH-811
Samsung CDMA	SPH-A820
Samsung CDMA	SCH-822 (811i) (IL)
Samsung CDMA	SCH-M828C
Samsung CDMA	SCH-830 (A562) (IL)
Samsung CDMA	SCH-i830
Samsung CDMA	SPH-M830 Galaxy Rush
Samsung CDMA	SPH-A840 (Telus)
Samsung CDMA	SPH-A840
Samsung CDMA	SPH-M840
Samsung CDMA	SCH-850 (X839) (IL)
Samsung CDMA	SCH-A850 (MetroPCS)
Samsung CDMA	SCH-A850 (US Cellular)
Samsung CDMA	SCH-A850
Samsung CDMA	SCH-A850 (880) (IL)
Samsung CDMA	SPH-M850 Instinct HD
Samsung CDMA	SPH-A860
Samsung CDMA	SM-G800R4 Galaxy S5 Mini
Samsung CDMA	SM-G860P Galaxy S5 Sport
Samsung CDMA	SCH-R860 Caliber (MetroPCS)

Samsung CDMA	SCH-R860U ATIV Odyssey (USB)
Samsung CDMA	SCH-R860U ATIV Odyssey (BT)
Samsung CDMA	SCH-I869 Galaxy Win
Samsung CDMA	SCH-A870
Samsung CDMA	SCH-A870(Telus)
Samsung CDMA	SCH-A870 (CellSouth)
Samsung CDMA	SCH-A870c (Cricket)
Samsung CDMA	SCH-I879 Galaxy Grand
Samsung CDMA	SPH-A880
Samsung CDMA	SCH-R880 Acclaim
Samsung CDMA	SCH-i889 Galaxy Note
Samsung CDMA	SCH-A890
Samsung CDMA	SCH-A895 Evolution
Samsung CDMA	SPH-A900
Samsung CDMA	SPH-A900M
Samsung CDMA	SPH-A900 (IL)
Samsung CDMA	SPH-L900 Galaxy Note II
Samsung CDMA	SPH-M900 Moment
Samsung CDMA	SCH-R900 Craft
Samsung CDMA	SCH-R900M Craft
Samsung CDMA	SM-G900V Galaxy S5
Samsung CDMA	SM-T817R4 Galaxy Tab S2 9.7
Samsung CDMA	SM-T817V Galaxy Tab S2
Samsung CDMA	SM-T817P Galaxy Tab S2
Samsung CDMA	SM-T818V Galaxy Tab S3
Samsung CDMA	SM-T827V Galaxy Tab S3 9.7
Samsung CDMA	SM-G900R4 Galaxy S5
Samsung CDMA	SM-G900R7 Galaxy S5
Samsung CDMA	SM-G900P Galaxy S5
Samsung CDMA	SM-N910P Galaxy Note 4
Samsung CDMA	SM-G900T1 Galaxy S5
Samsung CDMA	SM-N900P Galaxy Note 3
Samsung CDMA	SM-N900R4 Galaxy Note 3
Samsung CDMA	SM-N900V Galaxy Note 3
Samsung CDMA	SM-N915V Galaxy Note Edge
Samsung CDMA	SM-N915P Galaxy Note Edge
Samsung CDMA	SCH-U900 FlipShot (Verizon)
Samsung CDMA	SM-P905V Galaxy Note Pro 12.2
Samsung CDMA	SCH-i905 Galaxy Tab 10.1 LTE
Samsung CDMA	SCH-910 (A302) (IL)
Samsung CDMA	SM-N910V Galaxy Note 4
Samsung CDMA	SCH-i910 Omnia
Samsung CDMA	SPH-M910 Intercept(Sprint)
Samsung CDMA	SPH-M910 Intercept(Virgin)
Samsung CDMA	SCH-R910 Galaxy Indulge
Samsung CDMA	SCH-I915 Galaxy Tab 10.1 Note II
Samsung CDMA	SM-G920P Galaxy S6
Samsung CDMA	SM-G920V Galaxy S6
Samsung CDMA	SM-N920P Galaxy Note 5
Samsung CDMA	SM-N920V Galaxy Note 5
Samsung CDMA	SM-N920R4 Galaxy Note 5
Samsung CDMA	SM-N920R7 Galaxy Note 5
Samsung CDMA	SM-N920W8 Galaxy Note 5
Samsung CDMA	SM-G920R4 Galaxy S6
Samsung CDMA	SM-G920R7 Galaxy S6

Samsung CDMA	SM-G925V Galaxy S6 Edge
Samsung CDMA	SM-G925P Galaxy S6 Edge
Samsung CDMA	SM-G925R7 Galaxy S6 Edge
Samsung CDMA	SM-G928P Galaxy S6 Edge+
Samsung CDMA	SM-G928V Galaxy S6 Edge+
Samsung CDMA	SM-G925R4 Galaxy S6 Edge
Samsung CDMA	SM-G928R4 Galaxy S6 Edge+
Samsung CDMA	SCH-N719 Galaxy Note II
Samsung CDMA	SCH-R890 Galaxy S4 Mini
Samsung CDMA	SCH-I925 Galaxy Tab 10.1 Note
Samsung CDMA	SCH-R915
Samsung CDMA	SPH-M920 Transform
Samsung CDMA	SCH-911 (A101) (IL)
Samsung CDMA	SPH-A920
Samsung CDMA	SCH-i920 Omnia 2
Samsung CDMA	SCH-R920 Attain
Samsung CDMA	SCH-i929
Samsung CDMA	SCH-R930
Samsung CDMA	SCH-930 (A612) (IL)
Samsung CDMA	SCH-A930
Samsung CDMA	SCH-A930 (770) (IL)
Samsung CDMA	SCH-I930 ATIV Odyssey (USB)
Samsung CDMA	SCH-I930 ATIV Odyssey (BT)
Samsung CDMA	SPH-M930 Transform Ultra
Samsung CDMA	SM-G930P Galaxy S7
Samsung CDMA	SM-G930V Galaxy S7
Samsung CDMA	SM-G930VC Galaxy S7
Samsung CDMA	SM-N930V Galaxy Note 7
Samsung CDMA	SM-G930R4 Galaxy S7
Samsung CDMA	SM-G930R7 Galaxy S7
Samsung CDMA	SM-G935V Galaxy S7 Edge
Samsung CDMA	SM-G935P Galaxy S7 Edge
Samsung CDMA	SM-G935R4 Galaxy S7 Edge
Samsung CDMA	SCH-I939D Galaxy S III
Samsung CDMA	SPH-A940
Samsung CDMA	SCH-R940 Galaxy S Lightray 4G
Samsung CDMA	SCH-U940 Glyde (Verizon)
Samsung CDMA	SCH-A950 (Telus)
Samsung CDMA	SM-N950U Galaxy Note 8
Samsung CDMA	SM-G950U Galaxy S8
Samsung CDMA	SM-G955U Galaxy S8+
Samsung CDMA	SCH-A950
Samsung CDMA	SPH-M950 Galaxy Reverb
Samsung CDMA	SCH-R950 Galaxy Note II
Samsung CDMA	SCH-S950C Showcase
Samsung CDMA	SCH-i959 Galaxy S4
Samsung CDMA	SPH-A960
Samsung CDMA	SCH-R960 Galaxy Mega
Samsung CDMA	SCH-S960L Galaxy S III
Samsung CDMA	SCH-U960 Rogue
Samsung CDMA	SCH-A970
Samsung CDMA	SCH-R970 Galaxy S4
Samsung CDMA	SCH-R970X Galaxy S4
Samsung CDMA	SCH-R970C Galaxy S4
Samsung CDMA	SCH-A990

Samsung CDMA	GT-P3113TS Galaxy Tab 2 7.0
Samsung CDMA	GT-S6812i Galaxy Fame
Samsung CDMA	SCH-2000i (N101) (IL)
Samsung CDMA	GT-N8010 Galaxy Note 10.1
Samsung CDMA	SM-N9009 Galaxy Note 3
Samsung GSM	Generic Android
Samsung GSM	SC-01H (Galaxy Active neo)
Samsung GSM	SC-04G Galaxy S6 Edge
Samsung GSM	SCV32 Galaxy A8
Samsung GSM	GT-P1010 Galaxy Tab
Samsung GSM	SM-J120FN Galaxy J1 2016
Samsung GSM	SM-S120VL Galaxy Luna
Samsung GSM	SGH-CC01i
Samsung GSM	Fake Samsung Lafone SIII Mini S3
Samsung GSM	Fake Samsung Note 8
Samsung GSM	YP-GB70 Yepp Galaxy S Player
Samsung GSM	SGH-BC01
Samsung GSM	SC-05D Galaxy Note
Samsung GSM	SGH-ZV10
Samsung GSM	SGH-ZV30
Samsung GSM	SGH-ZX10
Samsung GSM	SGH-ZX20
Samsung GSM	SGH-ZX30
Samsung GSM	SGH-ZV40
Samsung GSM	SGH-ZV60
Samsung GSM	SGH-N075T Galaxy J
Samsung GSM	SM-J100F Galaxy J1
Samsung GSM	SM-J100H Galaxy J1
Samsung GSM	SM-J100VPP Galaxy J1
Samsung GSM	SM-A115F_DS Galaxy A11
Samsung GSM	SM-N980F_DS Galaxy Note 20
Samsung GSM	SM-G988B_DS Galaxy S20 Ultra
Samsung GSM	SM-S102DL Galaxy A10e
Samsung GSM	SM-A217M_DS Galaxy A21s
Samsung GSM	SM-A515F_DS Galaxy A51
Samsung GSM	SM-A715F_DS Galaxy A71
Samsung GSM	SCV42 Galaxy S10+
Samsung GSM	SM-G988U1 Galaxy S20 Ultra 5G
Samsung GSM	SM-G611M_DS Galaxy J7 Prime 2
Samsung GSM	SM-T707V Galaxy Tab S
Samsung GSM	SM-T705 Galaxy Tab S
Samsung GSM	SM-G977U Galaxy S10 5G
Samsung GSM	SM-G981U1 Galaxy S20 5G
Samsung GSM	SM-G986B_DS Galaxy S20+ 5G
Samsung GSM	SM-A202F_DS Galaxy A20e
Samsung GSM	SM-A307GN_DS Galaxy A30s
Samsung GSM	SM-T387V Galaxy Tab A 8.0
Samsung GSM	SM-T927A Galaxy View 2 Tablet
Samsung GSM	SM-A805F A80
Samsung GSM	SM-A908N Galaxy A90 5G
Samsung GSM	SM-J337W Galaxy J3 (2018)
Samsung GSM	SM-J337R4 Galaxy J3 Aura
Samsung GSM	SM-N976V Galaxy Note 10 Plus
Samsung GSM	SM-M405F Galaxy M40
Samsung GSM	SM-A707F_DS Galaxy A70s

Samsung GSM	SM-M3070_DS Galaxy M30s
Samsung GSM	SM-A600T1 Galaxy A6
Samsung GSM	SM-N9700_DS Galaxy Note 10
Samsung GSM	SM-N975U Galaxy Note 10 Plus
Samsung GSM	SM-A505U Galaxy A50
Samsung GSM	SM-J260AZ Galaxy J2 Pure
Samsung GSM	SM-A102U Galaxy A10e
Samsung GSM	SM-A205F_DS Galaxy A20
Samsung GSM	SM-A7050_DS Galaxy A70
Samsung GSM	SM-T860 Galaxy Tab S6
Samsung GSM	SM-N975F Galaxy Note 10+
Samsung GSM	SM-N970F Galaxy Note 10
Samsung GSM	SM-G985F Galaxy S20 Plus
Samsung GSM	SM-T285 Galaxy Tab A (2016)
Samsung GSM	SM-M105M Galaxy M10
Samsung GSM	SM-T830 Galaxy Tab S4
Samsung GSM	SM-A305F_DS Galaxy A30
Samsung GSM	SM-A105F Galaxy A10
Samsung GSM	SM-A705FN_DS Galaxy A70
Samsung GSM	SM-A705MN_DS Galaxy A70
Samsung GSM	SM-G975W GalaxyS10 Plus
Samsung GSM	SM-J327W Galaxy J3 Prime
Samsung GSM	Fake Samsung SM-G9750 Galaxy S10 PRO
Samsung GSM	SM-G930VL Galaxy S7
Samsung GSM	SM-A305G_DS Galaxy A30
Samsung GSM	SM-J260F Galaxy J2 Core
Samsung GSM	SM-S260DL Galaxy J2
Samsung GSM	SM-J260M Galaxy J2 Core
Samsung GSM	SM-S327VL Galaxy J3 Luna Pro
Samsung GSM	SM-J336AZ SOL 3
Samsung GSM	SM-S337TL J3 Luna Pro
Samsung GSM	SM-J105B\DS Galaxy J1 mini 2016
Samsung GSM	SM-J106B_DS Galaxy J1 Mini Prime
Samsung GSM	SM-J111F_DS Galaxy J1 Ace Neo
Samsung GSM	SM-J106H\DS Galaxy J1 mini Prime
Samsung GSM	SM-J120A Galaxy J1 2016
Samsung GSM	SM-J120F Galaxy J1 2016
Samsung GSM	SM-J120H\DS Galaxy J1 2016
Samsung GSM	SM-J120M\DS Galaxy J1 2016
Samsung GSM	SM-J120W Galaxy J1 2016
Samsung GSM	SM-J100FN Galaxy J1
Samsung GSM	SM-J110H Galaxy J1
Samsung GSM	SM-J110F Galaxy J1 Ace
Samsung GSM	SM-J111M Galaxy J1 ace VE LTE
Samsung GSM	SM-J100MU Galaxy J1
Samsung GSM	SM-J110M Galaxy J1 Ace
Samsung GSM	SM-J120AZ Galaxy Amp 2
Samsung GSM	SM-J200M Galaxy J2
Samsung GSM	SM-J200GU Galaxy J2
Samsung GSM	SM-J200H Galaxy J2
Samsung GSM	SM-J250G_DS Galaxy J2 Pro
Samsung GSM	SM-J250F_DS Galaxy J2 2018
Samsung GSM	SM-A307FN_DS Galaxy A30s
Samsung GSM	SM-J320A Galaxy J3 2016
Samsung GSM	SM-J320F Galaxy J3 2016

Samsung GSM	SM-J320FN Galaxy J3 2016
Samsung GSM	SM-J320P Galaxy J3
Samsung GSM	SM-J320H Galaxy J3 2016
Samsung GSM	SM-J321AZ Galaxy SOL
Samsung GSM	SM-J326AZ Galaxy Sol 2
Samsung GSM	SM-J327A Galaxy J3 2017
Samsung GSM	SM-J327T Galaxy J3 2017
Samsung GSM	SM-J327P Galaxy J3 Emerge
Samsung GSM	SM-J327T1 Galaxy J3 2017
Samsung GSM	SM-J100Y Galaxy J1
Samsung GSM	SM-J3110 Galaxy J3 Pro
Samsung GSM	SM-J337A J3 Neo
Samsung GSM	SM-J337P Galaxy J3 Achieve
Samsung GSM	SM-G970W Galaxy S10e
Samsung GSM	SM-G973W Galaxy S10
Samsung GSM	SM-J337U Galaxy
Samsung GSM	SM-J337V Galaxy J3 V
Samsung GSM	SM-J337VPP Galaxy J3
Samsung GSM	SM-J260A Galaxy J2 Core
Samsung GSM	SM-S357BL Galaxy J3 Orbit
Samsung GSM	SM-A105M_DS Galaxy A10
Samsung GSM	SM-A205G_DS Galaxy A20
Samsung GSM	SM-A207M_DS Galaxy A20s
Samsung GSM	SM-A260G_DS Galaxy A2 Core
Samsung GSM	SM-G977N Galaxy S10 5G
Samsung GSM	SM-J337T J3 Galaxy J3 (2018)
Samsung GSM	EK-GC100 Galaxy Camera
Samsung GSM	EK-GC200 Galaxy Camera 2
Samsung GSM	SGH-C100 (534)
Samsung GSM	SGH-D100
Samsung GSM	SGH-E100
Samsung GSM	SGH-U100
Samsung GSM	SGH-X100
Samsung GSM	SM-C101 Galaxy S4 Zoom
Samsung GSM	SGH-T101
Samsung GSM	SM-C105A Galaxy S4 Zoom
Samsung GSM	SGH-A107 Prepaid
Samsung GSM	SGH-F110
Samsung GSM	SGH-E105
Samsung GSM	SGH-X105
Samsung GSM	SGH-P107
Samsung GSM	SGH-Z107
Samsung GSM	SGH-T109
Samsung GSM	SM-G110H Galaxy Pocket 2
Samsung GSM	SM-T110 Galaxy Tab 3 7.0
Samsung GSM	SGH-M110
Samsung GSM	SHW-M110S Galaxy S
Samsung GSM	SHV-E110S Galaxy S II
Samsung GSM	SM-C111 Galaxy K Zoom
Samsung GSM	SM-C5000 Galaxy C5
Samsung GSM	SM-C5010 Galaxy C5 Pro
Samsung GSM	SM-C7000 Galaxy C7
Samsung GSM	SM-C7010 Galaxy C7 Pro
Samsung GSM	SM-T111 Galaxy Tab 3 Lite 7.0
Samsung GSM	SM-T113 Galaxy Tab 3 Lite 7.0

Samsung GSM	SM-C115 Galaxy K zoom
Samsung GSM	SM-G885Y_DS Galaxy A8 Star
Samsung GSM	SM-G885FD_DS Galaxy A8 Star
Samsung GSM	SM-A810S Galaxy A8 2016
Samsung GSM	SM-G532M Galaxy J2 Prime
Samsung GSM	SM-G532G_DS Galaxy J2 Prime
Samsung GSM	SM-G887F_DS Galaxy A8s
Samsung GSM	SM-M105F_DS Galaxy M10
Samsung GSM	SM-M107F_DS Galaxy M10s
Samsung GSM	SM-N981N Galaxy Note 20 5G
Samsung GSM	SM-N981U1 Galaxy Note 20 5G
Samsung GSM	SM-J250M Galaxy J2 Pro
Samsung GSM	SM-J200F Galaxy J2
Samsung GSM	SHW-M250K Galaxy S II
Samsung GSM	SHW-M250S Galaxy S II
Samsung GSM	SHW-M290K Galaxy Gio
Samsung GSM	SHW-M440S Galaxy S III 3G
Samsung GSM	SGH-A117
Samsung GSM	SGH-T119
Samsung GSM	SGH-C120
Samsung GSM	SHV-E120S Galaxy S2 HD
Samsung GSM	SGH-B130
Samsung GSM	SGH-C130
Samsung GSM	SGH-M130L
Samsung GSM	SGH-Z130
Samsung GSM	SGH-A137
Samsung GSM	SGH-T139
Samsung GSM	SGH-T159
Samsung GSM	SGH-Z140
Samsung GSM	SGH-J150
Samsung GSM	SGH-M150
Samsung GSM	SGH-X150
Samsung GSM	SGH-Z150
Samsung GSM	SGH-T155G Prepaid
Samsung GSM	SGH-X156
Samsung GSM	SGH-A157
Samsung GSM	SGH-C158
Samsung GSM	SGH-X160
Samsung GSM	SHV-E160K Galaxy Note
Samsung GSM	SHV-E160S Galaxy Note
Samsung GSM	SM-G160N Galaxy Folder 2
Samsung GSM	SGH-A167
Samsung GSM	SGH-Z170
Samsung GSM	SHV-E170K Galaxy R Style
Samsung GSM	SGH-C180
Samsung GSM	SGH-A187
Samsung GSM	SGH-C200
Samsung GSM	SGH-E200
Samsung GSM	SGH-F200
Samsung GSM	SGH-A177
Samsung GSM	SGH-I187 ATIV S Neo (USB)
Samsung GSM	SGH-I187 ATIV S Neo (BT)
Samsung GSM	SGH-i200
Samsung GSM	SGH-P200
Samsung GSM	SGH-V200

Samsung GSM	SGH-X200
Samsung GSM	SGH-T201G
Samsung GSM	SGH-V205
Samsung GSM	SGH-V206
Samsung GSM	SGH-A207 Denim
Samsung GSM	SGH-C207
Samsung GSM	SGH-P207
Samsung GSM	SGH-T209
Samsung GSM	SGH-E210
Samsung GSM	SGH-F210
Samsung GSM	SM-T210R Galaxy Tab 3 7.0
Samsung GSM	SM-T211 Galaxy Tab 3 7.0
Samsung GSM	SGH-X210
Samsung GSM	SHV-E210L Galaxy S III
Samsung GSM	SHV-E210S Galaxy S III
Samsung GSM	SM-T210 Galaxy Tab 3 7.0
Samsung GSM	SGH-E215L
Samsung GSM	SM-T215 Galaxy Tab 3 7.0
Samsung GSM	SM-T116NU Galaxy Tab 3V
Samsung GSM	SGH-C216
Samsung GSM	SM-T217A Galaxy Tab 3
Samsung GSM	SM-T217T Galaxy Tab 3 4G
Samsung GSM	SGH-B220B Impact b
Samsung GSM	SVH-E220S Galaxy Pop
Samsung GSM	SM-T255S Galaxy W
Samsung GSM	SM-T230NU Galaxy Tab 4
Samsung GSM	SM-T231 Galaxy Tab 4
Samsung GSM	SM-T239M Galaxy Tab 4 Lite 7.0
Samsung GSM	SGH-J218
Samsung GSM	SGH-T219
Samsung GSM	SGH-T229
Samsung GSM	SGH-T239
Samsung GSM	SGH-A256 Hype
Samsung GSM	SGH-A257 Magnet
Samsung GSM	SGH-F266
Samsung GSM	SGH-L288
Samsung GSM	SGH-Z230
Samsung GSM	SGH-A237
Samsung GSM	SGH-Z240 (Cellcom)
Samsung GSM	SGH-Z240 (Partner)
Samsung GSM	SGH-T249
Samsung GSM	SGH-T249R
Samsung GSM	SGH-E250 (USB)
Samsung GSM	SGH-E250 (BT)
Samsung GSM	SGH-E250i
Samsung GSM	SGH-F250
Samsung GSM	SGH-P250
Samsung GSM	SGH-E251
Samsung GSM	SGH-i257 Galaxy S4 Mini
Samsung GSM	SGH-i257M Galaxy S4 Mini
Samsung GSM	SM-G800A Galaxy S5 Mini
Samsung GSM	SC-04F Galaxy S5
Samsung GSM	SC-03G Galaxy Tab S 8.4
Samsung GSM	SM-G800F Galaxy S5 Mini
Samsung GSM	SM-S903VL Galaxy S5

Samsung GSM	SM-G800H Galaxy S5 Mini
Samsung GSM	SM-G800M Galaxy S5 Mini
Samsung GSM	SM-S902L Galaxy S5
Samsung GSM	SM-S906L Galaxy S6
Samsung GSM	SGH-T259
Samsung GSM	SGH-E260
Samsung GSM	SGH-P260
Samsung GSM	SHV-E230S Note 10.1 LTE
Samsung GSM	SHV-E270K Galaxy Grand
Samsung GSM	SGH-C270
Samsung GSM	SGH-F275L
Samsung GSM	SM-T280 Galaxy Tab A 7.0
Samsung GSM	SGH-C280
Samsung GSM	SM-T285M Galaxy Tab A 7.0 (2016)
Samsung GSM	SGH-T289 Gravity Q
Samsung GSM	SGH-C300
Samsung GSM	SGH-E300
Samsung GSM	SHV-E300K Galaxy S4
Samsung GSM	SHV-E300L Galaxy S4
Samsung GSM	SGH-F300
Samsung GSM	SGH-M300V
Samsung GSM	SGH-P300
Samsung GSM	SGH-S300
Samsung GSM	SGH-S300m
Samsung GSM	SGH-U300
Samsung GSM	SGH-Z300
Samsung GSM	SHV-E300S Galaxy S4
Samsung GSM	SGH-T301G
Samsung GSM	SGH-S306
Samsung GSM	SGH-D307
Samsung GSM	SGH-S307
Samsung GSM	SGH-S308
Samsung GSM	Fake Samsung GW-P308+I5600 S4
Samsung GSM	SGH-T309
Samsung GSM	SGH-B310
Samsung GSM	SM-B310E Guru Music 2
Samsung GSM	SGH-E310
Samsung GSM	SHV-E310S Galaxy Mega
Samsung GSM	SGH-L310
Samsung GSM	SGH-M310
Samsung GSM	SGH-M310v
Samsung GSM	SGH-P310
Samsung GSM	SM-T310 Galaxy Tab 3 8.0
Samsung GSM	SM-T311 Galaxy Tab 3 8.0
Samsung GSM	SM-B313E Metro 313 Duos
Samsung GSM	SM-G313H Galaxy Ace 4 Lite
Samsung GSM	SM-G313F Galaxy Ace 4
Samsung GSM	SM-T315 Galaxy Tab 3 8.0
Samsung GSM	SM-G318H Galaxy Trend 2 Lite
Samsung GSM	SM-G316M Galaxy Ace 4
Samsung GSM	SGH-E315
Samsung GSM	SGH-E316
Samsung GSM	SGH-E317
Samsung GSM	SGH-i317 Galaxy Note II
Samsung GSM	SGH-I317M Galaxy Note II

Samsung GSM	SGH-M318
Samsung GSM	SGH-C276L
Samsung GSM	SGH-T319
Samsung GSM	SGH-i320
Samsung GSM	SM-J320W8 Galaxy J3 2016
Samsung GSM	SM-J330FN Galaxy J3
Samsung GSM	SM-T320 Galaxy Tab Pro 8.4
Samsung GSM	SM-T325 Galaxy Tab Pro 8.4
Samsung GSM	SGH-T329 Stripe
Samsung GSM	SGH-E330
Samsung GSM	SGH-E335
Samsung GSM	SGH-E330C
Samsung GSM	SHV-E330L Galaxy S4 LTE-A
Samsung GSM	SHV-E330S Galaxy S4 LTE-A
Samsung GSM	SGH-F330
Samsung GSM	SGH-i337 Galaxy S4
Samsung GSM	SGH-i337M Galaxy S4
Samsung GSM	SGH-i337Z Galaxy S4
Samsung GSM	SM-T330NU Galaxy Tab 4 8.0
Samsung GSM	SGH-T330G
Samsung GSM	SM-T335 Galaxy Tab 4 8.0
Samsung GSM	SM-T337A Galaxy Tab 4
Samsung GSM	SGH-T339
Samsung GSM	SGH-E340
Samsung GSM	SGH-T340G
Samsung GSM	SGH-S341i
Samsung GSM	SGH-S342i
Samsung GSM	SGH-T349
Samsung GSM	B350E Metro
Samsung GSM	SM-G350 Galaxy Core Plus
Samsung GSM	SM-G3568V Galaxy Core Mini 4G
Samsung GSM	SM-G350E Galaxy Star 2 Plus
Samsung GSM	SM-T350 Galaxy Tab A 8.0
Samsung GSM	SM-T360 Galaxy Tab Active
Samsung GSM	SM-G360F Galaxy Core Prime
Samsung GSM	SM-G360AZ Galaxy Core Prime
Samsung GSM	SM-G350M Galaxy Core Plus
Samsung GSM	SM-G360T Galaxy Core Prime
Samsung GSM	SM-G360T1 Galaxy Core Prime
Samsung GSM	SGH-S366
Samsung GSM	SGH-T369
Samsung GSM	SGH-T369R Linx
Samsung GSM	SGH-E350
Samsung GSM	SGH-D357
Samsung GSM	SGH-E358
Samsung GSM	SM-G361F Galaxy Core Prime
Samsung GSM	SM-G361H Galaxy Core Prime
Samsung GSM	SGH-T359 :)
Samsung GSM	SGH-E360
Samsung GSM	SGH-E370
Samsung GSM	SGH-Z370
Samsung GSM	SM-T865 Galaxy Tab S6
Samsung GSM	SM-T377A Galaxy Tab E
Samsung GSM	SM-T377W Galaxy Tab E
Samsung GSM	SGH-T379 Gravity TXT

Samsung GSM	SM-T385 Galaxy Tab A
Samsung GSM	SGH-T399 Galaxy Light
Samsung GSM	SGH-T399N Galaxy Light
Samsung GSM	SGH-E380
Samsung GSM	SM-G386F Galaxy Core
Samsung GSM	SM-G386T Galaxy Avant
Samsung GSM	SM-G388F Galaxy Xcover 3
Samsung GSM	SM-G390F Galaxy Xcover 4
Samsung GSM	SGH-E390
Samsung GSM	SM-G386T1 Galaxy Avant
Samsung GSM	SM-G386W Galaxy Core LTE
Samsung GSM	SGH-S390G
Samsung GSM	SGH-F400
Samsung GSM	SGH-G400
Samsung GSM	SGH-J400
Samsung GSM	SM-J400F_DS Galaxy J4
Samsung GSM	SM-J400M Galaxy J4
Samsung GSM	SM-J415G_DS Galaxy J4 Plus
Samsung GSM	SGH-P400
Samsung GSM	SGH-S400i
Samsung GSM	SGH-S401i
Samsung GSM	SGH-X400
Samsung GSM	SGH-Z400
Samsung GSM	SGH-A401
Samsung GSM	SGH-T401G
Samsung GSM	403SC Galaxy Tab 4 7.0
Samsung GSM	SGH-T404G
Samsung GSM	SGH-C406
Samsung GSM	SGH-F406
Samsung GSM	SGH-D407
Samsung GSM	SGH-i408 (No Client)
Samsung GSM	SGH-i407 Galaxy Amp
Samsung GSM	SGH-i408 (Using Client)
Samsung GSM	SGH-T409
Samsung GSM	SGH-D410
Samsung GSM	SGH-S410i
Samsung GSM	SM-A405FN_DS Galaxy A40
Samsung GSM	SM-J410F_DS Galaxy J4 Core
Samsung GSM	SM-J415F Galaxy J4+
Samsung GSM	SM-J415FN Galaxy J4+
Samsung GSM	SGH-S425G
Samsung GSM	SGH-A411
Samsung GSM	SGH-A412
Samsung GSM	SGH-C414M Swift
Samsung GSM	SGH-C414Y Oyster
Samsung GSM	SGH-D415
Samsung GSM	SGH-C417
Samsung GSM	SGH-T419
Samsung GSM	SGH-C426
Samsung GSM	SGH-X426
Samsung GSM	SGH-X427
Samsung GSM	SGH-A436
Samsung GSM	SGH-T429
Samsung GSM	SGH-A437
Samsung GSM	SGH-i437 Galaxy Express

Samsung GSM	SGH-i437Z Galaxy Express
Samsung GSM	SGH-T439
Samsung GSM	SGH-C450
Samsung GSM	SGH-i450V (No Client)
Samsung GSM	SGH-i450V (Using Client)
Samsung GSM	SGH-X450
Samsung GSM	SGH-T456 Gravity
Samsung GSM	SGH-i458 (No Client)
Samsung GSM	SGH-i458 (Using Client)
Samsung GSM	SGH-T459 Gravity
Samsung GSM	SGH-X460
Samsung GSM	SGH-i467 Galaxy Note 8.0
Samsung GSM	SGH-T469 Gravity 2
Samsung GSM	SHV-E400S Galaxy Golden
Samsung GSM	SHV-E470S Galaxy S4 Active
Samsung GSM	SGH-X475
Samsung GSM	SGH-T479 Gravity 3
Samsung GSM	SGH-T479B
Samsung GSM	SGH-D480
Samsung GSM	SGH-F480 Tocco
Samsung GSM	SGH-F480i
Samsung GSM	SGH-F480T
Samsung GSM	SGH-X480
Samsung GSM	SGH-X481
Samsung GSM	SGH-E490
Samsung GSM	SGH-F490
Samsung GSM	SGH-F490V
Samsung GSM	SGH-X495
Samsung GSM	SGH-X497
Samsung GSM	SGH-I497 Galaxy Tab 2 10.1
Samsung GSM	SGH-T499 Dart
Samsung GSM	SGH-T499Y Galaxy Mini
Samsung GSM	SGH-D500
Samsung GSM	SGH-E500
Samsung GSM	SM-A500FQ Galaxy A5
Samsung GSM	SM-A500FU Galaxy A5
Samsung GSM	SM-E500F Galaxy E5
Samsung GSM	SM-J500F Galaxy J5
Samsung GSM	SM-J500FN Galaxy J5
Samsung GSM	SM-J500H Galaxy J5
Samsung GSM	SM-J500M Galaxy J5
Samsung GSM	SM-J5008 Galaxy J5 Duos
Samsung GSM	SM-E500M Galaxy E5
Samsung GSM	SM-A500F Galaxy A5
Samsung GSM	SM-A500H Galaxy A5
Samsung GSM	SM-A500W Galaxy A5
Samsung GSM	SM-A505FN_DS Galaxy A50
Samsung GSM	SM-A3050_DS Galaxy A40s
Samsung GSM	SM-M305M_DS Galaxy M30
Samsung GSM	SM-A6060 Galaxy A60
Samsung GSM	SM-A505G_DS Galaxy A50
Samsung GSM	SM-A510F Galaxy A5 2016
Samsung GSM	SM-J510F Galaxy J5
Samsung GSM	SM-J5108 Galaxy J5
Samsung GSM	SM-G5700 Galaxy J5 Prime

Samsung GSM	SM-G570F Galaxy J5 Prima Duos
Samsung GSM	SM-G570M Galaxy J5 Prime
Samsung GSM	SM-J510FN Galaxy J5
Samsung GSM	SM-J510MN Galaxy J5 Metal
Samsung GSM	SM-J530F Galaxy J5 Pro
Samsung GSM	SM-J530G_DS Galaxy J5 Pro
Samsung GSM	SM-J530Y Galaxy J5 Pro
Samsung GSM	Fake Samsung SM-A500F Galaxy A5
Samsung GSM	SM-A500M Galaxy A5
Samsung GSM	SM-A510M Galaxy A5 2016
Samsung GSM	SM-T580 Galaxy Tab A (2016)
Samsung GSM	SM-T595 Galaxy Tab A
Samsung GSM	SM-T590 Galaxy Tab A
Samsung GSM	SM-A606Y_DS Galaxy A60
Samsung GSM	SM-A700F Galaxy A7
Samsung GSM	SM-A710F Galaxy A7
Samsung GSM	SM-A720F Galaxy A7 2017
Samsung GSM	SM-A730F Galaxy A8+ 2018
Samsung GSM	SM-A750FN Galaxy A7 (2018)
Samsung GSM	SM-A750FN Galaxy A7 (2018) duos
Samsung GSM	SM-A710M Galaxy A7 2016
Samsung GSM	SGH-F500
Samsung GSM	SGH-P500
Samsung GSM	SGH-S500
Samsung GSM	SGH-X500
Samsung GSM	SGH-Z500
Samsung GSM	SGH-A501
Samsung GSM	SGH-S501i
Samsung GSM	SGH-X507
Samsung GSM	SGH-T509
Samsung GSM	SGH-C510
Samsung GSM	SGH-P510
Samsung GSM	SGH-X510
Samsung GSM	SGH-Z510
Samsung GSM	SGH-A517
Samsung GSM	SGH-B518
Samsung GSM	SGH-T519 Trace
Samsung GSM	SM-T520 Galaxy Tab Pro 10.1
Samsung GSM	SGH-B520b
Samsung GSM	SGH-C520
Samsung GSM	SGH-D520
Samsung GSM	SGH-i520V
Samsung GSM	SGH-P520 Armani
Samsung GSM	SGH-X520
Samsung GSM	SM-T525 Galaxy Tab Pro 10.1
Samsung GSM	SGH-i527 Galaxy Mega
Samsung GSM	SGH-T528G
Samsung GSM	SGH-E530
Samsung GSM	SGH-X530
Samsung GSM	SM-T530 Galaxy Tab 4 7.0
Samsung GSM	SM-T530NU Galaxy Tab 4 10.1
Samsung GSM	SM-T530NN Galaxy Tab 4 10.1
Samsung GSM	SM-G530H Galaxy Grand Prime
Samsung GSM	SM-G530M Galaxy Grand Prime
Samsung GSM	SM-G530A Galaxy Grand Prime

Samsung GSM	SM-G530AZ Galaxy Grand Prime
Samsung GSM	SM-G530FZ Galaxy Grand Prime
Samsung GSM	SM-G530W Galaxy Grand Prime
Samsung GSM	SM-A5000 Galaxy A5
Samsung GSM	SM-A5100 Galaxy A5
Samsung GSM	SM-A520F Galaxy A5 2017
Samsung GSM	SM-A520FDS Galaxy A5 2017
Samsung GSM	SM-A520W Galaxy A5 2017
Samsung GSM	SM-A530F Galaxy A8 2018
Samsung GSM	SM-A530N Galaxy A8 2018
Samsung GSM	SM-A530W Galaxy A8 2018
Samsung GSM	SM-T510 Galaxy Tab A
Samsung GSM	SM-T515 Galaxy Tab A
Samsung GSM	SM-S757BL Galaxy J7 Crown
Samsung GSM	SM-T720 Galaxy Tab S5e
Samsung GSM	SM-J810M_DS Galaxy J8
Samsung GSM	SM-G530T Galaxy Grand Prime
Samsung GSM	SM-G530T1 Galaxy Grand Prime
Samsung GSM	SM-G5308W Galaxy Grand Prime
Samsung GSM	SM-T531 Galaxy Tab 4 10.1
Samsung GSM	SM-G531H Galaxy Grand Prime
Samsung GSM	SM-G531F Galaxy Grand Prime
Samsung GSM	SM-G531M Galaxy Grand Prime
Samsung GSM	SM-T535 Galaxy Tab 4 10.1
Samsung GSM	SGH-i537 Galaxy S4 Active
Samsung GSM	SM-T537A Galaxy Tab 4
Samsung GSM	SGH-T539 Beat
Samsung GSM	SGH-Z540
Samsung GSM	SGH-i547 Galaxy Rugby Pro
Samsung GSM	SGH-i547C Galaxy Rugby Pro
Samsung GSM	SM-T550 Galaxy Tab A 9.7
Samsung GSM	SM-T585 Galaxy Tab A 10.1 2016
Samsung GSM	SM-B550H Xcover 550
Samsung GSM	SGH-i550 (No Client)
Samsung GSM	SGH-i550W (No Client)
Samsung GSM	SM-G550T Galaxy On5
Samsung GSM	SM-S550TL Galaxy On5
Samsung GSM	SM-G550T1 Galaxy On5
Samsung GSM	SM-G5500 Galaxy On5
Samsung GSM	SM-G5520 Galaxy On5 Neo 2016
Samsung GSM	SGH-i550 (Using Client)
Samsung GSM	SGH-i550W (Using Client)
Samsung GSM	SGH-A551
Samsung GSM	SGH-T559 Comeback
Samsung GSM	SGH-i560 (No Client)
Samsung GSM	SGH-i560 (Using Client)
Samsung GSM	SGH-i560V (No Client)
Samsung GSM	SGH-i560V (Using Client)
Samsung GSM	SM-T560 Galaxy Tab E 9.6
Samsung GSM	SM-T561 Galaxy Tab E 9.6
Samsung GSM	SM-T560NU Galaxy Tab E 9.6
Samsung GSM	SM-T378V Galaxy Tab E
Samsung GSM	SGH-Z560V
Samsung GSM	SGH-A561
Samsung GSM	SGH-T566 Corby Touch

Samsung GSM	SGH-E570
Samsung GSM	SGH-i577 Galaxy Exhilarate
Samsung GSM	SGH-T589 Gravity Smart
Samsung GSM	SGH-T589R Galaxy Q
Samsung GSM	SGH-E590
Samsung GSM	SGH-A597 Eternity 2
Samsung GSM	SGH-T599
Samsung GSM	SGH-T599N Galaxy Exhibit
Samsung GSM	SGH-D600
Samsung GSM	SGH-E600
Samsung GSM	SGH-G600
Samsung GSM	SGH-i600 BlackJack
Samsung GSM	SGH-J600
Samsung GSM	SGH-J600E
Samsung GSM	SGH-L600
Samsung GSM	SCH-i925 Galaxy Tab 10.1 Note
Samsung GSM	SM-J600G_DS Galaxy J6
Samsung GSM	SM-J600F Galaxy J6 (2018)
Samsung GSM	SM-J600FN_DS Galaxy J6
Samsung GSM	SM-J260T1 Galaxy J2
Samsung GSM	SM-A600P Galaxy A6
Samsung GSM	SM-A750GN_DS Galaxy A7
Samsung GSM	SM-G8870_DS Galaxy A8s
Samsung GSM	SM-J720M_DS Galaxy J7 Duo
Samsung GSM	SM-J737V Galaxy J7 Verizon
Samsung GSM	SM-J610G_DS Galaxy J6 Plus
Samsung GSM	SM-J610FN_DS Galaxy J6 Plus
Samsung GSM	SM-P600 Galaxy Note 10.1
Samsung GSM	SGH-U600
Samsung GSM	SGH-X600
Samsung GSM	SM-P601 Galaxy Note 10.1
Samsung GSM	SM-P602 Galaxy Note 10.1
Samsung GSM	SM-A600A Galaxy A6
Samsung GSM	SM-A600FN Galaxy A6 (2018)
Samsung GSM	SM-A605FN_DS Galaxy A6+
Samsung GSM	SM-A605G_DS Galaxy A6+
Samsung GSM	SM-A605GN Galaxy A6+ 2018
Samsung GSM	SM-P607T Galaxy Note 10.1
Samsung GSM	SM-P605 Galaxy Note 10.1
Samsung GSM	SGH-i607 BlackJack
Samsung GSM	SGH-T609
Samsung GSM	SM-G610F Galaxy J7 Prime
Samsung GSM	SM-G611F_DS Galaxy J7 Prime 2
Samsung GSM	SM-G610M Galaxy J7 Prime
Samsung GSM	SM-G615F Galaxy J7 Max
Samsung GSM	SGH-J610
Samsung GSM	SGH-M610
Samsung GSM	SGH-i617 BlackJack II
Samsung GSM	SGH-T619
Samsung GSM	SGH-E620
Samsung GSM	SGH-i620
Samsung GSM	SGH-M620
Samsung GSM	SGH-i627
Samsung GSM	SGH-M628
Samsung GSM	SGH-T629

Samsung GSM	SGH-E630
Samsung GSM	SGH-J630
Samsung GSM	SGH-Z630
Samsung GSM	SGH-E635
Samsung GSM	SGH-X636
Samsung GSM	SGH-A637
Samsung GSM	SGH-i637 Jack
Samsung GSM	SGH-T639
Samsung GSM	SGH-i640V
Samsung GSM	SGH-X640
Samsung GSM	SGH-X650
Samsung GSM	SGH-Z650i
Samsung GSM	SGH-T659 Scarlet
Samsung GSM	SGH-X660
Samsung GSM	SGH-A667T Evergreen
Samsung GSM	SGH-i677 Focus Flash (USB)
Samsung GSM	SGH-i677 Focus Flash (BT)
Samsung GSM	SM-T677A Galaxy View
Samsung GSM	SGH-T669 Gravity T
Samsung GSM	SGH-T669B Gravity T
Samsung GSM	SGH-T679 Exhibit II 4G
Samsung GSM	SGH-T679M Galaxy W 4G
Samsung GSM	SGH-X680
Samsung GSM	SGH-A687 Strive
Samsung GSM	SGH-i688
Samsung GSM	SGH-A697 Sunburst
Samsung GSM	SGH-T699 Galaxy S Relay 4G
Samsung GSM	SM-J700F Galaxy J7
Samsung GSM	SM-J700H Galaxy J7
Samsung GSM	SM-J700M Galaxy J7
Samsung GSM	SM-J700P Galaxy J7
Samsung GSM	SM-J700T Galaxy J7
Samsung GSM	SM-J700T1 Galaxy J7
Samsung GSM	SM-J701F Galaxy J7 Core
Samsung GSM	SM-J701M_DS Galaxy J7 Neo
Samsung GSM	SM-J701F_DS Galaxy J7 Core
Samsung GSM	SM-E700F Galaxy E7
Samsung GSM	SM-E700M Galaxy E7
Samsung GSM	SM-J710F Galaxy J7
Samsung GSM	SM-J710FN Galaxy J7
Samsung GSM	SM-C710F_DS Galaxy J7+
Samsung GSM	SM-S727VL Galaxy J7 Sky Pro
Samsung GSM	SM-J730F Galaxy J7 Pro
Samsung GSM	SM-J730FM Galaxy J7
Samsung GSM	SM-J730G_DS Galaxy J7 Pro
Samsung GSM	SM-J730GM_DS Galaxy J7 Pro
Samsung GSM	SM-J737A Galaxy J7 2018
Samsung GSM	SM-J737T Galaxy J7 Star
Samsung GSM	SM-J737T1 Galaxy J7 Star
Samsung GSM	SM-J737P Galaxy J7 Refine
Samsung GSM	SM-J737U Galaxy J7 Top
Samsung GSM	SM-J737VPP Galaxy J7
Samsung GSM	SM-A7100 Galaxy A7
Samsung GSM	SM-J7108 Galaxy J7
Samsung GSM	SGH-E700

Samsung GSM	SGH-F700v
Samsung GSM	SGH-J700
Samsung GSM	SGH-L700
Samsung GSM	SGH-X700
Samsung GSM	SGH-U700
Samsung GSM	SGH-A701
Samsung GSM	SGH-E705
Samsung GSM	SGH-J706
Samsung GSM	SGH-A707 SYNC
Samsung GSM	SM-T700 Galaxy Tab S
Samsung GSM	SM-T707A Galaxy Tab S 8.4
Samsung GSM	SM-T705W Galaxy Tab S 8.4
Samsung GSM	SM-T719 Galaxy Tab S2
Samsung GSM	SGH-J708
Samsung GSM	SGH-J708i
Samsung GSM	SCH-P709E Galaxy Mega Plus
Samsung GSM	SGH-T709
Samsung GSM	SGH-E710
Samsung GSM	SM-G710 Galaxy Grand 2
Samsung GSM	SGH-A711
Samsung GSM	SGH-E715
Samsung GSM	SGH-A717
Samsung GSM	SGH-i717 Galaxy Note
Samsung GSM	SGH-I717D Galaxy Note
Samsung GSM	SGH-i717M Galaxy Note
Samsung GSM	SGH-i717R Galaxy Note
Samsung GSM	SGH-i718
Samsung GSM	SGH-i718+
Samsung GSM	SGH-T719
Samsung GSM	SGH-E720
Samsung GSM	SGH-S720i
Samsung GSM	SGH-Z720
Samsung GSM	SGH-A727
Samsung GSM	SM-J727A Galaxy J7 (2017)
Samsung GSM	SM-J727AZ Galaxy J7
Samsung GSM	SM-J727P Galaxy J7 Perx
Samsung GSM	SM-J727T Galaxy J7 Prime 2017
Samsung GSM	SM-J727T1 Galaxy J7 Prime 2017
Samsung GSM	SM-J727VPP Galaxy J7 2017
Samsung GSM	SGH-i727 Galaxy S II Skyrocket
Samsung GSM	SM-J810F_DS Galaxy J8
Samsung GSM	SM-J810G_DS Galaxy J8
Samsung GSM	SM-J810Y Galaxy J8
Samsung GSM	SM-N915T Galaxy Note Edge
Samsung GSM	SM-N9500 Galaxy Note 8
Samsung GSM	SM-N950U Galaxy Note 8
Samsung GSM	SM-N950U1 Galaxy Note 8
Samsung GSM	SM-N950F Galaxy Note 8
Samsung GSM	SM-N950W Galaxy Note 8
Samsung GSM	SM-N960F_DS Galaxy Note 9
Samsung GSM	SM-N960F Galaxy Note 9
Samsung GSM	SM-N960W Galaxy Note 9
Samsung GSM	SM-N960U Galaxy Note 9
Samsung GSM	SM-N960U1 Galaxy Note 9
Samsung GSM	SGH-i727R Galaxy S II

Samsung GSM	SGH-i728
Samsung GSM	SGH-T729 Blast
Samsung GSM	SGH-E730
Samsung GSM	SGH-P730
Samsung GSM	SGH-P735
Samsung GSM	SGH-S730i
Samsung GSM	SM-G730A Galaxy S III Mini
Samsung GSM	SGH-S730G Galaxy Discover
Samsung GSM	SGH-S730M Galaxy Discover
Samsung GSM	SM-G730W8 Galaxy S III Mini
Samsung GSM	SGH-A736
Samsung GSM	SGH-A737
Samsung GSM	SGH-T739 Katalyst
Samsung GSM	SGH-E740
Samsung GSM	SGH-T746
Samsung GSM	SGH-A747 SLM
Samsung GSM	SGH-T749 Highlight
Samsung GSM	SM-N750 Galaxy Note 3 Neo
Samsung GSM	SM-S320VL Galaxy Sky
Samsung GSM	SCH-S735C Galaxy Discover
Samsung GSM	SM-N750S Galaxy Note 3 Neo
Samsung GSM	SGH-J750
Samsung GSM	SGH-T759 Exhibit 4G
Samsung GSM	SGH-E760
Samsung GSM	SGH-L760
Samsung GSM	SGH-A766 Propel
Samsung GSM	SGH-T769 Galaxy S Blaze 4G
Samsung GSM	SGH-i747 Galaxy S III
Samsung GSM	SGH-i747M Galaxy S III
Samsung GSM	SGH-I616
Samsung GSM	SM-G750A Galaxy Mega 2
Samsung GSM	SM-G750F Galaxy Mega 2
Samsung GSM	SM-G750H Galaxy Mega 2 Duos
Samsung GSM	SM-G7508Q Galaxy Mega 2
Samsung GSM	SGH-I757M Galaxy S II
Samsung GSM	SCH-i770 Saga
Samsung GSM	SM-N770F_DS Galaxy Note 10 Lite
Samsung GSM	SM-A315F_DS Galaxy A31
Samsung GSM	SGH-I777 Galaxy S II
Samsung GSM	SM-B780A Rugby 4
Samsung GSM	SM-B780W Rugby 4
Samsung GSM	SGH-J808E
Samsung GSM	SGH-A847 Rugby II
Samsung GSM	SGH-A847D Rugby II
Samsung GSM	SGH-A847R Rugby II
Samsung GSM	SGH-A885 Advance
Samsung GSM	SGH-A886 Forever
Samsung GSM	SM-G850A Galaxy Alpha
Samsung GSM	SM-G850M Galaxy Alpha
Samsung GSM	SM-G850F Galaxy Alpha
Samsung GSM	SM-G850K Galaxy Alpha
Samsung GSM	SM-G850W Galaxy Alpha
Samsung GSM	SGH-T869 Galaxy Tab 7.0 Plus
Samsung GSM	SGH-T899M ATIV S (USB)
Samsung GSM	SGH-T899M ATIV S (BT)

Samsung GSM	SM-N900A Galaxy Note 3
Samsung GSM	SM-A300M Galaxy A3
Samsung GSM	SM-N900U Galaxy Note 3
Samsung GSM	SM-N900K Galaxy Note 3
Samsung GSM	SM-N900Q Galaxy Note 3
Samsung GSM	SM-G900T Galaxy S5
Samsung GSM	SM-G900H Galaxy S5
Samsung GSM	SM-N900S Galaxy Note 3
Samsung GSM	SM-T900 Galaxy Tab Pro 12.2
Samsung GSM	SM-N900T Galaxy Note 3
Samsung GSM	SM-G900R4 Galaxy S5
Samsung GSM	SM-S978L Galaxy E5
Samsung GSM	SM-G9008W Galaxy S5 Duos
Samsung GSM	SM-G9008V Galaxy S5
Samsung GSM	SM-G9009D Galaxy S5
Samsung GSM	SM-P900 Galaxy Note Pro 12.2
Samsung GSM	SM-P907A Galaxy Note Pro
Samsung GSM	SC-05G (Galaxy S6)
Samsung GSM	SM-G920A Galaxy S6
Samsung GSM	SM-G920i Galaxy S6
Samsung GSM	SM-G920F Galaxy S6
Samsung GSM	SM-G920FD Galaxy S6
Samsung GSM	Fake Samsung SM-G920F Galaxy S6
Samsung GSM	SM-G920T Galaxy S6
Samsung GSM	SM-G920T1 Galaxy S6
Samsung GSM	SM-G9200 Galaxy S6
Samsung GSM	SM-N920R4 Galaxy Note 5
Samsung GSM	SM-G970F Galaxy S10e
Samsung GSM	SM-S367VL Galaxy J3 Orbit
Samsung GSM	SM-S767VL Galaxy J7 Crown Prepaid
Samsung GSM	SM-G975F Galaxy S10 Plus
Samsung GSM	SM-G9750 Galaxy S10 Plus
Samsung GSM	SM-G973F_DS Galaxy S10
Samsung GSM	SM-G9700 Galaxy S10e
Samsung GSM	SM-G970U Galaxy S10e
Samsung GSM	SM-G9208 Galaxy S6
Samsung GSM	SM-N9200 Galaxy Note 5
Samsung GSM	SM-N9208 Galaxy Note 5
Samsung GSM	SM-N920T Galaxy Note 5
Samsung GSM	SM-N920S Galaxy Note 5
Samsung GSM	SM-G920W8 Galaxy S6
Samsung GSM	SM-G925A Galaxy S6 Edge
Samsung GSM	SM-G925F Galaxy S6 Edge
Samsung GSM	SM-G925i Galaxy S6 Edge
Samsung GSM	SM-G925W8 Galaxy S6 Edge
Samsung GSM	SM-G9287 Galaxy S6 Edge+
Samsung GSM	SM-G925T Galaxy S6 Edge
Samsung GSM	SM-G9250 Galaxy S6 Edge
Samsung GSM	SM-G9280 Galaxy S6 Edge+
Samsung GSM	404SC (Galaxy S6 Edge)
Samsung GSM	SCV31 Galaxy S6 Edge
Samsung GSM	SM-A920F_DS Galaxy A9
Samsung GSM	SM-G930A Galaxy S7
Samsung GSM	SM-G930AZ Galaxy S7
Samsung GSM	SM-G930S Galaxy S7

Samsung GSM	SM-G930U Galaxy S7
Samsung GSM	SM-G930F Galaxy S7
Samsung GSM	SM-G930W8 Galaxy S7
Samsung GSM	SM-G930FD Galaxy S7 Dous
Samsung GSM	SM-G930K Galaxy S7
Samsung GSM	SM-G973U1 Galaxy S10
Samsung GSM	SM-G930T Galaxy S7
Samsung GSM	SM-G930T1 Galaxy S7
Samsung GSM	SM-G930R6 Galaxy S7
Samsung GSM	SM-G935A Galaxy S7 Edge
Samsung GSM	SM-G930L Galaxy S7
Samsung GSM	SM-G935L Galaxy S7 Edge
Samsung GSM	SM-G935U Galaxy S7 edge
Samsung GSM	SM-G935W8 Galaxy S7 Edge
Samsung GSM	SM-G9350 Galaxy S7 Edge
Samsung GSM	SM-G935F Galaxy S7 Edge
Samsung GSM	SM-G935FD Galaxy S7 Edge
Samsung GSM	SM-G935K Galaxy S7 Edge
Samsung GSM	SM-G935S Galaxy S7 Edge
Samsung GSM	SM-G935T Galaxy S7 Edge
Samsung GSM	SM-G950U Galaxy S8
Samsung GSM	SM-G950U1 Galaxy S8
Samsung GSM	SM-N976N Galaxy Note 10 Plus 5G
Samsung GSM	SM-G9500 Galaxy S8
Samsung GSM	SM-G950N Galaxy S8
Samsung GSM	SM-G950W Galaxy S8
Samsung GSM	SM-G9650_DS Galaxy S9+
Samsung GSM	SM-G965F Galaxy S9+
Samsung GSM	SM-G965N Galaxy S9+
Samsung GSM	SM-G965W Galaxy S9+
Samsung GSM	SM-G9600_DS Galaxy S9
Samsung GSM	SM-G960F Galaxy S9
Samsung GSM	SM-G960U Galaxy S9
Samsung GSM	SM-G960U1 Galaxy S9
Samsung GSM	SM-G960W Galaxy S9
Samsung GSM	SM-G965U Galaxy S9+
Samsung GSM	SM-G965U1 Galaxy S9+
Samsung GSM	SM-C7100 Galaxy C8
Samsung GSM	SM-S766C Galaxy Stardust
Samsung GSM	SM-G950F Galaxy S8
Samsung GSM	SM-G950FD Galaxy S8
Samsung GSM	SM-G9550 Galaxy S8+
Samsung GSM	SM-G955N Galaxy S8+
Samsung GSM	SM-G955FD Galaxy S8+
Samsung GSM	SM-G955F Galaxy S8+
Samsung GSM	SM-G955U Galaxy S8+
Samsung GSM	SM-G955U1 Galaxy S8+
Samsung GSM	SM-G955W Galaxy S8+
Samsung GSM	SM-A2070_DS Galaxy A20s
Samsung GSM	GT-I6330C
Samsung GSM	GT-I6410 M1
Samsung GSM	GT-I8320 H1
Samsung GSM	SGH-A767 Propel
Samsung GSM	SGH-E770
Samsung GSM	SGH-L770

Samsung GSM	SGH-L770V
Samsung GSM	SGH-A777
Samsung GSM	SGH-T779 Galaxy Tab 2 10.1
Samsung GSM	SGH-A796 Flight
Samsung GSM	SGH-A797 Flight
Samsung GSM	SGH-D780
Samsung GSM	SGH-E780
Samsung GSM	SGH-i780
Samsung GSM	SGH-E790
Samsung GSM	SGH-D800
Samsung GSM	SGH-E800
Samsung GSM	SGH-G800
Samsung GSM	SGH-J800 Luxe
Samsung GSM	SGH-U800
Samsung GSM	SM-T805W Galaxy Tab S 10.5
Samsung GSM	SGH-D807
Samsung GSM	SM-T807A Galaxy Tab S
Samsung GSM	SM-T807T Galaxy Tab S 10.5
Samsung GSM	SGH-T809
Samsung GSM	SGH-G810 (No Client)
Samsung GSM	SGH-G810 (Using Client)
Samsung GSM	SGH-L810V
Samsung GSM	SM-T810 Galaxy Tab S2 9.7
Samsung GSM	SM-T818W Galaxy Tab S2
Samsung GSM	SM-T819 Galaxy Tab S2
Samsung GSM	SM-T813 Galaxy Tab S2
Samsung GSM	SGH-A811
Samsung GSM	SGH-A817 Solstice 2
Samsung GSM	SGH-T819
Samsung GSM	SGH-D820
Samsung GSM	SM-T817A Galaxy Tab S2
Samsung GSM	SM-A800YZ Galaxy A8
Samsung GSM	SGH-E820
Samsung GSM	SM-S820L Galaxy Core Prime
Samsung GSM	SGH-X820
Samsung GSM	SGH-A821
Samsung GSM	SGH-A827 Access
Samsung GSM	SGH-i827 Galaxy Appeal
Samsung GSM	SGH-i827D Ace Q
Samsung GSM	SGH-D830
Samsung GSM	SGH-X830
Samsung GSM	SGH-X830N
Samsung GSM	SGH-A837 Rugby
Samsung GSM	SM-T837A Tab S4
Samsung GSM	SGH-E838
Samsung GSM	SGH-T839 Sidekick 4G
Samsung GSM	SGH-D840
Samsung GSM	SGH-E840
Samsung GSM	SGH-i847 Rugby Smart
Samsung GSM	SGH-T849 Galaxy Tab
Samsung GSM	SGH-i857 Doubletime
Samsung GSM	SM-G870A Galaxy S5 Active
Samsung GSM	SM-G870W Galaxy S5 Active
Samsung GSM	SC-02G Galaxy S5 Active
Samsung GSM	SC-02E(GALAXY NOTE II)

Samsung GSM	SC-02F Galaxy J
Samsung GSM	SC-02H Galaxy S7 Edge
Samsung GSM	SC-04J Galaxy Feel
Samsung GSM	SC-06D(GALAXY SIII)
Samsung GSM	SGH-L870 (No Client)
Samsung GSM	SGH-L870 (Using Client)
Samsung GSM	SGH-A887 Solstice
Samsung GSM	SGH-T889 Galaxy Note II
Samsung GSM	SGH-T889V Galaxy Note II
Samsung GSM	SM-G890A Galaxy S6 Active
Samsung GSM	SM-G891A Galaxy S7 Active
Samsung GSM	SGH-i896 Captivate
Samsung GSM	SGH-i897 Captivate
Samsung GSM	SM-S890L Galaxy S4 Mini
Samsung GSM	SM-G900A Galaxy S5
Samsung GSM	SM-G900i Galaxy S5
Samsung GSM	SM-G900F Galaxy S5
Samsung GSM	Fake SM-G900F Galaxy S5
Samsung GSM	Fake SM-G9006V Galaxy S5
Samsung GSM	SM-G900FQ Galaxy S5
Samsung GSM	SM-A300F Galaxy A3
Samsung GSM	SM-A310F Galaxy A3 (2016)
Samsung GSM	SM-A320FL Galaxy A3 (2017)
Samsung GSM	SM-A300FU Galaxy A3 LTE
Samsung GSM	SM-G310HN Galaxy Ace Style
Samsung GSM	SM-G313ML Galaxy Ace 4 Lite
Samsung GSM	SM-G357FZ Galaxy Ace 4 Style
Samsung GSM	SM-G901F Galaxy S5 Plus
Samsung GSM	SM-P905 Galaxy Note Pro 12.2
Samsung GSM	SM-G906K Galaxy S5 LTE-A
Samsung GSM	SM-G906L Galaxy S5 LTE-A
Samsung GSM	SM-G906S Galaxy S5
Samsung GSM	SM-G910S Galaxy Round
Samsung GSM	SM-G900L Galaxy S5
Samsung GSM	SM-G900M Galaxy S5
Samsung GSM	SM-G900S Galaxy S5
Samsung GSM	SM-G900W8 Galaxy S5
Samsung GSM	SM-G903F Galaxy S5 Neo
Samsung GSM	SM-G903M Galaxy S5 Neo
Samsung GSM	SGH-I908E
Samsung GSM	SGH-I908L
Samsung GSM	SM-N910A Galaxy Note 4
Samsung GSM	SM-N910F Galaxy Note 4
Samsung GSM	SM-N910C Galaxy Note 4
Samsung GSM	SM-N910H Galaxy Note 4
Samsung GSM	SM-N910G Galaxy Note 4
Samsung GSM	SM-N9106W Galaxy Note 4
Samsung GSM	SM-N910L Galaxy Note 4
Samsung GSM	SM-N910T Galaxy Note 4
Samsung GSM	SM-N910S Galaxy Note 4
Samsung GSM	SM-N910U Galaxy Note 4
Samsung GSM	SM-T827R4 Galaxy Tab S3
Samsung GSM	SM-N910R4 Galaxy Note 4
Samsung GSM	SM-N910W8 Galaxy Note 4
Samsung GSM	SM-N916S Galaxy Note 4 S-LTE

Samsung GSM	SM-N9150 Galaxy Note Edge
Samsung GSM	SM-N915A Galaxy Note Edge
Samsung GSM	SM-N915F Galaxy Note Edge
Samsung GSM	SM-N915FY Galaxy Note Edge
Samsung GSM	SM-N915K Galaxy Note Edge
Samsung GSM	SM-N915G Galaxy Note Edge
Samsung GSM	SM-N915S Galaxy Note Edge
Samsung GSM	SM-N915W8 Galaxy Note Edge
Samsung GSM	SM-S920L Galaxy Grand Prime
Samsung GSM	SC-01E(Galaxy Tab 7.7 Plus)
Samsung GSM	SC-01G Galaxy Note Edge
Samsung GSM	SCL23 Galaxy S5
Samsung GSM	SCL24 Galaxy Note Edge
Samsung GSM	SM-S975L Galaxy S4
Samsung GSM	SM-N9100 Galaxy Note 4
Samsung GSM	Fake Samsung SM-N9100 Galaxy Note 4
Samsung GSM	SGH-A927 Flight II
Samsung GSM	SM-N920A Galaxy Note 5
Samsung GSM	SM-N920C Galaxy Note 5
Samsung GSM	SM-N920i Galaxy Note 5
Samsung GSM	SM-N920F Galaxy Note 5
Samsung GSM	SM-G928A Galaxy S6 Edge+
Samsung GSM	SM-G928G Galaxy S6 Edge+
Samsung GSM	SM-G928i Galaxy S6 Edge+
Samsung GSM	SM-G928C Galaxy S6 Edge+
Samsung GSM	SM-G928F Galaxy S6 Edge+
Samsung GSM	SM-G903W Galaxy S5 Neo
Samsung GSM	SM-G928T Galaxy S6 Edge+
Samsung GSM	SGH-i927 Captivate Glide
Samsung GSM	SM-N930A Galaxy Note 7
Samsung GSM	SM-N930T Galaxy Note 7
Samsung GSM	SGH-i937 Focus S (USB)
Samsung GSM	SGH-i937 Focus S (BT)
Samsung GSM	SGH-S959G Galaxy S II
Samsung GSM	SGH-S970G Galaxy S4
Samsung GSM	SGH-T999 Galaxy S III
Samsung GSM	SGH-T999L Galaxy S III
Samsung GSM	SGH-T999N Galaxy S III
Samsung GSM	SGH-T999V Galaxy S III
Samsung GSM	GT-P1000 Galaxy Tab
Samsung GSM	GT-P1000N Galaxy Tab
Samsung GSM	GT-S5200
Samsung GSM	GT-S5200C
Samsung GSM	GT-S3550 Shark 3 (USB)
Samsung GSM	GT-S3550 Shark 3(Unlocked)
Samsung GSM	GT-S5660 Galaxy Gio
Samsung GSM	GT-S7070
Samsung GSM	SGH-S7330
Samsung GSM	SGH-S7350
Samsung GSM	SGH-M7500 Armani
Samsung GSM	GT-S7500L Galaxy Ace Plus
Samsung GSM	GT-S7500T
Samsung GSM	GT-S7562 Galaxy S Duos
Samsung GSM	SGH-i8510 INNOV8 (No Client)
Samsung GSM	SGH-i8510 INNOV8 (Using Client)

Samsung GSM	SGH-E860
Samsung GSM	SGH-A867 Eternity
Samsung GSM	SGH-E870
Samsung GSM	SGH-A877 Impression
Samsung GSM	SGH-T879 Galaxy Note
Samsung GSM	SGH-D880 Duos
Samsung GSM	SGH-E880
Samsung GSM	SGH-D888 Duos
Samsung GSM	SM-G892A Galaxy S8 Active
Samsung GSM	SM-G892U Galaxy S8 Active
Samsung GSM	SGH-A897 Mythic
Samsung GSM	SGH-D900
Samsung GSM	SGH-D900i
Samsung GSM	SGH-E900
Samsung GSM	SGH-i900 Omnia
Samsung GSM	SGH-i900 Player Addict
Samsung GSM	SM-N900 Galaxy Note 3
Samsung GSM	SM-N900W8 Galaxy Note 3
Samsung GSM	SGH-P900
Samsung GSM	SGH-U900 (USB)
Samsung GSM	SGH-U900 (BT)
Samsung GSM	SGH-i907 Epix
Samsung GSM	SGH-E910 Serene
Samsung GSM	SGH-i917 Focus (USB)
Samsung GSM	SGH-i917 Focus (BT)
Samsung GSM	SGH-M919 Galaxy S4
Samsung GSM	SGH-M919N Galaxy S4
Samsung GSM	SGH-M919V Galaxy S4
Samsung GSM	SGH-T919 Behold
Samsung GSM	SGH-T929 Memoir
Samsung GSM	SGH-T939 Behold II
Samsung GSM	SGH-T959 Vibrant
Samsung GSM	SGH-E950
Samsung GSM	SGH-i957 Galaxy Tab 8.9
Samsung GSM	SGH-T959V Galaxy S 4G
Samsung GSM	SGH-T959D Galaxy S Fascinate 3G+
Samsung GSM	SGH-T959W Galaxy S 4G
Samsung GSM	SCH-S968C Galaxy S III
Samsung GSM	SGH-D980
Samsung GSM	SGH-D988
Samsung GSM	SGH-T989 Galaxy S II
Samsung GSM	SGH-T989D Galaxy S II
Samsung GSM	SGH-A997 Rugby III
Samsung GSM	SGH-i997 Infuse 4G
Samsung GSM	SGH-i997R Infuse 4G
Samsung GSM	GT-E1050
Samsung GSM	GT-E1070M
Samsung GSM	GT-E1075L
Samsung GSM	GT-E1080
Samsung GSM	GT-E1081T
Samsung GSM	GT-E1085L
Samsung GSM	GT-E1086L
Samsung GSM	SGH-E1100
Samsung GSM	SGH-E1120
Samsung GSM	GT-E1125

Samsung GSM	GT-E1130B
Samsung GSM	GT-E1150
Samsung GSM	GT-E1170
Samsung GSM	GT-E1170i
Samsung GSM	GT-E1180
Samsung GSM	GT-E1190
Samsung GSM	GT-E1195L
Samsung GSM	GT-E1230 (TIM)
Samsung GSM	GT-E1230
Samsung GSM	SGH-E1310B
Samsung GSM	GT-E1360b
Samsung GSM	SM-G1650 Galaxy Folder 2
Samsung GSM	SM-W2014
Samsung GSM	B2100 Niagara
Samsung GSM	B2100 Solid Extreme
Samsung GSM	B2100 Xplorer
Samsung GSM	GT-E2100B
Samsung GSM	SM-T2105 Galaxy Tab 3 Kids
Samsung GSM	GT-E2120
Samsung GSM	GT-E2121
Samsung GSM	GT-E2121B
Samsung GSM	E2152 Pampas
Samsung GSM	GT-E2202
Samsung GSM	GT-E2210B Hello Kitty
Samsung GSM	SGH-E2210C
Samsung GSM	GT-E2220 Ch@t 222 (USB)
Samsung GSM	GT-E2220 Ch@t 222 (BT)
Samsung GSM	GT-E2252
Samsung GSM	GT-E2330
Samsung GSM	GT-E2230
Samsung GSM	GT-E2230L
Samsung GSM	GT-E2232
Samsung GSM	GT-M2310
Samsung GSM	GT-E2350B
Samsung GSM	GT-E2370 Xcover
Samsung GSM	GT-E2510
Samsung GSM	GT-M2520
Samsung GSM	GT-E2530 (USB)
Samsung GSM	GT-E2530 (BT)
Samsung GSM	GT-E2550 Monte Slider
Samsung GSM	GT-E2600
Samsung GSM	GT-B2700
Samsung GSM	GT-B2710 Makalu
Samsung GSM	GT-B2710 Xcover 271
Samsung GSM	SGH-M2710
Samsung GSM	SM-A3000 Galaxy A3
Samsung GSM	GT-C3010
Samsung GSM	GT-C3011 (USB)
Samsung GSM	GT-C3011 (BT)
Samsung GSM	SGH-S3030
Samsung GSM	SGH-C3050
Samsung GSM	GT-C3053 (USB)
Samsung GSM	GT-C3053 (BT)
Samsung GSM	GT-C3060
Samsung GSM	GT-P3100 Galaxy Tab 2 7.0

Samsung GSM	GT-S3100 Croy
Samsung GSM	GT-C3110
Samsung GSM	GT-P3110 Galaxy Tab 2 7.0
Samsung GSM	SGH-M3200 Beat s
Samsung GSM	GT-B3210 Corby Txt
Samsung GSM	GT-E3210 (USB)
Samsung GSM	GT-E3210 (BT)
Samsung GSM	GT-C3200 Monte Bar
Samsung GSM	GT-C3212 (USB)
Samsung GSM	GT-C3212 (BT)
Samsung GSM	GT-E3300
Samsung GSM	GT-C3780
Samsung GSM	GT-C3222 Ch@t 322 (USB)
Samsung GSM	GT-C3222W Ch@t 322 (USB)
Samsung GSM	GT-C3222 Ch@t 322 (BT)
Samsung GSM	GT-C3222W Ch@t 322 (BT)
Samsung GSM	GT-C3262 Champ Neo Duos
Samsung GSM	GT-C3300K Mini Star
Samsung GSM	GT-C3300I
Samsung GSM	GT-C3300k Champ
Samsung GSM	GT-C3303K Champ (USB)
Samsung GSM	GT-C3303K Champ (BT)
Samsung GSM	GT-B3310
Samsung GSM	GT-S3310
Samsung GSM	GT-B3313 Corby Mate
Samsung GSM	GT-C3322
Samsung GSM	GT-C3312 Champ Deluxe
Samsung GSM	GT-C3330 Champ 2
Samsung GSM	GT-S3350(Telcel) (USB)
Samsung GSM	GT-S3350(Telcel) (BT)
Samsung GSM	GT-C3350 Xcover 2 (USB)
Samsung GSM	GT-C3350 Xcover 2 (BT)
Samsung GSM	GT-S3350 Ch@t 335 (USB)
Samsung GSM	GT-S3350 Ch@t 335 (BT)
Samsung GSM	GT-S3370 Acton
Samsung GSM	GT-S3370 Mini Touch
Samsung GSM	GT-S3370 Pocket
Samsung GSM	GT-S3370B Acton
Samsung GSM	GT-S3370B Mini Touch
Samsung GSM	B3410 Star Qwerty
Samsung GSM	GT-B3410 Corby Plus
Samsung GSM	GT-B3410R Corby Plus (Rogers)
Samsung GSM	GT-B3410W
Samsung GSM	GT-C3500 Cha@t 350
Samsung GSM	S3500
Samsung GSM	C3510 Corby Pop
Samsung GSM	GT-C3510 Genoa
Samsung GSM	GT-C3630C
Samsung GSM	SM-G3502 Galaxy Trend 3
Samsung GSM	SM-G3502I Galaxy Trend 3
Samsung GSM	SGH-M3510 Beat b
Samsung GSM	GT-C3520 (USB)
Samsung GSM	GT-C3520 (BT)
Samsung GSM	GT-C3530
Samsung GSM	GT-S3570 Ch@t 357 (USB)

Samsung GSM	GT-S3570 Ch@t 357 (BT)
Samsung GSM	GT-C3590
Samsung GSM	GT-C3592 Duos
Samsung GSM	GT-C3595
Samsung GSM	SGH-S150G
Samsung GSM	SGH-S275G
Samsung GSM	SGH-S275M
Samsung GSM	SGH-S275R
Samsung GSM	SGH-S3600
Samsung GSM	GT-S3600I
Samsung GSM	GT-S3650 Corby
Samsung GSM	GT-S3653 Corby
Samsung GSM	S3653 Genio Touch
Samsung GSM	GT-C3730C
Samsung GSM	GT-C3750
Samsung GSM	GT-C3752 (USB)
Samsung GSM	GT-C3752 (BT)
Samsung GSM	GT-S3800W REX 70
Samsung GSM	SM-G3812 Galaxy Win Pro Duos
Samsung GSM	SM-G3815 Galaxy Express 2
Samsung GSM	GT-S3850 Corby II
Samsung GSM	SM-G3858 Galaxy Beam 2
Samsung GSM	GT-S3930c
Samsung GSM	GT-C5010E
Samsung GSM	SGH-S5050
Samsung GSM	SM-A5070_DS Galaxy A50s
Samsung GSM	SM-A507FN_DS Galaxy A50s
Samsung GSM	SM-A107F_DS Galaxy A10s
Samsung GSM	GT-C5110
Samsung GSM	GT-P5100 Galaxy Tab 10.1
Samsung GSM	GT-P5110 Galaxy Tab II 10.1
Samsung GSM	GT-N5110 Galaxy Note 8.0 WiFi
Samsung GSM	GT-P5113 Galaxy Tab 2 10.1
Samsung GSM	GT-N5120 Note 8.0 LTE
Samsung GSM	GT-C5130
Samsung GSM	GT-C5130 (Turkcell)
Samsung GSM	GT-S5150 Diva folder
Samsung GSM	GT-P5200 Galaxy Tab 3 10.1
Samsung GSM	GT-P5210 Galaxy Tab 3 10.1
Samsung GSM	GT-C5212 Fizz
Samsung GSM	GT-P5220 Galaxy Tab 3 10.1
Samsung GSM	GT-C5220
Samsung GSM	GT-S5220 Star 3
Samsung GSM	GT-S5222 STAR 3 DUOS
Samsung GSM	GT-S5222 Star 3
Samsung GSM	GT-S5229 Star3
Samsung GSM	GT-S5230 Tocco Lite
Samsung GSM	GT-S5230C
Samsung GSM	GT-S5230N Star
Samsung GSM	GT-S5233S Star
Samsung GSM	GT-S5233W Star
Samsung GSM	GT-S5253 Wave 525
Samsung GSM	GT-S5260 Star II
Samsung GSM	GT-S5280 Galaxy Star
Samsung GSM	GT-S5292 Star Deluxe Duos

Samsung GSM	GT-S5300 Galaxy Pocket
Samsung GSM	GT-S5301L Galaxy Pocket
Samsung GSM	GT-S5302 Galaxy Pocket Duos
Samsung GSM	GT-S5303 Galaxy Y Plus
Samsung GSM	GT-B5310 Corby Pro
Samsung GSM	GT-B5310r Corby Pro (Rogers)
Samsung GSM	GT-S5310 Pocket Neo
Samsung GSM	GT-S5320
Samsung GSM	GT-S5330 Wave 533
Samsung GSM	GT-B5330 Galaxy Ch@t
Samsung GSM	GT-S5380D Wave Y
Samsung GSM	GT-S5380G Wave Y
Samsung GSM	GT-S5350 Shark
Samsung GSM	GT-S5360 Galaxy Y
Samsung GSM	GT-S5360T Galaxy Y
Samsung GSM	GT-S5360L Galaxy Y
Samsung GSM	GT-i5500 Europa Galaxy 5
Samsung GSM	GT-I5503T
Samsung GSM	GT-B5510 Galaxy Y Pro
Samsung GSM	GT-i5510 Galaxy
Samsung GSM	GT-S5510
Samsung GSM	GT-i5510M Galaxy
Samsung GSM	GT-S5511T
Samsung GSM	GT-B5512 Galaxy Y Pro Duos
Samsung GSM	GT-S5560 Marvel
Samsung GSM	GT-S5570 Galaxy Mini
Samsung GSM	GT-S5570 Tass
Samsung GSM	GT-S5570i Galaxy Pop Plus
Samsung GSM	GT-S5600 Player Star
Samsung GSM	GT-S5600V
Samsung GSM	GT-S5603
Samsung GSM	GT-S5610 (USB)
Samsung GSM	GT-S5610 (BT)
Samsung GSM	GT-S5611
Samsung GSM	GT-S5620 Monte
Samsung GSM	GT-S5620 Onix
Samsung GSM	GT-S5628i
Samsung GSM	GT-S5630C
Samsung GSM	GT-M5650 Lindy
Samsung GSM	GT-M5650U Lindy
Samsung GSM	GT-S5690 Galaxy Xcover
Samsung GSM	GT-S5690M Galaxy Rugby
Samsung GSM	GT-S5690R Galaxy Rugby
Samsung GSM	GT-I5700 Galaxy Spica
Samsung GSM	GT-B5702C
Samsung GSM	GT-B5722 Duos
Samsung GSM	GT-S5750E Wave 575
Samsung GSM	GT-S5780 Wave 578
Samsung GSM	GT-I5800 Galaxy 3 Apollo
Samsung GSM	I5800 Galaxy 3 Teos
Samsung GSM	GT-I5800L
Samsung GSM	GT-I5801
Samsung GSM	GT-S5830 Galaxy Ace
Samsung GSM	GT-S5830 Galaxy Cooper
Samsung GSM	GT-S5830i Galaxy Ace

Samsung GSM	GT-S5839i Galaxy Ace
Samsung GSM	SM-G6000 Galaxy On7 Duos
Samsung GSM	GT-S6010 Galaxy Music
Samsung GSM	GT-S6012 Galaxy Music Duos
Samsung GSM	SM-A6058_DS Galaxy A9 Star Lite
Samsung GSM	GT-S6102 Galaxy Y Duos
Samsung GSM	GT-C6112
Samsung GSM	GT-P6200 Galaxy Tab 7.0 Plus
Samsung GSM	GT-P6210 Galaxy Tab Plus 7.0
Samsung GSM	GT-P6800 Galaxy Tab 7.7
Samsung GSM	GT-S6310N Galaxy Young
Samsung GSM	GT-S6310T Galaxy Young
Samsung GSM	GT-S6312 Galaxy Young Duos
Samsung GSM	SM-G130H Galaxy Young 2
Samsung GSM	SM-G130HN Galaxy Young 2
Samsung GSM	GT-I6320C
Samsung GSM	GT-S6500 Galaxy Mini 2
Samsung GSM	GT-S6500D Galaxy Mini 2
Samsung GSM	GT-S6500L Galaxy Mini 2
Samsung GSM	GT-S6700T
Samsung GSM	GT-S6790 Galaxy Fame Lite
Samsung GSM	GT-S6800 Galaxy Ace Advance
Samsung GSM	GT-S6802
Samsung GSM	GT-S6810M Galaxy Fame
Samsung GSM	GT-S6810P Galaxy Fame
Samsung GSM	GT-S6818 Galaxy Fame
Samsung GSM	GT-N7000 Galaxy Note
Samsung GSM	N7005 Galaxy Note LTE
Samsung GSM	GT-N7100 Galaxy Note II
Samsung GSM	GT-P7100 Galaxy Tab 10.1v
Samsung GSM	GT-N7102 Galaxy Note II
Samsung GSM	SM-G355H Galaxy Core 2 Duos
Samsung GSM	SM-G355HN Galaxy Core 2
Samsung GSM	SM-G355M Galaxy Core 2
Samsung GSM	SM-G6100 Galaxy On7 2016
Samsung GSM	SM-A700YD Galaxy A7 Duos
Samsung GSM	SM-A7000 Galaxy A7 Duos
Samsung GSM	SM-G7102 Galaxy Grand II
Samsung GSM	SM-G7105 Galaxy Grand 2
Samsung GSM	GT-N7105 Galaxy Note II
Samsung GSM	GT-N7105T Galaxy Note II
Samsung GSM	SM-G7106 Galaxy Grand 2
Samsung GSM	GT-N7108 Galaxy Note II
Samsung GSM	GT-N7108D Galaxy Note II
Samsung GSM	SM-G7108V Galaxy Grand 2
Samsung GSM	SM-J7109 Galaxy J7 (2016)
Samsung GSM	SM-J710MN_DS Galaxy J7 Metal 2016
Samsung GSM	SM-G7109 Galaxy Grand 2
Samsung GSM	GT-S7220 Ultra b
Samsung GSM	GT-S7230E Wave 723 Touchwiz
Samsung GSM	GT-S7250 Wave M
Samsung GSM	GT-S7262 Galaxy Star Plus
Samsung GSM	GT-S7270 Galaxy Ace 3
Samsung GSM	GT-S7275R Galaxy Ace 3
Samsung GSM	GT-B7300 OmniaLITE

Samsung GSM	GT-B7350 Omnia 4
Samsung GSM	GT-P7300 Galaxy Tab 8.9
Samsung GSM	GT-P7310 Galaxy Tab 8.9
Samsung GSM	GT-P7320 Galaxy Tab 8.9 LTE
Samsung GSM	GT-B7320 Omnia PRO
Samsung GSM	GT-B7330 OmniaPRO
Samsung GSM	GT-B7330B Messenger (Rogers)
Samsung GSM	GT-B7330B Scala (Bell)
Samsung GSM	GT-B7330r Messenger (Rogers)
Samsung GSM	GT-S7390 Trend Lite
Samsung GSM	GT-S7392 Galaxy Trend
Samsung GSM	GT-I7500 Galaxy
Samsung GSM	GT-I7500L Galaxy
Samsung GSM	GT-P7500 Galaxy Tab 10.1
Samsung GSM	SM-N7505 Galaxy Note 3 Neo
Samsung GSM	SM-N7506V Galaxy Note 3 Neo
Samsung GSM	SM-N7508V Galaxy Note 3 Neo
Samsung GSM	GT-B7510 Galaxy Pro
Samsung GSM	GT-P7510 Galaxy Tab 10.1
Samsung GSM	GT-S7530 (USB)
Samsung GSM	GT-S7530 (BT)
Samsung GSM	GT-S7550 Blue Earth
Samsung GSM	GT-S7560M Ace II X
Samsung GSM	GT-S7560 Galaxy Trend
Samsung GSM	GT-S7562C Galaxy Trend Duos
Samsung GSM	GT-S7572 Galaxy Trend II Duos
Samsung GSM	GT-S7568 Galaxy Trend
Samsung GSM	GT-S7580 Galaxy Trend Plus
Samsung GSM	GT-S7580L Galaxy Trend Plus
Samsung GSM	GT-S7582 Galaxy S Duos 2
Samsung GSM	GT-S7583T Galaxy Trend Plus
Samsung GSM	SGH-M7600
Samsung GSM	SGH-M7603 Beat DJ
Samsung GSM	GT-B7610 Omnia Pro
Samsung GSM	GT S7710 Galaxy Xcover 2
Samsung GSM	GT-B7722
Samsung GSM	SM-A8000 Galaxy A8
Samsung GSM	SM-A8000 Galaxy A8 Duos
Samsung GSM	GT-I8000 Omnia II
Samsung GSM	GT-N8000 Galaxy Note 10.1
Samsung GSM	GT-S8000 Jet
Samsung GSM	GT-N8013 Galaxy Note 10.1
Samsung GSM	GT-N8020 Galaxy Note 10.1
Samsung GSM	GT-P8110 Nexus 10
Samsung GSM	GT-i8150 Galaxy Wonder
Samsung GSM	GT-i8150T Galaxy Wonder
Samsung GSM	GT-i8160 Galaxy Ace 2
Samsung GSM	GT-I8180C
Samsung GSM	GT-i8190 Galaxy S III Mini
Samsung GSM	GT-i8190N Galaxy S III Mini
Samsung GSM	GT-i8190T Galaxy S III Mini
Samsung GSM	GT-I8190L Galaxy S III Mini
Samsung GSM	GT-I8200 Galaxy S III mini
Samsung GSM	GT-I8200N Galaxy S III Mini
Samsung GSM	GT-I8262 Galaxy Core

Samsung GSM	GT-I8268
Samsung GSM	SGH-S8300 Tocco Ultra
Samsung GSM	GT-S8003 Jet
Samsung GSM	GT-I8350 Omnia W (USB)
Samsung GSM	GT-I8350 Omnia W (BT)
Samsung GSM	SM-G8508S Galaxy Alpha
Samsung GSM	GT-S8500 Wave
Samsung GSM	GT-S8500M Wave
Samsung GSM	GT-i8530 Galaxy Beam
Samsung GSM	GT-S8530 Wave II
Samsung GSM	GT-I8552 Galaxy Win
Samsung GSM	GT-S8600 Wave 3
Samsung GSM	GT-I8700 Omnia 7 (USB)
Samsung GSM	GT-I8700 Omnia 7 (BT)
Samsung GSM	GT-I8730 Galaxy Express
Samsung GSM	GT-I8750 ATIV S (USB)
Samsung GSM	GT-I8750 ATIV S (BT)
Samsung GSM	SGH-M8800 Pixon
Samsung GSM	SGH-i8910 Omnia HD (No Client)
Samsung GSM	SGH-i8910 Omnia HD (Using Client)
Samsung GSM	GT-M8910 Pixon12
Samsung GSM	SM-A9000 Galaxy A9
Samsung GSM	C9000 Galaxy C9 Pro
Samsung GSM	GT-I9000 Galaxy S
Samsung GSM	GT-I9000M Galaxy S Vibrant
Samsung GSM	GT-I9000T Galaxy S
Samsung GSM	GT-I9001 Galaxy S Plus
Samsung GSM	SM-N9002 Galaxy Note 3 Duos
Samsung GSM	GT-I9003 Galaxy SCL
Samsung GSM	SM-N9005 Galaxy Note 3
Samsung GSM	SM-N9006 Galaxy Note 3
Samsung GSM	Fake Samsung GT-N9006 Galaxy Note 3
Samsung GSM	GT-I9008 Galaxy S
Samsung GSM	SM-N9008V Galaxy Note 3
Samsung GSM	SM-N9008S Galaxy Note 3
Samsung GSM	GT-I9020a Nexus S
Samsung GSM	GT-I9020T Nexus S
Samsung GSM	GT-i9023 Nexus S
Samsung GSM	GT-I9060 Galaxy Grand Neo
Samsung GSM	GT-I9060I Galaxy Grand Neo Plus
Samsung GSM	GT-I9060M Galaxy Grand Neo Plus
Samsung GSM	GT-I9060L Galaxy Grand Neo
Samsung GSM	GT-i9070 Galaxy S Advance
Samsung GSM	SM-A9100 Galaxy A9 Pro 2016
Samsung GSM	SM-N9108V Galaxy Note 4
Samsung GSM	SM-N9109W Galaxy Note 4
Samsung GSM	GT-I9082 Galaxy Grand
Samsung GSM	GT-I9082i Galaxy Grand Duos
Samsung GSM	GT-I9100 Galaxy S II
Samsung GSM	GT-i9100G Galaxy S II
Samsung GSM	GT-I9100M Galaxy S II
Samsung GSM	GT-I9100P Galaxy S II
Samsung GSM	GT-I9100T Galaxy S II
Samsung GSM	GT-i9103 Galaxy R
Samsung GSM	I9105P Galaxy S II Plus

Samsung GSM	GT-I9128E Galaxy Grand
Samsung GSM	GT-I9152 Galaxy Mega 5.8
Samsung GSM	GT-I9152P Galaxy Mega Plus
Samsung GSM	GT-I9158 Galaxy Mega
Samsung GSM	GT-I9168I Galaxy Grand Neo
Samsung GSM	i9105 Galaxy S+
Samsung GSM	GT-i9190 Galaxy S4 Mini
Samsung GSM	GT-I9192 Galaxy S4 Mini Duos
Samsung GSM	GT-i9195 Galaxy S4 Mini
Samsung GSM	GT-i9195I Galaxy S4 Mini
Samsung GSM	SHV-E370K Galaxy S4 Mini
Samsung GSM	SM-A9200_DS Galaxy A9s
Samsung GSM	SM-M205F Galaxy M20
Samsung GSM	GT-I9200 Galaxy Mega
Samsung GSM	GT-i9205 Samsung Galaxy Mega 6.3
Samsung GSM	SM-S907VL Galaxy S6
Samsung GSM	SM-G9209 Galaxy S6
Samsung GSM	GT-i9210 Galaxy S II LTE
Samsung GSM	GT-i9228 Galaxy Note
Samsung GSM	GT-i9230 Galaxy Golden
Samsung GSM	GT-i9235 Galaxy Golden
Samsung GSM	GT-I9250 Galaxy Nexus
Samsung GSM	GT-I9250M Galaxy Nexus
Samsung GSM	GT-I9260 Galaxy Premier
Samsung GSM	GT-I9295 Galaxy S4 Active
Samsung GSM	Fake Samsung I9300
Samsung GSM	Fake Samsung BP-I9300 Galaxy S3
Samsung GSM	SM-G9300 Galaxy S7
Samsung GSM	GT-I9300 Galaxy S III
Samsung GSM	GT-i9300i Galaxy S III Neo
Samsung GSM	GT-i9300i Galaxy S III Neo+
Samsung GSM	GT-I9300T Galaxy S III
Samsung GSM	GT-i9301I Galaxy S III Neo
Samsung GSM	GT-i9305T Galaxy S III
Samsung GSM	GT-I9305 Galaxy S III LTE
Samsung GSM	GT-i9308 Galaxy S III
Samsung GSM	SM-G9308 Galaxy S7 Duos
Samsung GSM	GT-I9500 Galaxy S4
Samsung GSM	GT-I9500 Fake Samsung Galaxy S4
Samsung GSM	GT-I9502 Galaxy S4
Samsung GSM	GT-I9505 Galaxy S4 LTE
Samsung GSM	GT-I9505G Galaxy S4 Google Edition
Samsung GSM	GT-i9506 Galaxy S4
Samsung GSM	GT-I9507V Galaxy S4
Samsung GSM	GT-i9508 Galaxy S4
Samsung GSM	GT-i9508V Galaxy S4
Samsung GSM	GT-I9515 Galaxy S4
Samsung GSM	GT-I9515L Galaxy S4
Samsung GSM	SM-N9600 Galaxy Note 9
Samsung GSM	Fake Samsung N9589 Note 2
Samsung GSM	SM-G9730 Galaxy S10
Samsung GSM	SM-N986U Galaxy Note 20 Ultra 5G
Samsung GSM	SM-T870 Galaxy Tab S7
Samsung GSM	SM-A600AZ Galaxy A6
Samsung TDMA	STH-A225 (912)

Samsung TDMA	STH-N271 (612)
Samsung TDMA	STH-N375 (522)
Sanyo CDMA	2500 S1
Sanyo CDMA	M1
Sanyo CDMA	MVP (ESPN)
Sanyo CDMA	Pro-200 (Bell)
Sanyo CDMA	Pro-200 (Sprint)
Sanyo CDMA	SCP-200
Sanyo CDMA	Pro-700 (Bell)
Sanyo CDMA	Pro-700 (Sprint)
Sanyo CDMA	Pro-700 (MTS)
Sanyo CDMA	RL-2000
Sanyo CDMA	VI-2300
Sanyo CDMA	SCP-2400
Sanyo CDMA	SCP-2700 Juno
Sanyo CDMA	SCP-3100
Sanyo CDMA	SCP-3200
Sanyo CDMA	SCP-3800 Katana LX
Sanyo CDMA	SCP-3810 Mirror
Sanyo CDMA	SCP-3820 Vero
Sanyo CDMA	SCP-4000
Sanyo CDMA	E4100 Tahoe
Sanyo CDMA	SCP-4500
Sanyo CDMA	SCP-4700
Sanyo CDMA	VM-4500
Sanyo CDMA	4900
Sanyo CDMA	RL-4920
Sanyo CDMA	SCP-4920 (Bell)
Sanyo CDMA	RL-4930
Sanyo CDMA	SCP-5000
Sanyo CDMA	SCP-5150
Sanyo CDMA	SCP-5300
Sanyo CDMA	SCP-5400 (RL-2500)
Sanyo CDMA	SCP-5500 (VM4500)
Sanyo CDMA	MM-5600
Sanyo CDMA	SCP-6000
Sanyo CDMA	SCP-6200
Sanyo CDMA	SCP-6400
Sanyo CDMA	6600 Katana
Sanyo CDMA	SCP-6650 Katana II
Sanyo CDMA	SCP-6750 Katana Eclipse
Sanyo CDMA	SCP-6760 Incognito
Sanyo CDMA	SCP-6780 Innuendo (Sprint)
Sanyo CDMA	SCP-7000
Sanyo CDMA	SCP-7050
Sanyo CDMA	SCP-7200 (RL-2000)
Sanyo CDMA	SCP-7300 (RL-7300)
Sanyo CDMA	MM-7400
Sanyo CDMA	MM-7500
Sanyo CDMA	SCP-8100
Sanyo CDMA	SCP-8100 (Bell)
Sanyo CDMA	8200 (PM-8200)
Sanyo CDMA	MM-8300
Sanyo CDMA	SCP-8400
Sanyo CDMA	SCP-8500 Katana DLX

Sanyo CDMA	SCP-8600 Zio
Sanyo CDMA	MM-9000
Satellite phones	Thuraya SO-2510
Satellite phones	Thuraya SG-2520
Satellite phones	Iridium 9555
Sharp	SH-02F Aquos Phone EX
Sharp	SH-03F Junior 2
Sharp	SH-05E Junior
Sharp	SH-07E Aquos
Sharp	ADS1 FX Plus
Sharp	SH-04H AQUOS ZETA
Sharp	SH-02H AQUOS COMPACT
Sharp	S1 Android One S1
Sharp	SH-02E Aquos Phone Zeta Docomo
Sharp	503SH Aquos Xx2 Mini SoftBank
Sharp	S3-SH Android One SoftBank
Sharp	SBM107SH Pantone 5 SoftBank
Sharp	701SH Aquos
Sharp	SBM200SH Pantone 6
Sharp	SH-04F Aquos Zeta
Sharp	X5
Sharp	IS05
Sharp	X9
Sharp	IS15SH AQUOS
Sharp	ISW16SH AQUOS SERIE
Sharp	PB20ZU Kin Two
Sharp	GX10i
Sharp	GX15
Sharp	GX17
Sharp	GX20
Sharp	SHF31 AQUOS K
Sharp	SHL22
Sharp	SHL23
Sharp	SHL24 Aquos Phone Serie mini
Sharp	SHL25 Aquos Serie
Sharp	GX25
Sharp	GX29
Sharp	GX30
Sharp	GX30i
Sharp	GX33
Sharp	GX34
Sharp	EC40
Sharp	GX40
Sharp	PV300 MobiFlip
Sharp	303SH
Sharp	SBM104SH Aquos
Sharp	306SH Aquos Crystal
Sharp	402SH AQUOS Crystal X
Sharp	NP501SH AQUOS
Sharp	SBM009SH Aquos
Sharp	SHT22 Aquos Pad
Sharp	SH530U
Sharp	770SH
Sharp	832P
Sharp	880SH

Sharp	SH6018C
Sharp	SH6118C
Sharp	9020C
Sharp	SH9110C
Sharp	SH9260C
Sharp	WX04SH Aquos Phone
Sharp	WX05SH Aquos Phone
Sharp	106SH Sharp Aquos Phone Xx
Sharp	DM010SH Disney Mobile
Sharp	DM011SH Disney Mobile
Sharp	DM012SH Disney Mobile
Sharp	DM013SH Disney Mobile
Siemens/Benq	AL21
Siemens/Benq	C25
Siemens/Benq	S25
Siemens/Benq	C35
Siemens/Benq	S35
Siemens/Benq	M35
Siemens/Benq	M35i
Siemens/Benq	C45
Siemens/Benq	M45
Siemens/Benq	M46
Siemens/Benq	A50
Siemens/Benq	M50
Siemens/Benq	MT50
Siemens/Benq	A55
Siemens/Benq	C55
Siemens/Benq	CL55
Siemens/Benq	M55
Siemens/Benq	S55
Siemens/Benq	SL55
Siemens/Benq	A56
Siemens/Benq	C56
Siemens/Benq	CT56
Siemens/Benq	S56
Siemens/Benq	SL56
Siemens/Benq	SX66
Siemens/Benq	S57
Siemens/Benq	A60
Siemens/Benq	C60
Siemens/Benq	MC60
Siemens/Benq	C61
Siemens/Benq	C62
Siemens/Benq	CF62
Siemens/Benq	CF63
Siemens/Benq	A65
Siemens/Benq	C65
Siemens/Benq	CX65
Siemens/Benq	CXV65
Siemens/Benq	M65
Siemens/Benq	S65
Siemens/Benq	S65v
Siemens/Benq	SL65
Siemens/Benq	A66
Siemens/Benq	C66

Siemens/Benq	CT66
Siemens/Benq	CX66
Siemens/Benq	S68
Siemens/Benq	C70
Siemens/Benq	CX70
Siemens/Benq	CX70v
Siemens/Benq	EL71
Siemens/Benq	C72v
Siemens/Benq	AX75
Siemens/Benq	C75
Siemens/Benq	CF75
Siemens/Benq	CX75
Siemens/Benq	M75
Siemens/Benq	S75
Siemens/Benq	SL75
Siemens/Benq	SFG75
Siemens/Benq	SI341i
SIM Card	SIM
SIM Card	Iden SIM
SK CDMA	IM 1400
SK CDMA	IM 3000
SK CDMA	IM 5000
SK CDMA	IM 5000A
SK CDMA	IM 5100
SK CDMA	IM 5400
SK CDMA	IM 6000
SK CDMA	IM 6100
SK CDMA	IM 7200
SK CDMA	IM 7400
Sky	IM-A730S Sky Vega S
Sky	5.0L
Sky	ELITE 6.0L+ DS
Sky	Platinum 6.0+ DS
Sky	5.0W
Skype	Amoi WP-S1 Skype
Skype	Amoi WP-S2 Skype
Smart Phones/PDAs	Android Bluetooth (Logical (No Multimedia))
Smart Phones/PDAs	Android Bluetooth (Logical (Only Multimedia))
Smart Phones/PDAs	Android Bluetooth Fast Phonebook
Smart Phones/PDAs	Android (Logical ADB Normal(Recommended))
Smart Phones/PDAs	Android (Logical Bypassing Lock (HTC))
Smart Phones/PDAs	Android (Logical Bypassing Lock (Motorola))
Smart Phones/PDAs	MS Pocket PC 2003 (GSM)
Smart Phones/PDAs	MS SmartPhone 2003 (GSM)
Smart Phones/PDAs	MS Windows Mobile 5 (GSM)
Smart Phones/PDAs	MS Windows Mobile 6.x (GSM)
Smart Phones/PDAs	Windows Phone 7 (USB)
Smart Phones/PDAs	Windows Phone 7 (BT)
Smart Phones/PDAs	Windows Phone 8 (USB)
Smart Phones/PDAs	Windows Phone 8 (BT)
Smart Phones/PDAs	Windows Phone 10 (USB)
Smart Phones/PDAs	Windows Phone 10 (BT)
Smart Phones/PDAs	Symbian 3rd Ed. (Client)
Smart Phones/PDAs	BlackBerry (CDMA)
Smart Phones/PDAs	BlackBerry (GSM)

Smart Phones/PDAs	BlackBerry 10 (Bluetooth)
Smart Phones/PDAs	BlackBerry 10 (USB cable)
Smartisan	YQ601 U1
Smartisan	SM919 M1L
Smartisan	U3 Pro
Smartisan	OD103 U2 Pro
Smartisan	DE106 R1
Smartisan	OE106 JianGuo Pro 2s
SoftBank	iPad Air (GSM)
SoftBank	iPad mini
SoftBank	Memory Card
SoftBank	709SC
SoftBank	814T
SoftBank	815SH
SoftBank	820N
SoftBank	920P
SoftBank	920SH
SoftBank	706P
SoftBank	912T
SoftBank	820T
SoftBank	822T
SoftBank	920SC(PHOTOS)
SoftBank	705SC
SoftBank	805SC
SoftBank	820SC
SoftBank	706SC
SoftBank	730SC
SoftBank	707SC
SoftBank	708SC
SoftBank	913SH(FULLFACE)
SoftBank	814SH
SoftBank	811T
SoftBank	911T
SoftBank	830CA
SoftBank	811SH
SoftBank	810P
SoftBank	705P
SoftBank	821SC
SoftBank	812T
SoftBank	910T
SoftBank	822P
SoftBank	812SH
SoftBank	813SH
SoftBank	822SH
SoftBank	825SH(PANTONE Slide)
SoftBank	911SH
SoftBank	921SH(FULLFACE2)
SoftBank	831SH KT
SoftBank	931SH(AQUOS FULLTOUCH)
SoftBank	824SH(THE PREMIUM)
SoftBank	831SH
SoftBank	830SH(NEW PANTONE)
SoftBank	923SH
SoftBank	942SH(THE PREMIUM5)
SoftBank	831SHs(GENT)

SoftBank	830SHs(GENT)
SoftBank	934SH(mirumo)
SoftBank	940SH(AQUOS SHOT)
SoftBank	930SH
SoftBank	936SH(SOLAR HYBRID)
SoftBank	935SH(THE PREMIUM)
SoftBank	941SH(AQUOS FULLTOUCH)
SoftBank	823SH(THE PREMIUM TEXTURE)
SoftBank	832SH
SoftBank	840SH(Jelly Beans)
SoftBank	932SH(AQUOS)
SoftBank	933SH(AQUOS SHOT)
SoftBank	931SC(OMNIA POP)
SoftBank	731SC
SoftBank	830SC(Emporio Armani)
SoftBank	740SC
SoftBank	832SHs(GENT)
SoftBank	940SC(OMNIA VISION)
SoftBank	930CA(EXILIM)
SoftBank	940P(VIERA)
SoftBank	840P(COLOR LIFE)
SoftBank	941P(VIERA)
SoftBank	831P
SoftBank	830P
SoftBank	921P
SoftBank	841P
SoftBank	824P(MIRROR2)
SoftBank	821N
SoftBank	832P
SoftBank	930P(VIERA)
SoftBank	931P(VIERA)
SoftBank	940N
SoftBank	831N
SoftBank	931N
SoftBank	830N
SoftBank	823T
SoftBank	930N
SoftBank	824T
SoftBank	821T
SoftBank	831T(fanfun.petit)
SoftBank	830T(funfun.2)
SoftBank	832T
SoftBank	930SC(OMNIA)
SoftBank	823P(TROPICAL)
SoftBank	943SH(AQUOS)
SoftBank	922SH
SoftBank	921T
SoftBank	DM001SH
SoftBank	DM002SH
SoftBank	DM003SH
SoftBank	DM004SH
SoftBank	DM005SH
SoftBank	942SH KT
SoftBank	821N GLA
SoftBank	920SH YK

SoftBank	X01HT
SoftBank	X01NK (No Client)
SoftBank	X02NK (No Client)
SoftBank	iPhone 3G
SoftBank	iPhone 3GS
SoftBank	X03HT
SoftBank	X04HT(Diamond)
SoftBank	X05HT(Touch Pro)
SoftBank	Nokia N82 (No Client)
SoftBank	705NK (No Client)
SoftBank	920T
SoftBank	910SH
SoftBank	841SH(THE PREMIUM6)
SoftBank	841SHs(GENT)
SoftBank	912SH
SoftBank	812SHs(GENT)
SoftBank	812SHs2(GENT)
SoftBank	816SH
SoftBank	905SH
SoftBank	810SH
SoftBank	820SH(THE PREMIUM)
SoftBank	821SH(THE PREMIUM)
SoftBank	705Px
SoftBank	820P
SoftBank	821P(MIRROR)
SoftBank	707SC2
SoftBank	810T
SoftBank	813T
SoftBank	815T(fanfun)
SoftBank	X06HT(Desire)
SoftBank	944SH(mirumo2)
SoftBank	945SH(AQUOS SHOT)
SoftBank	842SH(SOLAR HYBRID)
SoftBank	942P(VIERA)
SoftBank	842P
SoftBank	840N
SoftBank	DM006SH
SoftBank	X01T
SoftBank	X02T(dynapocket)
SoftBank	X01SC
SoftBank	841N
SoftBank	843SH
SoftBank	001N
SoftBank	DM007SH
SoftBank	DM008SH
SoftBank	001SH(PANTONE3)
SoftBank	002SH(AQUOS SHOT)
SoftBank	840Z
SoftBank	001SC(AQUA STYLE)
SoftBank	001HT(Desire HD)
SoftBank	003SH(GALAPAGOS)
SoftBank	001DL(DELL Streak)
SoftBank	003Z(Libero)
SoftBank	004SH(THE PREMIUN)
SoftBank	001P(LUMIX)

SoftBank	002P
SoftBank	iPhone 4
SoftBank	iPhone 4S
SoftBank	008SH
SoftBank	005SH(GALAPAGOS)
SoftBank	006SH
SoftBank	007SH(THE HYBRID)
SoftBank	007SH J(THE HYBRID)
SoftBank	003P(Sweety)
SoftBank	101P(LUMIX)
SoftBank	009SH
SoftBank	009SH Y(Yahoo Phone)
SoftBank	101SH(THE HYBRID)
SoftBank	102SH
SoftBank	DM009SH
SoftBank	008Z
SoftBank	009Z
SoftBank	007HW(Vision)
SoftBank	103SH
SoftBank	101N(MEDIAS CH)
SoftBank	101K(HONEY BEE)
SoftBank	104SH
SoftBank	007SH KT
SoftBank	101DL DELL Streak
SoftBank	105SH(PANTONE4)
SoftBank	102P
SoftBank	102SHII
SoftBank	106SH
SoftBank	SBM102SH2 Aquos
SoftBank	107SH(PANTONE5)
SoftBank	101F (ArrowsA)
SoftBank	103P
SoftBank	iPhone 5 (USB cable)
SoftBank	iPhone 5 (Bluetooth (fast phonebook))
SoftBank	iPhone 5S (USB cable)
SoftBank	iPhone 5S (Bluetooth (fast phonebook))
SoftBank	iPhone 5C (USB cable)
SoftBank	iPhone 5C (Bluetooth (fast phonebook))
SoftBank	108SH
SoftBank	109SH
SoftBank	107SH B
SoftBank	201HW
SoftBank	DM011SH
SoftBank	DM013SH
SoftBank	201M(RAZR M)
SoftBank	DM010SH
SoftBank	200SH
SoftBank	203SH
SoftBank	204SH
SoftBank	DM014SH
SoftBank	201K
SoftBank	202F
SoftBank	DM012SH
SoftBank	202SH
SoftBank	205SH

SoftBank	206SH
SoftBank	DM015K
SoftBank	201F(Arrows A)
SoftBank	301F(Arrows A)
SoftBank	302SH(AQUOS PHONE Xx)
SoftBank	DM016SH
SoftBank	iPhone 6
SoftBank	iPhone 6 Plus
SoftBank	303SH
SoftBank	301P
SoftBank	301SH
SoftBank	304SH
SoftBank	305SH
SoftBank	Sharp 401SH Aquos Hybrid
SoftBank	402SH
SoftBank	401PM
SoftBank	404KC (DIGNO U)
SoftBank	404SC (Galaxy S6 Edge)
SoftBank	403SC (Galaxy Tab4)
SoftBank	402SO (Xperia Z4)
SoftBank	iPhone 6s
SoftBank	iPhone 6s Plus
SoftBank	iPhone SE
SoftBank	301Z
SoftBank	401SO (Xperia Z3)
SoftBank	402HW (MediaPad10 Link+)
SoftBank	403SH (AQUOS CRYSTAL2)
SoftBank	404SH (AQUOS Xx)
SoftBank	501LV (Lenovo TAB2)
SoftBank	501SO (Xperia Z5)
SoftBank	502SH (AQUOS Xx2)
SoftBank	502SO (Xperia X Performance)
SoftBank	503KC (DIGNO F)
SoftBank	503SH (AQUOS Xx2 mini)
SoftBank	506SH (AQUOS Xx3)
SoftBank	iPhone 7
SoftBank	iPhone 7 Plus
SoftBank	501KC
SoftBank	505SH
SoftBank	202K(DIGNO R)
SoftBank	509SH
SoftBank	601SH
Sonim	S1 Land Rover
Sonim	XP1
Sonim	XP1520 Bolt SL
Sonim	XP1300
Sonim	XP1330 Core
Sonim	XP3.20
Sonim	XP3400
Sonim	XP3410
Sonim	XP3410-IS
Sonim	XP4400 Enduro
Sonim	XP5300
Sonim	XP5560 BOLT
Sonim	XP5560 Bolt 2

Sonim	XP5700 XP5
Sonim	XP5800
Sonim	XP6700 XP6
Sonim	XP7700 XP7
Sonim	XP8800
Sony (SonyEricsson)	Generic Android
Sony (SonyEricsson)	SGP521 Xperia Z2 Tablet
Sony (SonyEricsson)	D2005 Xperia E1
Sony (SonyEricsson)	D2104 Xperia E1
Sony (SonyEricsson)	J9110 Xperia 1
Sony (SonyEricsson)	J9210 Xperia 5
Sony (SonyEricsson)	I3312 Xperia L3
Sony (SonyEricsson)	I4193 Xperia 10
Sony (SonyEricsson)	SO-01J Xperia XZ
Sony (SonyEricsson)	SO-02J(Xperia X Compact)
Sony (SonyEricsson)	C6916 Xperia Z1s
Sony (SonyEricsson)	M1a Aspen
Sony (SonyEricsson)	U5i Kurara (No Client)
Sony (SonyEricsson)	U5i Vivaz (No Client)
Sony (SonyEricsson)	X5 Xperia Pureness
Sony (SonyEricsson)	A8i
Sony (SonyEricsson)	U8a Vivaz Pro (No Client)
Sony (SonyEricsson)	U8i Vivaz Pro (No Client)
Sony (SonyEricsson)	U8a Vivaz Pro (Using Client)
Sony (SonyEricsson)	U8i Vivaz Pro (Using Client)
Sony (SonyEricsson)	J10i Elm
Sony (SonyEricsson)	IS11S Xperia acro
Sony (SonyEricsson)	CK13i TXT (USB)
Sony (SonyEricsson)	WT13i Mix Walkman (USB)
Sony (SonyEricsson)	Xperia E15i
Sony (SonyEricsson)	Xperia X8
Sony (SonyEricsson)	Xperia E10a mini
Sony (SonyEricsson)	Xperia X10 mini
Sony (SonyEricsson)	Xperia E10i
Sony (SonyEricsson)	Xperia X10 mini
Sony (SonyEricsson)	Xperia U20i mini pro
Sony (SonyEricsson)	Xperia X10 mini pro
Sony (SonyEricsson)	Xperia Neo V MT11a
Sony (SonyEricsson)	Xperia Neo V MT11i
Sony (SonyEricsson)	IS12S(XPERIA acroHD)
Sony (SonyEricsson)	SO-03D Xperia acro HD
Sony (SonyEricsson)	SO-03F Xperia Z2
Sony (SonyEricsson)	TXT Pro CK15a (USB)
Sony (SonyEricsson)	TXT Pro CK15i (USB)
Sony (SonyEricsson)	LT15a Xperia Arc
Sony (SonyEricsson)	MT15i Xperia Neo
Sony (SonyEricsson)	Xperia Mini ST15i
Sony (SonyEricsson)	Xperia Pro MK16i
Sony (SonyEricsson)	MK16a Xperia Pro
Sony (SonyEricsson)	SK17a Xperia Mini Pro
Sony (SonyEricsson)	SK17i Xperia Mini Pro
Sony (SonyEricsson)	Xperia Arc S LT18a
Sony (SonyEricsson)	LT18i Xperia Arc S
Sony (SonyEricsson)	WT19a
Sony (SonyEricsson)	SOL21 Xperia

Sony (SonyEricsson)	LT22i Xperia P
Sony (SonyEricsson)	ST23i Xperia Miro
Sony (SonyEricsson)	MT25i Xperia Neo L
Sony (SonyEricsson)	ST25a Xperia U
Sony (SonyEricsson)	ST25i Xperia U
Sony (SonyEricsson)	LT26i Xperia S
Sony (SonyEricsson)	ST26a Xperia J
Sony (SonyEricsson)	LT26ii Xperia SL
Sony (SonyEricsson)	LT28at Xperia Ion
Sony (SonyEricsson)	LT28H Xperia Ion
Sony (SonyEricsson)	T28S
Sony (SonyEricsson)	LT30a Xperia T
Sony (SonyEricsson)	LT30at Xperia TL
Sony (SonyEricsson)	Xperia Active ST17i
Sony (SonyEricsson)	Xperia Ray ST18i
Sony (SonyEricsson)	Xperia Live WT19i
Sony (SonyEricsson)	W20i Zyló (USB)
Sony (SonyEricsson)	W20i Zyló (BT)
Sony (SonyEricsson)	Robyn
Sony (SonyEricsson)	Yari
Sony (SonyEricsson)	P1i
Sony (SonyEricsson)	U1i Satio
Sony (SonyEricsson)	Xperia X1
Sony (SonyEricsson)	Xperia X1a
Sony (SonyEricsson)	Xperia X2
Sony (SonyEricsson)	i2 Elm
Sony (SonyEricsson)	i2 Susan
Sony (SonyEricsson)	Xperia X10
Sony (SonyEricsson)	Xperia X10i
Sony (SonyEricsson)	U10i Aino
Sony (SonyEricsson)	J20 Hazel (USB)
Sony (SonyEricsson)	J20 Hazel (BT)
Sony (SonyEricsson)	ST21i Xperia Tipo
Sony (SonyEricsson)	SOL22 Xperia UL
Sony (SonyEricsson)	SOL26 Xperia Z3
Sony (SonyEricsson)	LT25i Xperia V
Sony (SonyEricsson)	ST26i Xperia J
Sony (SonyEricsson)	LT26w Acro S
Sony (SonyEricsson)	ST27a Xperia Go
Sony (SonyEricsson)	MT27i Xperia Pepper
Sony (SonyEricsson)	MT27i Xperia Solo
Sony (SonyEricsson)	ST27i Xperia Go
Sony (SonyEricsson)	LT28i Xperia Ion
Sony (SonyEricsson)	LT29i Xperia TX
Sony (SonyEricsson)	LT30p Xperia T
Sony (SonyEricsson)	S39h Xperia C
Sony (SonyEricsson)	T39
Sony (SonyEricsson)	S51SE mini
Sony (SonyEricsson)	T65
Sony (SonyEricsson)	T68i
Sony (SonyEricsson)	F100i Bao
Sony (SonyEricsson)	F100i Bijou
Sony (SonyEricsson)	F100i Jalou
Sony (SonyEricsson)	U100i Yari
Sony (SonyEricsson)	W100i Spiro (Content)

Sony (SonyEricsson)	J105 Ling
Sony (SonyEricsson)	J105 Naite
Sony (SonyEricsson)	J105a
Sony (SonyEricsson)	J105i
Sony (SonyEricsson)	J108i Cedar (USB)
Sony (SonyEricsson)	J108i Hong (USB)
Sony (SonyEricsson)	J108i Cedar (BT)
Sony (SonyEricsson)	J108i Hong (BT)
Sony (SonyEricsson)	SGPT111 Tablet S
Sony (SonyEricsson)	W150i Yendo
Sony (SonyEricsson)	W200i
Sony (SonyEricsson)	W205 (Content)
Sony (SonyEricsson)	SGPT211TWS Tablet P
Sony (SonyEricsson)	T226
Sony (SonyEricsson)	T230
Sony (SonyEricsson)	T237
Sony (SonyEricsson)	T290
Sony (SonyEricsson)	J300i
Sony (SonyEricsson)	K300i
Sony (SonyEricsson)	T300
Sony (SonyEricsson)	W300i
Sony (SonyEricsson)	S302
Sony (SonyEricsson)	W302
Sony (SonyEricsson)	T303 (Content)
Sony (SonyEricsson)	T303a
Sony (SonyEricsson)	F305
Sony (SonyEricsson)	T306
Sony (SonyEricsson)	K310i
Sony (SonyEricsson)	T310
Sony (SonyEricsson)	T316
Sony (SonyEricsson)	Z310i
Sony (SonyEricsson)	SGP311 Xperia Tablet Z WiFi
Sony (SonyEricsson)	S312
Sony (SonyEricsson)	Z320a
Sony (SonyEricsson)	K320i
Sony (SonyEricsson)	SGP321 Xperia Z Tab
Sony (SonyEricsson)	W350a
Sony (SonyEricsson)	W350i
Sony (SonyEricsson)	W380
Sony (SonyEricsson)	W380I
Sony (SonyEricsson)	W395
Sony (SonyEricsson)	F500i
Sony (SonyEricsson)	K500i
Sony (SonyEricsson)	Z500A
Sony (SonyEricsson)	S500i
Sony (SonyEricsson)	G502 (USB)
Sony (SonyEricsson)	G502 (BT)
Sony (SonyEricsson)	TM506
Sony (SonyEricsson)	K508
Sony (SonyEricsson)	W508
Sony (SonyEricsson)	W518
Sony (SonyEricsson)	C510
Sony (SonyEricsson)	K510i (USB)
Sony (SonyEricsson)	K510i (BT)
Sony (SonyEricsson)	R520

Sony (SonyEricsson)	Z520i
Sony (SonyEricsson)	Z525a
Sony (SonyEricsson)	K530i (USB)
Sony (SonyEricsson)	K530i (BT)
Sony (SonyEricsson)	Z530i
Sony (SonyEricsson)	K550i
Sony (SonyEricsson)	K550im
Sony (SonyEricsson)	W550i
Sony (SonyEricsson)	Z550i
Sony (SonyEricsson)	Z555
Sony (SonyEricsson)	SGP561
Sony (SonyEricsson)	W580i
Sony (SonyEricsson)	W595 (USB)
Sony (SonyEricsson)	W595 (BT)
Sony (SonyEricsson)	K600i
Sony (SonyEricsson)	M600i
Sony (SonyEricsson)	T600
Sony (SonyEricsson)	V600i
Sony (SonyEricsson)	W600i
Sony (SonyEricsson)	Z600
Sony (SonyEricsson)	K608i
Sony (SonyEricsson)	M608c
Sony (SonyEricsson)	K610i
Sony (SonyEricsson)	K610im
Sony (SonyEricsson)	T610
Sony (SonyEricsson)	T616
Sony (SonyEricsson)	W610i
Sony (SonyEricsson)	Z610i (USB)
Sony (SonyEricsson)	Z610i (BT)
Sony (SonyEricsson)	T618
Sony (SonyEricsson)	T628
Sony (SonyEricsson)	K630i
Sony (SonyEricsson)	T630
Sony (SonyEricsson)	T637
Sony (SonyEricsson)	V630i
Sony (SonyEricsson)	V640i
Sony (SonyEricsson)	T650i (USB)
Sony (SonyEricsson)	T650i (BT)
Sony (SonyEricsson)	K660i
Sony (SonyEricsson)	W660i
Sony (SonyEricsson)	G700
Sony (SonyEricsson)	K700i
Sony (SonyEricsson)	S700i
Sony (SonyEricsson)	T700
Sony (SonyEricsson)	W700i
Sony (SonyEricsson)	C702 (USB)
Sony (SonyEricsson)	C702 (BT)
Sony (SonyEricsson)	G705
Sony (SonyEricsson)	W705 (USB)
Sony (SonyEricsson)	W705 (BT)
Sony (SonyEricsson)	T707 (USB)
Sony (SonyEricsson)	T707 (BT)
Sony (SonyEricsson)	S710
Sony (SonyEricsson)	W710i
Sony (SonyEricsson)	Z710i

Sony (SonyEricsson)	T715a (USB)
Sony (SonyEricsson)	T715a (BT)
Sony (SonyEricsson)	T715 Alma (USB)
Sony (SonyEricsson)	T715 Alma (BT)
Sony (SonyEricsson)	W715
Sony (SonyEricsson)	TM717 Equinox
Sony (SonyEricsson)	D750i
Sony (SonyEricsson)	K750i (USB)
Sony (SonyEricsson)	K750i (BT)
Sony (SonyEricsson)	Z750a
Sony (SonyEricsson)	Z750i
Sony (SonyEricsson)	W760i (USB)
Sony (SonyEricsson)	W760i (BT)
Sony (SonyEricsson)	K770i
Sony (SonyEricsson)	Z770i
Sony (SonyEricsson)	Z780i
Sony (SonyEricsson)	K790i
Sony (SonyEricsson)	K800i
Sony (SonyEricsson)	R800a Xperia Play
Sony (SonyEricsson)	Xperia Play R800at
Sony (SonyEricsson)	Xperia R800i Play
Sony (SonyEricsson)	R800x Xperia Play (Verizon)
Sony (SonyEricsson)	R800x Xperia Play (CellSouth)
Sony (SonyEricsson)	V800
Sony (SonyEricsson)	W800i (USB)
Sony (SonyEricsson)	W800i (BT)
Sony (SonyEricsson)	Z800
Sony (SonyEricsson)	K810i
Sony (SonyEricsson)	W810i
Sony (SonyEricsson)	W830c
Sony (SonyEricsson)	K850i
Sony (SonyEricsson)	W850i
Sony (SonyEricsson)	W880i (USB)
Sony (SonyEricsson)	W880i (BT)
Sony (SonyEricsson)	W890i
Sony (SonyEricsson)	G900
Sony (SonyEricsson)	W900
Sony (SonyEricsson)	C901
Sony (SonyEricsson)	C902 (USB)
Sony (SonyEricsson)	C902 (BT)
Sony (SonyEricsson)	W902
Sony (SonyEricsson)	C903
Sony (SonyEricsson)	C905 (USB)
Sony (SonyEricsson)	C905a (USB)
Sony (SonyEricsson)	C905 (BT)
Sony (SonyEricsson)	C905a (BT)
Sony (SonyEricsson)	W908C
Sony (SonyEricsson)	W910i (USB)
Sony (SonyEricsson)	W910i (BT)
Sony (SonyEricsson)	W950i
Sony (SonyEricsson)	W960i
Sony (SonyEricsson)	W980
Sony (SonyEricsson)	P990i
Sony (SonyEricsson)	W995
Sony (SonyEricsson)	E5306 Xperia C4

Sony (SonyEricsson)	F3113 Xperia XA
Sony (SonyEricsson)	G8142 Xperia XZ
Sony (SonyEricsson)	G8141 Xperia XZ
Sony (SonyEricsson)	G8341 Xperia XZ1
Sony (SonyEricsson)	G8342 Xperia XZ1
Sony (SonyEricsson)	F8331 Xperia XZ
Sony (SonyEricsson)	Z1010
Sony (SonyEricsson)	C1504 Xperia E
Sony (SonyEricsson)	C1505 Xperia E
Sony (SonyEricsson)	C1605 Xperia E Dual
Sony (SonyEricsson)	C1904 Xperia M
Sony (SonyEricsson)	C1905 Xperia M
Sony (SonyEricsson)	D2004 Xperia E1
Sony (SonyEricsson)	E2006 Xperia E4g
Sony (SonyEricsson)	G8441 Xperia XZ1 Compact
Sony (SonyEricsson)	E2104 Xperia E4
Sony (SonyEricsson)	E2105 Xperia E4
Sony (SonyEricsson)	E2303 Xperia M4 Aqua
Sony (SonyEricsson)	E2306 Xperia M4 Aqua
Sony (SonyEricsson)	D2403 Xperia M2 Aqua
Sony (SonyEricsson)	C2104 Xperia L
Sony (SonyEricsson)	C2105 Xperia L
Sony (SonyEricsson)	G3311 Xperia L1
Sony (SonyEricsson)	G3312 Xperia L1
Sony (SonyEricsson)	H3321 Xperia L2
Sony (SonyEricsson)	G3313 Xperia L1
Sony (SonyEricsson)	D2203 Xperia E3
Sony (SonyEricsson)	D2206 Xperia E3
Sony (SonyEricsson)	C2305 Xperia C
Sony (SonyEricsson)	D2303 Xperia M2
Sony (SonyEricsson)	D2306 Xperia M2
Sony (SonyEricsson)	F3111 Xperia XA
Sony (SonyEricsson)	G3121 Xperia XA1
Sony (SonyEricsson)	G3221 Xperia XA1 Ultra
Sony (SonyEricsson)	H8314 XZ2 Compact
Sony (SonyEricsson)	G3123 Xperia XA1
Sony (SonyEricsson)	E5633 Xperia M5 Dual
Sony (SonyEricsson)	I4293 Xperia 10 Plus
Sony (SonyEricsson)	H3113 Xperia XA2
Sony (SonyEricsson)	H3223 XA2 Ultra
Sony (SonyEricsson)	H4493 XPERIA XA2 Plus
Sony (SonyEricsson)	H3123 XA2
Sony (SonyEricsson)	F3216 Xperia XA Ultra
Sony (SonyEricsson)	H9493 Xperia XZ3
Sony (SonyEricsson)	F3213 Xperia XA Ultra
Sony (SonyEricsson)	H3213 Xperia XA2
Sony (SonyEricsson)	F3311 Xperia E5
Sony (SonyEricsson)	G3416 Xperia XA1 Plus
Sony (SonyEricsson)	G3426 Xperia XA1 Plus
Sony (SonyEricsson)	H8216 Xperia XZ2
Sony (SonyEricsson)	C5302 Xperia SP
Sony (SonyEricsson)	C5303 Xperia SP
Sony (SonyEricsson)	C5306 Xperia SP
Sony (SonyEricsson)	D5103 Xperia T3
Sony (SonyEricsson)	D5106 Xperia T3

Sony (SonyEricsson)	F5121 Xperia X
Sony (SonyEricsson)	F5122 Xperia X Dual
Sony (SonyEricsson)	D5306 Xperia T2 Ultra
Sony (SonyEricsson)	D5503 Xperia Z1 Compact
Sony (SonyEricsson)	D5303 Xperia T2 Ultra
Sony (SonyEricsson)	E2363 Xperia M4
Sony (SonyEricsson)	E5606 Xperia M5
Sony (SonyEricsson)	F5321 Xperia X Compact
Sony (SonyEricsson)	E5333 Xperia C4 Dual
Sony (SonyEricsson)	E5533 C5 Ultra
Sony (SonyEricsson)	E5506 Xperia C5 Ultra
Sony (SonyEricsson)	D5803 Xperia Z3 Compact
Sony (SonyEricsson)	E5823 Xperia Z5 Compact
Sony (SonyEricsson)	D5833 Xperia Z3 Compact
Sony (SonyEricsson)	C6502 Xperia ZL
Sony (SonyEricsson)	D6503 Xperia Z2
Sony (SonyEricsson)	SOV31 Xperia Z4
Sony (SonyEricsson)	E6508 Xperia Z4v
Sony (SonyEricsson)	E6553 Xperia Z3+
Sony (SonyEricsson)	D6616 Xperia Z3
Sony (SonyEricsson)	C6602 Xperia Z
Sony (SonyEricsson)	C6603 Xperia Z
Sony (SonyEricsson)	C6603 Xperia Z Yuga
Sony (SonyEricsson)	D6643 Xperia Z3 TV
Sony (SonyEricsson)	C6503 Xperia ZL
Sony (SonyEricsson)	C6506 Xperia ZL
Sony (SonyEricsson)	C6603 Xperia Z [CDMA]
Sony (SonyEricsson)	C6606 Xperia Z
Sony (SonyEricsson)	C6616 Xperia Z
Sony (SonyEricsson)	E6683 Xperia Z5 Dual
Sony (SonyEricsson)	E6653 Xperia Z5
Sony (SonyEricsson)	D6708 Xperia Z3v
Sony (SonyEricsson)	C6802 Xperia Z Ultra
Sony (SonyEricsson)	SOL24 Xperia Z Ultra
Sony (SonyEricsson)	E6853 Xperia Z5
Sony (SonyEricsson)	C6902 Xperia Z1
Sony (SonyEricsson)	C6903 Xperia Z1
Sony (SonyEricsson)	D6603 Xperia Z3
Sony (SonyEricsson)	E6603 Xperia Z5
Sony (SonyEricsson)	D6653 Xperia Z3
Sony (SonyEricsson)	E6883 Xperia Z5 Premium
Sony (SonyEricsson)	C6906 Xperia Z1
Sony (SonyEricsson)	F8131 Xperia Performance
Sony (SonyEricsson)	F8132 Xperia Performance Dual
Sony (SonyEricsson)	SO-02F Xperia Z1f
Sony (SonyEricsson)	H8296 XPERIA XZ2
Sunup	TK007
Sunup	TK008
Sunup	08A
Sunup	QV8
Sunup	GXT100
Sunup	CS117
Sunup	CS118
Sunup	SP188
Sunup	CS200

Sunup	NB599
Sunup	ZF600
Sunup	QQ628
Sunup	H699
Sunup	NB699
Sunup	HK801
Sunup	HK805
Sunup	HK811
Sunup	K858
Sunup	Y999
Sunup	TF3316
Sunup	AMG6900
Sunup	MC8801
Swisstone	Swisstone BBM 550
Swisstone	Swisstone BBM 610
Swisstone	Swisstone SC 230
Swisstone	Swisstone MP33
Swisstone	SC 580
Swisstone	SC 330
Swisstone	SC 710
Swisstone	SC 660_DS
TCL	P590L Lewan 2C
TCL	i709M
TCL	M2M
TCL	S950 One Touch Idol X
TCL	S950T Idol X
TCL	T799H 10 Pro
TCL	A503DL TracFone
TCL	T780H Plex
TCL	6062Z Revvl 2 Plus
TCL	J320T
TCL	J600T
TCL	Y910 Hero N3
TEC	M526
TIM	StarTIM1
Palm	Pre CDMA (Sprint)
Palm	Pre GSM
Palm	Pre Plus GSM
Palm	Pre Plus CDMA (Verizon) (Content)
Palm	Pre Plus CDMA (Verizon) (Phonebook)
Palm	Pre 2 CDMA (Verizon)
Palm	Pre 2 GSM
Palm	Pixi CDMA (Sprint)
Palm	Pixi Plus GSM
Palm	Pixi Plus CDMA (Verizon) (Phonebook)
Palm	Pixi Plus CDMA (Verizon) (Content)
Palm	P130www Pre 3 CDMA (USB)
Palm	P130www Pre 3 CDMA (BT)
Palm	P130UNA Pre 3 GSM (USB)
Palm	P130UNA Pre 3 GSM (BT)
Palm	P160UNA Veer (USB)
Palm	P160UNA Veer (BT)
Palm	TREO 500v GSM
Palm	TREO 700w
Palm	TREO 700wx CDMA

Palm	TREO 750 GSM
Palm	TREO 750v GSM
Palm	TREO 800w CDMA (Sprint)
Palm	TREO 850w Pro CDMA
Tablets	Generic Android
Tablets	Asus P01Z Zenpad
Tablets	VFD 1300 Smart Tab N8
Tablets	iRULU MID
Tablets	Pipo S1 Pro
Tablets	Verizon QTAXIA1
Tablets	ZTE K92
Tablets	Lenovo Smart Tab II 10
Tablets	ZTE K88
Tablets	Huawei M2-802L MediaPad M2
Tablets	Huawei CPN-AL00 MediaPad M3 Lite 8
Tablets	Huawei CPN-L09 MediaPad M3 Lite 8
Tablets	Huawei KOB-L09 MediaPad T3
Tablets	Huawei BAH-W09 MediaPad M3 Lite 10
Tablets	Huawei X1 7.0 MediaPad X1
Tablets	Freelander PX2
Tablets	MTK Alba 8in
Tablets	MTK Alba AC70PLV5 7
Tablets	Asus K004 Fonepad
Tablets	Asus ME175CG Fonepad 7 K00Z
Tablets	Asus P028 ZenPad 10
Tablets	Pendo PP4MT-7 Pad 7
Tablets	Fake Samsung Note 8
Tablets	Sharp SH-08E AQUOS PAD
Tablets	Sharp SHT22 Aquos Pad
Tablets	MTK A9 8377 Tablet 3G
Tablets	Chinese Brand Mini iPad18 Coolgen E72 Note 8W
Tablets	Chinese Brand S750L
Tablets	Asus K008 Google Nexus 7 II
Tablets	K009 Nexus 7
Tablets	YIFANG Next7P12-8G Nextbook 7
Tablets	Archos A70BHT Home Tablet 7
Tablets	Alcatel EVO 7 One Touch
Tablets	Cube U25GT-C4YT
Tablets	Cube U27GT-S
Tablets	Coby MID9742 Kyros
Tablets	Prestigio PMP7170B Multipad 7.0 Prime 3G
Tablets	Ployer MOMO21 3G
Tablets	Samsung YP-GB70 Yepp Galaxy S Player
Tablets	Yarvik Luna-TAB07-151
Tablets	Xenta TAB07-200
Tablets	Yarvik Luna TAB09-100
Tablets	Samsung YP-GS1 Galaxy Player 3.6
Tablets	Samsung SC-01C Galaxy Tab
Tablets	Samsung SC-01D (GALAXY Tab 10.1 LTE)
Tablets	Samsung SC-01E(Galaxy Tab 7.7 Plus)
Tablets	Samsung SC-03G Galaxy Tab S 8.4
Tablets	NTT Docomo F-01D(ARROWS Tab LTE)
Tablets	NTT Docomo F-03G (ARROWS Tab)
Tablets	True Beyond Tab 3G
Tablets	Verizon QTAQZ3 Ellipsis 8

Tablets	Verizon QTAQZ3KID Ellipsis Kids
Tablets	Samsung SCT21 Galaxy Tab S 10.5
Tablets	Samsung SM-T255S Galaxy W
Tablets	Huawei S7 Ideos
Tablets	Huawei T-Touch Tab
Tablets	Verizon QMV7B Ellipsis 7
Tablets	Verizon QTAIR7 Ellipsis
Tablets	Asus ME172V Memo Pad
Tablets	Huawei S7-301u MediaPad
Tablets	Huawei S7-303u SpringBoard
Tablets	ViewSonic ViewPad 7
Tablets	ZTE V9 Optus MyTab
Tablets	ZTE Light
Tablets	Vonino Xavy_T7
Tablets	ZTE V9A Light Tab2
Tablets	Oysters T72X 3G
Tablets	ZTE V72C Optik 2
Tablets	Slate 8 AQT80
Tablets	Amazon SV98LN Fire
Tablets	Archos 80 G9
Tablets	Archos 101 G9
Tablets	Lenovo TB-X103F Tab 10
Tablets	Sony SGPT111 Tablet S
Tablets	Toshiba AT200 16GB Tab
Tablets	Samsung SM-T110 Galaxy Tab 3 7.0
Tablets	Samsung SM-T111 Galaxy Tab 3 Lite 7.0
Tablets	Samsung SM-T113 Galaxy Tab 3 Lite 7.0
Tablets	Vonino Druid_L10
Tablets	Samsung SM-T211 Galaxy Tab 3 7.0
Tablets	Sony SGPT211TWS Tablet P
Tablets	Samsung SM-T215 Galaxy Tab 3 7.0
Tablets	Samsung SM-T116NU Galaxy Tab 3V
Tablets	Samsung SM-T210R Galaxy Tab 3 7.0
Tablets	Samsung SM-T217T Galaxy Tab 3 4G
Tablets	Samsung SM-T217S Galaxy Tab 3
Tablets	Samsung SM-T237P Galaxy Tab 4
Tablets	Samsung SM-T239M Galaxy Tab 4 Lite 7.0
Tablets	Samsung SM-T280 Galaxy Tab A 7.0
Tablets	Samsung SM-T285M Galaxy Tab A 7.0 (2016)
Tablets	Samsung 403SC Galaxy Tab 4 7.0
Tablets	Alcatel P310A Pop 7
Tablets	Sony SGP311 Xperia Tablet Z WiFi
Tablets	Alcatel P330X One Touch POP 7S
Tablets	Samsung SM-T350 Galaxy Tab A 8.0
Tablets	Samsung SM-T360 Galaxy Tab Active
Tablets	Sony SGP521 Xperia Z2 Tablet
Tablets	Asus ME370T Nexus 7
Tablets	Asus ME375CL MeMO Pad 7 LTE
Tablets	Dell Streak
Tablets	Dell Streak Mini 5
Tablets	Dell Streak 7
Tablets	Huawei S10-103LT Mediapad 10 FHD
Tablets	Huawei 403HW MediaPad
Tablets	Huawei S10-231W MediaPad 10 Link+
Tablets	LG V520 G Pad X 8.0

Tablets	ZTE K81
Tablets	ZTE K9OU 10.1
Tablets	ZTE V55
Tablets	Apple iPad 1 WiFi (A1219)
Tablets	Apple iPad 1 (A1337)
Tablets	Apple iPad 2 WiFi (A1395)
Tablets	Apple iPad 2 (A1396)
Tablets	Apple iPad 2 (A1397)
Tablets	Apple iPad 3 (A1403)
Tablets	Apple iPad 3 WiFi (A1416)
Tablets	Apple iPad 3 (A1430)
Tablets	Apple iPad 4 WiFi (A1458)
Tablets	Apple iPad 4 (A1459)
Tablets	Apple iPad 4 (A1460)
Tablets	Apple iPad Pro 12.9" WiFi (A1584)
Tablets	Apple iPad Pro 12.9" (A1652)
Tablets	iPad Pro 10.5" (A1701)
Tablets	Apple iPad Pro 9.7" WiFi (A1673)
Tablets	Apple iPad Pro 9.7" (A1674)
Tablets	Apple iPad Pro 9.7" (A1675)
Tablets	Apple iPad mini WiFi (A1432)
Tablets	Apple iPad mini (A1454)
Tablets	Apple iPad mini (A1455)
Tablets	Apple iPad Air WiFi (A1474)
Tablets	Apple iPad Air (A1475)
Tablets	Apple iPad Air (A1476)
Tablets	Apple iPad Air 2 WiFi (A1566)
Tablets	Apple iPad Air 2 (A1567)
Tablets	Apple iPad mini with Retina display WiFi (A1489)
Tablets	Apple iPad mini with Retina display (A1490)
Tablets	Apple iPad mini with Retina display (A1491)
Tablets	Apple iPad mini 3 WiFi (A1599)
Tablets	Apple iPad mini 3 (A1600)
Tablets	Apple iPad mini 3 (A1601)
Tablets	Apple iPad mini 4 (A1538) WiFi
Tablets	Apple iPad mini 4 (A1550)
Tablets	Samsung SPH-P100 Galaxy Tab
Tablets	Asus P00I
Tablets	Fake ME7 CCTV (MA75)
Tablets	Fake M70 YFinside (MA75)
Tablets	Asus TF101 Transformer Eee Pad
Tablets	Asus TF201 Transformer Prime
Tablets	Samsung SM-T210 Galaxy Tab 3 7.0
Tablets	Lenovo TB-X704A Tab 4
Tablets	Lenovo TB-X704V Tab 4 10 Plus
Tablets	GoTab GT785X X Mini
Tablets	Samsung SGH-T869 Galaxy Tab 7.0 Plus
Tablets	Samsung SM-T217A Galaxy Tab 3
Tablets	Samsung SM-T231 Galaxy Tab 4
Tablets	Samsung SM-T230NU Galaxy Tab 4
Tablets	Asus TF300T Transformer Pad
Tablets	Samsung SM-T310 Galaxy Tab 3 8.0
Tablets	Samsung SM-T311 Galaxy Tab 3 8.0
Tablets	Samsung SM-T315 Galaxy Tab 3 8.0
Tablets	Samsung SM-T320 Galaxy Tab Pro 8.4

Tablets	Sony SGP321 Xperia Z Tab
Tablets	T1-821L Mediapad T1 Pro 8.0
Tablets	Samsung SM-T325 Galaxy Tab Pro 8.4
Tablets	Samsung SM-T330NU Galaxy Tab 4 8.0
Tablets	Samsung SM-T335 Galaxy Tab 4 8.0
Tablets	Samsung SM-T337A Galaxy Tab 4
Tablets	Samsung SM-T337V
Tablets	Samsung SM-T377A Galaxy Tab E
Tablets	Samsung SM-T377V Galaxy Tab E 8.0
Tablets	Samsung SM-T377R4 Galaxy Tab E 8.0
Tablets	Samsung SM-T385 Galaxy Tab A
Tablets	Barnes and Noble BNTV400 Nook HD
Tablets	LG V410 G Pad 7.0 LTE
Tablets	LG V400 G Tablet 7.0
Tablets	LG V480 G Tablet 8.0
Tablets	LG V490 G Tablet 8.0 4G
Tablets	LG VK410 G Pad 7.0
Tablets	LG LGUK410 G Pad 7.0
Tablets	LG V495 G Pad F 8.0
Tablets	LG V521 G Pad X 8.0
Tablets	Samsung SM-T827R4 Galaxy Tab S3
Tablets	LG V496 G Pad F 8.0
Tablets	Samsung SGH-i467 Galaxy Note 8.0
Tablets	Samsung SM-T530 Galaxy Tab 4 7.0
Tablets	Samsung SM-T530NU Galaxy Tab 4 10.1
Tablets	SM-T530NN Galaxy Tab 4 10.1
Tablets	Samsung SM-T560NU Galaxy Tab E 9.6
Tablets	Samsung SM-T378V Galaxy Tab E
Tablets	Samsung SM-T560 Galaxy Tab E 9.6
Tablets	Samsung SM-T561 Galaxy Tab E 9.6
Tablets	Samsung SM-T567V Galaxy Tab E 9.6
Tablets	Samsung SM-T805W Galaxy Tab S 10.5
Tablets	LG VK815 G Pad X
Tablets	Samsung SM-T817A Galaxy Tab S2
Tablets	Samsung SM-T817R4 Galaxy Tab S2 9.7
Tablets	Samsung SM-T818V Galaxy Tab S3
Tablets	Samsung SM-T818W Galaxy Tab S2
Tablets	Sony SGP561
Tablets	Huawei T1-701u Honor Play 7.0
Tablets	Huawei T1-701w T1 7.0
Tablets	Samsung SM-T525 Galaxy Tab Pro 10.1
Tablets	Shinco FD790
Tablets	Samsung SM-T807T Galaxy Tab S 10.5
Tablets	Google C1502W Pixel C
Tablets	Samsung GT-N5110 Galaxy Note 8.0 WiFi
Tablets	Samsung GT-P5113 Galaxy Tab 2 10.1
Tablets	Samsung GT-N5120 Note 8.0 LTE
Tablets	Samsung GT-P5200 Galaxy Tab 3 10.1
Tablets	Samsung GT-P5220 Galaxy Tab 3 10.1
Tablets	LG LK430 G Pad F 7.0
Tablets	UK495 G Pad F 8.0
Tablets	Samsung SGH-i497 Galaxy Tab 2 10.1
Tablets	LG VK700 G Pad 10.1
Tablets	Acer B1-730 Iconia One 7
Tablets	Acer B1-770 Iconia One 7

Tablets	Acer B3-A30 Tab One 10
Tablets	Acer A1-840FHD Iconia Tab 8
Tablets	Samsung SGH-i957 Galaxy Tab 8.9
Tablets	Acer A500 Iconia Tab
Tablets	LG V500 G Pad 8.3
Tablets	Samsung SPH-P500 Galaxy Tab 2 10.1
Tablets	Samsung SM-T531 Galaxy Tab 4 10.1
Tablets	Samsung SM-T535 Galaxy Tab 4 10.1
Tablets	Samsung SM-T537A Galaxy Tab 4
Tablets	Samsung SM-T537R4 Galaxy Tab 4 10.1
Tablets	Samsung SM-T537V Galaxy Tab 4 10.1
Tablets	Barnes and Noble BNTV600 Nook HD+
Tablets	Samsung SM-P600 Galaxy Note 10.1
Tablets	Samsung SPH-P600 Galaxy Tab 10.1
Tablets	Samsung SHV-E230S Note 10.1 LTE
Tablets	Motorola MZ601 XOOM
Tablets	Samsung SM-P601 Galaxy Note 10.1
Tablets	Samsung SM-P602 Galaxy Note 10.1
Tablets	Samsung SM-P605 Galaxy Note 10.1
Tablets	Samsung SM-P605V Galaxy Note 10.1
Tablets	Samsung SM-T520 Galaxy Tab Pro 10.1
Tablets	PLE-703L MediaPad M2 7.0
Tablets	M2-803L Mediapad M2 8.0
Tablets	SM-T585 Galaxy Tab A 10.1 2016
Tablets	Samsung SM-T550 Galaxy Tab A 9.7
Tablets	Samsung SM-P607T Galaxy Note 10.1
Tablets	Motorola MZ609 XYBoard 8.2
Tablets	Motorola MZ617 XYBoard 10.1
Tablets	Samsung SM-T677A Galaxy View
Tablets	LG V700 G Tablet 10.1
Tablets	Samsung SCH-i705 Galaxy Tab 2
Tablets	Samsung SM-T700 Galaxy Tab S
Tablets	Samsung SM-T705W Galaxy Tab S 8.4
Tablets	Samsung SM-T707A Galaxy Tab S 8.4
Tablets	Samsung SM-T719 Galaxy Tab S2
Tablets	Silverline SL726NC
Tablets	LG UK750 G Pad X II 10.1
Tablets	Samsung SGH-T779 Galaxy Tab 2 10.1
Tablets	Samsung SCH-i800 Galaxy Tab
Tablets	Samsung SM-T807A Galaxy Tab S
Tablets	Samsung SM-T807V Galaxy Tab S
Tablets	Samsung SM-T807P Galaxy Tab S
Tablets	Samsung SM-T807R4 Galaxy Tab S 10.5
Tablets	LG VK810 G Pad 8.3
Tablets	Samsung SM-T810 Galaxy Tab S2 9.7
Tablets	Samsung SM-T817V Galaxy Tab S2
Tablets	Samsung SCH-i815 Galaxy Tab 7.7
Tablets	Samsung SM-T817P Galaxy Tab S2
Tablets	ONDA V819i Intel Bay Trail-T
Tablets	Samsung SM-T837A Tab S4
Tablets	Samsung SGH-T849 Galaxy Tab
Tablets	Lenovo YT3-X50L Yoga Tab 3
Tablets	Lenovo YT3-850F Yoga Tab 3 8
Tablets	Samsung SM-P900 Galaxy Note Pro 12.2
Tablets	Samsung SM-T900 Galaxy Tab Pro 12.2

Tablets	VFD 1100 Tab Mini 7
Tablets	VF-1397 Smart Tab 4G
Tablets	LG V900 Optimus Pad
Tablets	Samsung SM-P905 Galaxy Note Pro 12.2
Tablets	Samsung SM-P905V Galaxy Note Pro 12.2
Tablets	Samsung SCH-i905 Galaxy Tab 10.1 LTE
Tablets	Alcatel 9007T One Touch
Tablets	Samsung SM-P907A Galaxy Note Pro
Tablets	LG V909 G-Slate
Tablets	Samsung SCH-I915 Galaxy Tab 10.1 Note II
Tablets	Samsung SCH-I925 Galaxy Tab 10.1 Note
Tablets	Samsung SCH-I925 Galaxy Tab 10.1 Note
Tablets	LG V930 G Pad X
Tablets	V935 G Pad II 10.1
Tablets	Huawei S8-301L Mediapad M1 8.0
Tablets	Huawei S7-931w MediaPad 7Pad Lite
Tablets	JXD P1000
Tablets	Juning K1
Tablets	MTK KNC MD-1008
Tablets	Samsung GT-P1000 Galaxy Tab
Tablets	Samsung GT-P1000N Galaxy Tab
Tablets	Samsung GT-P1010 Galaxy Tab
Tablets	Smart Tab 3G
Tablets	Smartab ST1009
Tablets	Vodafone VF-1296 Tab Grand 6
Tablets	VF-1497 Tab Prime 6
Tablets	Chinese Brand GD Ippo rk3026
Tablets	Samsung GT-P3100 Galaxy Tab 2 7.0
Tablets	Samsung GT-P3110 Galaxy Tab 2 7.0
Tablets	Samsung GT-P3113TS Galaxy Tab 2 7.0
Tablets	Dell 3830 Venue 8
Tablets	Lenovo S5000-F
Tablets	A3000 IdeaPad
Tablets	Lenovo A3500-FL
Tablets	Lenovo TB2-X30F Tab 2 A10-30
Tablets	Lenovo A10-70 A7600-H
Tablets	Lenovo S6000L-F
Tablets	Samsung GT-P5100 Galaxy Tab 10.1
Tablets	Samsung GT-P5110 Galaxy Tab II 10.1
Tablets	Samsung GT-P5210 Galaxy Tab 3 10.1
Tablets	Samsung GT-P6200 Galaxy Tab 7.0 Plus
Tablets	Samsung GT-P6210 Galaxy Tab Plus 7.0
Tablets	RCA CT9223W97 Pro 12
Tablets	RCA RCT6203W46 Pro 10
Tablets	RCA RCT6303W87DK 10 Viking Pro
Tablets	RCA RCT6773W22 7 Voyager
Tablets	Samsung GT-P6800 Galaxy Tab 7.7
Tablets	Samsung GT-P7100 Galaxy Tab 10.1
Tablets	Samsung GT-P7300 Galaxy Tab 8.9
Tablets	Samsung GT-P7310 Galaxy Tab 8.9
Tablets	Samsung GT-P7320 Galaxy Tab 8.9 LTE
Tablets	Samsung GT-P7500 Galaxy Tab 10.1
Tablets	Samsung GT-P7510 Galaxy Tab 10.1
Tablets	Samsung GT-N8000 Galaxy Note 10.1
Tablets	Samsung GT-N8010 Galaxy Note 10.1

Tablets	Samsung GT-N8013 Galaxy Note 10.1
Tablets	Samsung GT-N8020 Galaxy Note 10.1
Tablets	Samsung GT-P8110 Nexus 10
Tablets	MTK C8751M V75 Telephone Pad
Tablets	Tesco Hudl HT7S3
Tablets	Yarvik TAB462 Zania 10ic
Tablets	Yarvik TAB13-201 13c
Tablets	Amazon Kindle Fire
Tablets	Amazon PR53DC Fire HD 8
Tablets	Amazon X43Z60 Kindle Fire HD
Tablets	Samsung SM-T2105 Galaxy Tab 3 Kids
Tablets	Alcatel 9020A Trek HD
Tablets	HTC OP82100 Nexus 9
Tablets	Alcatel 9006W One Touch Pixi 7
Tablets	Verizon QTASUN1
Tablets	Chromo CI2419
Tablets	iQ3204 Magic 11.6
Tablets	iQ9016 Grand 4G
Tablets	MLS iQ9610 Angel 3G
Tablets	AU SOT21 (XPERIA Z2 Tablet)
Tablets	AU FJT21 (ARROWS Tab)
Tecno	D3
Tecno	Camon CX
Tecno	Y2
Tecno	W2
Tecno	F3
Tecno	CF7 Tecno
Tecno	KA70 Spark 2
Tecno	LA6 Pouvoir 1
Tecno	LA7 Pouvoir 2
Tecno	KA7 Spark 2
Tecno	L9 Plus
Tecno	M3
Tecno	N3
Tecno	P3
Tecno	P5 Plus
Tecno	A9 Phantom 6 Plus
Tecno	T6
Tecno	N7
Tecno	T8
Tecno	T312
Tecno	T343
Tecno	T340
Tecno	T349
Tecno	T21 (USB)
Tecno	T21 (BT)
Tecno	T36 (USB)
Tecno	T36 (BT)
Tecno	T484
Tecno	T551
Tecno	T605
Tecno	T608
Tecno	T611S
Tecno	T728
Tecno	T858

Tecno	WX4
Telit	C1 Car phone
Telit	X60
Telit	X70
Telit	X95
Telit	X110
Telit	X120
Telit	X170
Telit	X210
Texet	TM-5172 maxi qHD
Texet	TM-D327
Texet	TM-D328_DS
Torque	Droidz Mate
Torque	Driodz Atom
Torque	Driodz Sport
Torque	D9
Torque	i58 Spark
Toshiba	IS04 Regza
Toshiba	AT200 16GB Tab
Toshiba	G500 Portege
Toshiba	TG01
Toshiba	TG01CV
True	S1 GO Live
True	True Beyond Tab 3G
True	True Beyond 4G
True	SSB-508D Slim Phone
Turkcell	T10
Turkcell	T11 MaxiPhone
Turkcell	T11 Racer II
Turkcell	T20
Turkcell	T21 Maxi Plus5
Turkcell	T30 Maxi Pro5
Turkcell	T50
Turkcell	T60
UMI	Generic Android
UMI	TOUCH
UMI	SUPER
UMI	Eagle Tab 10
UMI	UMI X2
UMI	UMI Iron Pro
UMI	UMI Fair
UMI	UMI Rome X
UMX	MXW1
UMX	MXC-450 Companion
UMX	MXC-560
UMX	MXC-570
UMX	MXC-628 Flip
UMX	MXE-635a
UMX	MXE-670C
UMX	U670C Max Bravo
UMX	SN357 MAXquartz V351
UMX	U671C
UMX	U673C
UMX	MXG401
UMX	U680

Ubiquam	U-200
Ubiquam	U-300
Ubiquam	U-400
Ubiquam	U-520
Ubiquam	U-800
Ulefone	Power 2
Ulefone	Power 3S
Ulefone	Power 5
Ulefone	T1
Ulefone	Note 7_DS
Ulefone	S7
Ulefone	S8
UniMile	PR-600
Unnecto	UN510 Drone X
Unnecto	U510 Drone X
Unnecto	U510 2NA Drone XS
Unnecto	U613 Quattro S
Unnecto	U700-2NA Drone Z
Unnecto	U4051 Swift
Unnecto	U5151 Bolt
Unnecto	U901 Air 4.5
Unnecto	U830 Rush
VIVO	NEX S
VIVO	X3T
VIVO	X1S
VIVO	X3L
VIVO	X6L
VIVO	X3S W
VIVO	X5L
VIVO	X5V
VIVO	X6A
VIVO	X6Plus D
VIVO	X6S A
VIVO	S7i(t)
VIVO	X5F
VIVO	X5M
VIVO	X5S L
VIVO	X5 Pro
VIVO	X5Max+
VIVO	X5Max S
VIVO	X510T Xplay
VIVO	X7
VIVO	X6 plus
VIVO	Y83A_DS
VIVO	1910_DS V17 Pro
VIVO	V1818CA_DS Y91
VIVO	V1916A Iqoo Pro 5G
VIVO	Y927
VIVO	Y913_DS
VIVO	V1938T X30 Pro
VIVO	Y55_DS
VIVO	V1921A_DS Z5
VIVO	Y75s_DS
VIVO	Y31
VIVO	V1928A_DS U3x

VIVO	X5Pro V_DS
VIVO	X9L_DS
VIVO	Y35A
VIVO	X6Plus A
VIVO	Y923_DS
VIVO	V1818CA_DS Y93s
VIVO	PD1415D X6D
VIVO	Y11iW
VIVO	Y11
VIVO	Y11i T
VIVO	Y13
VIVO	Y13iL_DS
VIVO	Y17T
VIVO	Y17W
VIVO	Y18L
VIVO	Y20T
VIVO	Y21L
VIVO	Y23L
VIVO	Y27
VIVO	Y29L
VIVO	Y31A_DS
VIVO	Y35
VIVO	X710L Xshot
VIVO	1915_DS
VIVO	V1936A_DS Iqoo Neo 855
VIVO	V1924A Nex 3
VIVO	Y66L
VIVO	X20
VIVO	Y67L
VIVO	Y67A
VIVO	X20 Plus A
VIVO	V1941A_DS U3
VIVO	V1818CA Y95
VIVO	V1731CA Y73
VIVO	V1813A_DS Z3i
VIVO	V1911A_DS Z5x
VIVO	V1814A_DS X21s
VIVO	1818_DS V15 Pro
VIVO	1901_DS
VIVO	1913 Nex
VIVO	1801_DS Y71i
VIVO	1813 Nex Dual
VIVO	V1813BT_DS Z3
VIVO	V1831A_DS S1
VIVO	V1832A_DS S1 Pro
VIVO	V1838A_DS X27
VIVO	V1818CT Y91
VIVO	V1732A Y81s
VIVO	V1818A U1
VIVO	1804 V11
VIVO	V1816A X23
VIVO	V1824A_DS iQOO
VIVO	V1836A X27 Pro
VIVO	V1821A Nex
VIVO	Y51t L

VIVO	Y37
VIVO	Y51
VIVO	Y51A
VIVO	Y53 1606
VIVO	Y53L
VIVO	V1730EA Z1 Lite
VIVO	Y55s 1610
VIVO	PD1621B Y66i A
VIVO	X520A Xplay3S
VIVO	1727 V9
VIVO	1714 Y69
VIVO	Y71A
VIVO	V3 MAX
VIVO	V3_DS
VIVO	V1730DT Z1i
VIVO	V1813A Y97
VIVO	V1813A Y97 (Bluetooth)
VIVO	V1
VIVO	X21i
VIVO	X21UD
VIVO	1723 V9
VIVO	V1809T X23
VIVO	1806 V11i
VIVO	V1813BA Z3
VIVO	V1809A X23
VIVO	NEX A
VIVO	Y85A Youth
VIVO	V1801A0 Z1
VIVO	Y83
VIVO	Y83 (Bluetooth)
VIVO	Y67
VIVO	Y79A
VIVO	Y75A
VIVO	Y66
VIVO	Xplay5A
VIVO	Xplay 6
VIVO	X9s
VIVO	X9S Plus
VIVO	X20A
VIVO	X21A
VIVO	V1901A_DS Y3
VIVO	1724 Y71
VIVO	X9i
VIVO	1601 V5
VIVO	1609 V5 Lite
VIVO	1611_DS V5 Plus
VIVO	1713 V5S
VIVO	1716 V7 Plus
VIVO	V1938CT X30
VK Mobile	650 - Kickflip
Verizon	QTAXIA1
Verizon	QMV7A Ellipsis 7
Verizon	QMV7B Ellipsis 7
Verizon	QTAQZ3 Ellipsis 8
Verizon	QTAQZ3KID Ellipsis Kids

Verizon	QTAIR7 Ellipsis
Verizon	QTASUN1
Vertu	Ayxta (Constellation F)
Vertu	Ascent X
Vertu	Ascent Ti (RM-267V)
Vertu	Ascent Ti-C (RM-467V)
Vertu	Constellation (RHV-8)
Vertu	Signature-S (RM-266V)
Vertu	Ascent (RHV-1)
Vertu	Signature (NPM-7)
Vertu	Ascent RHV-3
Vertu	Ascent RHV-5
Vertu	Signature (RHV-2)
Vertu	Constellation T (RM-681V) (No Client)
Vertu	Constellation T (RM-681V) (Using Client)
Vertu	Constellation Quest (RM-582V) (No Client)
Vertu	Constellation Quest (RM-582V) (Using Client)
Vertu	Vertu Ti
Vertu	VM-01 Aster
Vertu	Signature Touch
Vertu	Signature Touch VM-03
Vertu	VM-06 Signature S 2017 S
Vertu	VM-08 Constellation x
Verykool	R23 (USB)
Verykool	R23 (BT)
Verykool	RS75
Verykool	RS90 Vortex
Verykool	i129
Verykool	i133
Verykool	i320
Verykool	s350
Verykool	s352
Verykool	S400
Verykool	S470
Verykool	i607
Verykool	I674
Verykool	R623
Verykool	S728
Verykool	s732
Verykool	s735
Verykool	s758
Vestel	Venus V3 5010
Videocon	V7500 Zeus
ViewSonic	VS14032 ViewPhone3
ViewSonic	ViewPad 7
Vodafone	Magic (Google)
Vodafone	VDA
Vodafone	VDA II
Vodafone	VFD 610
Vodafone	VFD 720 Smart N9
Vodafone	VDA V
Vodafone	VPA
Vodafone	VPA Compact
Vodafone	Vod. VPA Compact GPS
Vodafone	VPA Compact S

Vodafone	VPA Touch
Vodafone	Vod. VPA Compact II
Vodafone	Vod. VPA III
Vodafone	Vod. VPx
Vodafone	Vod. VPA Compact III
Vodafone	Vod. VPA Compact IV
Vodafone	Vod. VPA Compact V
Vodafone	T20
Vodafone	VFD 100 Smart Kicka ve
Vodafone	VFD 120
Vodafone	Rockr F181W 3G
Vodafone	VFD 200
Vodafone	VFD 300 Smart Mini 7
Vodafone	340
Vodafone	345
Vodafone	353
Vodafone	354
Vodafone	Vodafone 455 (USB)
Vodafone	Vodafone 455 (BT)
Vodafone	VFD 500 Smart Turbo 7
Vodafone	550 (Bluetooth (no multimedia))
Vodafone	550 (USB)
Vodafone	526
Vodafone	527
Vodafone	541
Vodafone	VF543
Vodafone	VFD 600 Smart Prime 7
Vodafone	VFD 710 Smart V8
Vodafone	VFD 700 Smart Ultra 7
Vodafone	VFD 510 Smart E8
Vodafone	VFD 511 Smart E8
Vodafone	VFD 513 Smart E8
Vodafone	VFD 820 Smart X9
Vodafone	VFD 527 Smart E9
Vodafone	VFD 900 Smart Platinum 7
Vodafone	VF695 Smart first 6
Vodafone	VF-696 Smart grant
Vodafone	555 Blue
Vodafone	VF-795 Smart Speed 6
Vodafone	845
Vodafone	888N Smart 4
Vodafone	Vodafone Smart Ultra 6
Vodafone	890N Smart 4 Turbo
Vodafone	VF-895N Smart Prime 6
Vodafone	v1240
Vodafone	v1415
Vodafone	1520
Vodafone	v1605
Vodafone	v1615
Vodafone	v1620
Vodafone	v7505
Vodafone	625
Vodafone	710
Vodafone	715
Vodafone	720

Vodafone	736
Vodafone	810
Vodafone	725
Vodafone	735
Vodafone	V-X760
Vodafone	785 Smart 4 Mini
Vodafone	830i
Vodafone	858 Smart
Vodafone	V860 Smart II
Vodafone	Smart Tab 3G
Vodafone	VF-1296 Tab Grand 6
Vodafone	VFD 1100 Tab Mini 7
Vodafone	VFD 1300 Smart Tab N8
Vodafone	ZTE P752D Smart Chat
Vodafone	VF-1397 Smart Tab 4G
Vodafone	VF-1497 Tab Prime 6
Vonino	Xavy_T7
Vonino	Druid_L10
WILLCOM	WX320K
WILLCOM	WX300K
WILLCOM	WX310K
WILLCOM	WX320KR
WILLCOM	WX330K
WILLCOM	WX331K(HONEY BEE)
WILLCOM	WX331KC(HONEY BEE 2)
WILLCOM	WX333K(HONEY BEE 3)
WILLCOM	WX334K(HONEY BEE BOX)
WILLCOM	WX340K
WILLCOM	WX341K(BAUM)
WILLCOM	WS018KE(WILLCOM 9)
WILLCOM	WS009KE
WILLCOM	WS023T(LU)
WILLCOM	WX320T
WILLCOM	WX310J
WILLCOM	WX220J
WILLCOM	WX321J
WILLCOM	WX330J
WILLCOM	WX330JE
WILLCOM	WX350K(HONEY BEE 4)
WILLCOM	WX01K
WILLCOM	WX02K
WILLCOM	WX03K
WILLCOM	WX04K(DIGNO DUAL)
WILLCOM	WX05K
WILLCOM	WX07K
WILLCOM	WX09K
WILLCOM	WX11K
WILLCOM	WX12K
WILLCOM	WX08K
WILLCOM	WX06K Honey Bee
WILLCOM	WX10K Digno Dual 2
WILLCOM	WX04SH Aquos Phone
Wiko	Cink Five
Wiko	Cink King
Wiko	Cink Peax 2

Wiko	Cink Slim
Wiko	Dolby
Wiko	Fever
Wiko	Jerry
Wiko	Jerry 2
Wiko	Jimmy
Wiko	Lenny2
Wiko	Lenny3
Wiko	C210AE
Wiko	v3740 Lenny 4 Plus
Wiko	W_C800 View 2
Wiko	W_K300 Jerry 3
Wiko	W-V600 Harry2
Wiko	W-P220 View 2 Go
Wiko	View Prime
Wiko	Sunny 2 Plus
Wiko	U Feel Lite
Wiko	Freddy
Wiko	View XL
Wiko	Wim Lite
Wiko	Minimi
Wiko	Minz+
Wiko	Ozzy
Wiko	Pulp 4G
Wiko	Rainbow
Wiko	Rainbow Jam 4G
Wiko	Rainbow Lite 4G
Wiko	Ridge 4G
Wiko	Ridge Fab 4G
Wiko	Robby
Wiko	Stairway
Wiko	Sunset
Wiko	Sunset 2
Wiko	Harry
Wiko	Highway
Wiko	Highway Pure 4G
Wiko	Highway Star
Wiko	Kite
Wiko	Wax
Wiko	GOA
Wiko	Riff
Wiko	Riff 2
Wiko	Lubi 4
Wiko	Lubi5_DS
Wiko	Tommy
Wiko	Tommy2
Xiaomi	Fake Xiaomi MI NOTE LTE
Xiaomi	Fake Xiaomi HM NOTE 1TD
Xiaomi	Fake Xiaomi HM 1STD Redmi
Xiaomi	2013121\HM NOTE 1W Redmi Note
Xiaomi	Mi Mix 2
Xiaomi	M1810E5E Mi Mix 3
Xiaomi	M1810E5A Mi Mix 3
Xiaomi	M1901F7BE Redmi Note 7 Pro
Xiaomi	M1908C3KG_DS Redmi 8A

Xiaomi	MCE3B_DS Redmi 5A
Xiaomi	M2004J11G_DS Poco F2 Pro
Xiaomi	M2003J6B2G_DS Redmi Note 9 Pro
Xiaomi	M1904F3BC_Mi Cc 9
Xiaomi	M1910F4E_DS Mi CC9 Pro
Xiaomi	M2003J6A1G_Redmi Note 9S
Xiaomi	M2004J19C_DS Redmi 9
Xiaomi	Redmi Note 5 Pro
Xiaomi	2014813_DS Redmi
Xiaomi	M1906F9SC_MI CC 9e
Xiaomi	M1910F4S_Mi Note 10 Pro
Xiaomi	M1908C3JE_DS Redmi Note 8
Xiaomi	M2001J11E_Redmi K30 Pro
Xiaomi	Redmi K30i 5G
Xiaomi	M1910F4G_DS Mi Note 10
Xiaomi	M1908C3IC_DS Redmi 8
Xiaomi	M1908F1XE_DS Mi 9 Pro
Xiaomi	M1810F6LE_DS Redmi 7
Xiaomi	M1903F11I_DS Redmi K20 Pro
Xiaomi	M1810F6I_DS Redmi Y3
Xiaomi	M1901F7S_Redmi Note 7 Pro
Xiaomi	MD16S_DS Redmi Y1
Xiaomi	MD16_DS Redmi Y1 Lite
Xiaomi	M1903F11G_DS Mi 9T Pro
Xiaomi	M1903C3EI_DS Redmi 7A
Xiaomi	M1903C3EG_DS Redmi 7A
Xiaomi	M1906F9SI_Mi A3
Xiaomi	M1906G7E_Redmi Note 8 Pro
Xiaomi	M1904F3BG_Mi 9 Lite
Xiaomi	M1906G7G_Redmi Note 8 Pro
Xiaomi	M1903F10G_DS Mi 9T
Xiaomi	M1807E8A_MI 8 PRO
Xiaomi	M1902F1A_Mi 9
Xiaomi	Xiaomi M1901F9E_MI Play
Xiaomi	M1903F2A_MI 9 SE
Xiaomi	M1805D1SE_DS Redmi 6 Pro
Xiaomi	M1903C3GG_Redmi Go
Xiaomi	2014811_Redmi 2
Xiaomi	Redmi Note 2
Xiaomi	MDE40_Mi Max 2
Xiaomi	MDE1_Redmi 5
Xiaomi	8 SE
Xiaomi	M1804E4A_MI Max 3
Xiaomi	M1804D2SE_6X
Xiaomi	M1804C3DE_Redmi 6
Xiaomi	M1803D5XE_Redmi 6
Xiaomi	M1901F7E_Redmi Note 7
Xiaomi	MDG6_Redmi Note 5A
Xiaomi	M1804C3CE_Redmi 6A
Xiaomi	M1805E10A_POCOPHONE F1
Xiaomi	MEE7S_Note 5_DS
Xiaomi	M1803D5XA_Mi Mix 2S
Xiaomi	MI 6X
Xiaomi	MI 8
Xiaomi	M1807E8S_MI 8 Explorer Edition

Xiaomi	M1808D2TG Mi 8 Lite
Xiaomi	Redmi Pro
Xiaomi	Redmi 3X
Xiaomi	SKR-A0 Black Shark
Xiaomi	M1903F11A Redmi K20 Pro
Xiaomi	SKW-A0 Black Shark 2
Xiaomi	MDT1 Redmi 5
Xiaomi	M1803E7SG Redmi Note 5
Xiaomi	TD-LTE M1806D9E Mi Pad 4
Xiaomi	M1803E7SH Redmi Note 5
Xiaomi	MDG2 Mi A1
Xiaomi	Redmi 3
Xiaomi	HM 1W Redmi
Xiaomi	Redmi 3S
Xiaomi	Redmi 4
Xiaomi	Redmi 5 Plus
Xiaomi	Redmi 4A
Xiaomi	Redmi Note 3
Xiaomi	Redmi Note 4X
Xiaomi	Redmi 4X
Xiaomi	Redmi Note 4
Xiaomi	M1806E7TG Redmi Note 6 Pro
Xiaomi	M1808D2TE Mi 8 Lite
Xiaomi	AWM-A0 Black Shark Helo
Xiaomi	QIN 1s AI
Xiaomi	QIN 1s AI (USB)
Xiaomi	Redmi Note 5A
Xiaomi	M1803E6G Redmi S2
Xiaomi	M1804C3CG Redmi 6A
Xiaomi	HM 1SW Hongmi 1S
Xiaomi	A0101 Mi Pad 7.9
Xiaomi	Mi 4c
Xiaomi	Mi 5
Xiaomi	Mi 5c
Xiaomi	Mi 5s
Xiaomi	Mi 5s Plus
Xiaomi	Mi 5X
Xiaomi	MCE16 Mi 6
Xiaomi	MCE8 Mi Note 3
Xiaomi	MI-1S
Xiaomi	MI 2
Xiaomi	MI-2A
Xiaomi	MI2S
Xiaomi	MI MAX
Xiaomi	MI 2 Smart
Xiaomi	M1804D2SG Mi A2
Xiaomi	M1805D1SG Mi A2 Lite
Xiaomi	MI-3
Xiaomi	Mi 4i
Xiaomi	Fake Xiaomi MI-4LTE
Xiaomi	MI 4W MI-4
Xiaomi	MI 3W
Xiaomi	MI 4LTE
Xiaomi	Mi Mix (Logical (No Multimedia))
Xiaomi	Mi Mix (Logical (Only Multimedia))

Yarvik	Luna-TAB07-151
Yarvik	Xenta TAB07-200
Yarvik	Luna TAB09-100
Yarvik	TAB13-201 13c
Yarvik	TAB462 Zania 10ic
Ymobile	302HW
Ymobile	Nexus 6
Ymobile	301JR
Ymobile	403SH(AQUOS CRYSTAL Y2)
Ymobile	404SH(AQUOS Xx-Y)
Yotaphone	C9660
Yotaphone	YD201 Yotaphone 2
Zanco	beetle b33tle
Zanco	AMO505_DS
Zonda	ZMKN110Z
Zonda	ZMUR300
Zonda	ZMTN615
Zonda	ZMEM1120
ZTE CDMA	Generic Android
ZTE CDMA	V55
ZTE CDMA	C70
ZTE CDMA	V72C Optik 2
ZTE CDMA	C76
ZTE CDMA	C78
ZTE CDMA	C79
ZTE CDMA	C88
ZTE CDMA	C90
ZTE CDMA	S165
ZTE CDMA	A210 CAPTR II
ZTE CDMA	Z2321U
ZTE CDMA	Z2321UL
ZTE CDMA	Z233V
ZTE CDMA	Z233VL Cymbal (USB)
ZTE CDMA	Z233VL Cymbal (BT)
ZTE CDMA	Z233V Cymbal (USB)
ZTE CDMA	Z233V Cymbal (BT)
ZTE CDMA	A310 MSGM8 II
ZTE CDMA	F350 Salute
ZTE CDMA	A410 TXTM8 3G
ZTE CDMA	A415
ZTE CDMA	F450 Adamant
ZTE CDMA	X500 Score (Cricket)
ZTE CDMA	X500 Score
ZTE CDMA	X501 Groove
ZTE CDMA	Z665C Valet
ZTE CDMA	Z223V
ZTE CDMA	Z750C Savvy
ZTE CDMA	Z768G Midnight
ZTE CDMA	Z796C Majesty
ZTE CDMA	Z837VL Zfive 2
ZTE CDMA	Z839
ZTE CDMA	E520 Agent
ZTE CDMA	N810 Reef
ZTE CDMA	N817 Quest
ZTE CDMA	N850 Fury

ZTE CDMA	N850L Director
ZTE CDMA	N860 Warp
ZTE CDMA	N861 Warp Sequent
ZTE CDMA	N880E
ZTE CDMA	N880F
ZTE CDMA	N880S
ZTE CDMA	N881F
ZTE CDMA	N910
ZTE CDMA	D930 Chorus
ZTE CDMA	K81
ZTE CDMA	K9OU 10.1
ZTE CDMA	N9516 Imperial II
ZTE CDMA	N9137 Tempo X
ZTE CDMA	Z917VL ZMax Champ
ZTE CDMA	Z936L Lever
ZTE CDMA	Z963U Imperial Max
ZTE CDMA	Z986U Blade Max 3
ZTE CDMA	Z986DL Max Blue
ZTE CDMA	Z752C Zephyr
ZTE CDMA	Z717VL Citrine
ZTE CDMA	V967S
ZTE CDMA	N8000 Engage LT
ZTE CDMA	MWP3505US Render (USB)
ZTE CDMA	MWP3505US Render (BT)
ZTE CDMA	N8000 Engage MT
ZTE CDMA	N800 Awe
ZTE CDMA	V8000 Engage
ZTE CDMA	N9100
ZTE CDMA	N9101 Imperial
ZTE CDMA	N9120 Avid
ZTE CDMA	N9130
ZTE CDMA	N9132
ZTE CDMA	N9500 Flash
ZTE CDMA	N9510 Warp 4G
ZTE CDMA	N9511 Source
ZTE CDMA	N9515
ZTE CDMA	N9518 Warp
ZTE CDMA	N9520 Max
ZTE CDMA	N9560 Max XL
ZTE CDMA	N9810 Vital
ZTE CDMA	F555 Aspect (USB)
ZTE CDMA	F555 Aspect (BT)
ZTE GSM	Generic Android
ZTE GSM	Z983 Blade X Max
ZTE GSM	Z955L Zmax 2
ZTE GSM	Baker
ZTE GSM	Orange Rono
ZTE GSM	F6S
ZTE GSM	V1050 Blade 20 Smart
ZTE GSM	MO-01J MONO
ZTE GSM	A2020 Pro Axon 10 Pro
ZTE GSM	Blade A7 (2019)
ZTE GSM	MO-01K
ZTE GSM	NX405H Nubia 5S
ZTE GSM	Blade Q\STARTRAIL 4

ZTE GSM	Blade S6
ZTE GSM	A1P Axon Pro
ZTE GSM	K92
ZTE GSM	Blade A110
ZTE GSM	L110 Blade
ZTE GSM	Blade Telstra 4GX Plus A112
ZTE GSM	B112 Boost Zume 5
ZTE GSM	B2015 Axon Tianji mini
ZTE GSM	Z981 ZMax Pro
ZTE GSM	Z982 Blade Z Max
ZTE GSM	CARL
ZTE GSM	V.35
ZTE GSM	V220
ZTE GSM	Tara 3G (USB)
ZTE GSM	Tara 3G (BT)
ZTE GSM	G R260
ZTE GSM	NX402 Nubia Z5 Mini
ZTE GSM	NX403A Nubia Z5S mini
ZTE GSM	NX505J Nubia 7 Max
ZTE GSM	NX529J Nubia Z11 Mini
ZTE GSM	Blade A0620 A6
ZTE GSM	Z978 Blade V8 Pro
ZTE GSM	A2018 Axon 7S
ZTE GSM	A7010 Blade A7s
ZTE GSM	A2019 Axon 9 Pro
ZTE GSM	Nubia NX619J_DS Red Magic Mars
ZTE GSM	Nubia NX629J_DS Red Magic 3
ZTE GSM	Nubia NX659J_DS Red Magic 5G
ZTE GSM	A1R Axon
ZTE GSM	Z559DL Blade T2 Lite
ZTE GSM	NX611J Nubia Z18 Mini
ZTE GSM	BV0800 Blade V8
ZTE GSM	V0900 Blade V9
ZTE GSM	Z3001S
ZTE GSM	A0620
ZTE GSM	A0620 (Bluetooth)
ZTE GSM	NX531J Nubia Z11
ZTE GSM	NX551J Nubia M2
ZTE GSM	NX595J Nubia Z17S
ZTE GSM	NX606J Nubia Z18
ZTE GSM	NX608J Nubia N3
ZTE GSM	NX609J Nubia Red Magic
ZTE GSM	NX616J Nubia X
ZTE GSM	NX907J Nubia M2 Play
ZTE GSM	Q505T
ZTE GSM	NX507J Nubia 7 Mini
ZTE GSM	NX508J Nubia Z9
ZTE GSM	NX511J Nubia Z9 Mini
ZTE GSM	NX512J nubia Z9 Max
ZTE GSM	NX541J Nubia N1
ZTE GSM	NX513J Nubia My Prague
ZTE GSM	NX518J Nubia Z9 Max Elite
ZTE GSM	NX563J Nubia Z17
ZTE GSM	Blade BA601
ZTE GSM	Nubia NX569H Z17 Mini

ZTE GSM	Nubia NX569J Z17 Mini
ZTE GSM	NX573J Nubia M2 Lite
ZTE GSM	NX575J Nubia N2
ZTE GSM	R22
ZTE GSM	Vodafone 353
ZTE GSM	R228
ZTE GSM	ACQUA
ZTE GSM	Boston
ZTE GSM	Blade Apex
ZTE GSM	Blade Apex 3
ZTE GSM	Blade L2
ZTE GSM	V6 Plus Blade
ZTE GSM	Z5000A
ZTE GSM	Z5250A
ZTE GSM	Blade V7
ZTE GSM	Blade V770 SoshPhone 3
ZTE GSM	402ZT Blade Q+
ZTE GSM	Blade L3 Plus
ZTE GSM	Blade L7
ZTE GSM	Z813 Overture 2
ZTE GSM	V0720 Blade A2
ZTE GSM	A0616 Blade A3
ZTE GSM	V829 Blade G Plus
ZTE GSM	Z818L All Star
ZTE GSM	Z819L Stratos
ZTE GSM	Z820 Obsidian
ZTE GSM	Z832 Sonata 3
ZTE GSM	Z850 Grand X 2
ZTE GSM	Z851M Overture 3
ZTE GSM	Z855
ZTE GSM	Z861BL ZFive L
ZTE GSM	Z557BL ZFive
ZTE GSM	Z558VL ZFive C
ZTE GSM	Z862VL ZFive L
ZTE GSM	Z956 Grand X 4
ZTE GSM	Z828
ZTE GSM	Z828 Avid Plus
ZTE GSM	Z916BL Avid
ZTE GSM	Z836BL TracFone Z Five
ZTE GSM	Blade Apex 2
ZTE GSM	Blade III
ZTE GSM	Orange Dive 30
ZTE GSM	Blade Q
ZTE GSM	A430 Blade
ZTE GSM	Leo S1
ZTE GSM	N9519 Warp 7
ZTE GSM	Cute
ZTE GSM	GRAND X
ZTE GSM	FIT 4G Smart
ZTE GSM	Z932L Rapido
ZTE GSM	Z933 Grand X Virgin
ZTE GSM	Z987 Grand X Max+
ZTE GSM	Z999
ZTE GSM	S291 Grand S II
ZTE GSM	ICE

ZTE GSM	Internet 7 (USB)
ZTE GSM	Internet 7 (BT)
ZTE GSM	StarAddict
ZTE GSM	StarAddict II Plus
ZTE GSM	Jack 3G
ZTE GSM	San Francisco
ZTE GSM	Link
ZTE GSM	Soft Stone
ZTE GSM	StarTrail
ZTE GSM	StarTrail III
ZTE GSM	StarText
ZTE GSM	StarText II
ZTE GSM	StarNaute
ZTE GSM	STARNAUTE 2
ZTE GSM	T2 EasyTouch Discovery 2
ZTE GSM	A5 Sapo
ZTE GSM	R6
ZTE GSM	T6
ZTE GSM	R7
ZTE GSM	V9 Optus MyTab
ZTE GSM	V9
ZTE GSM	Light
ZTE GSM	V9A Light Tab2
ZTE GSM	Racer
ZTE GSM	T11 MaxiPhone
ZTE GSM	T11 Racer II
ZTE GSM	T55 Explorer 3
ZTE GSM	Turkcell T60
ZTE GSM	R90
ZTE GSM	T90
ZTE GSM	T95 Telstra
ZTE GSM	T96 Telstra
ZTE GSM	R100
ZTE GSM	T100
ZTE GSM	R101
ZTE GSM	F102
ZTE GSM	F103
ZTE GSM	T106
ZTE GSM	T108
ZTE GSM	R109
ZTE GSM	P103D1
ZTE GSM	GR221
ZTE GSM	P109A17
ZTE GSM	T116a Roamer
ZTE GSM	T126
ZTE GSM	Q150T
ZTE GSM	151 Text Edition
ZTE GSM	F152
ZTE GSM	F158
ZTE GSM	F160
ZTE GSM	F165
ZTE GSM	T165i Country
ZTE GSM	T165+ Explorer
ZTE GSM	T203
ZTE GSM	T U210

ZTE GSM	T U215
ZTE GSM	T U218
ZTE GSM	S218
ZTE GSM	R220
ZTE GSM	Z221
ZTE GSM	Z222
ZTE GSM	Z223
ZTE GSM	F230
ZTE GSM	T U230
ZTE GSM	G R231 Rome
ZTE GSM	P103F2
ZTE GSM	R236
ZTE GSM	G R250 ZEST 2
ZTE GSM	R252
ZTE GSM	F286 (Bluetooth)
ZTE GSM	F372S
ZTE GSM	F327s
ZTE GSM	F286 (USB)
ZTE GSM	N292 Atlas Edge
ZTE GSM	G N295 Dream
ZTE GSM	T303 Telstra Easy Call 3
ZTE GSM	P721F
ZTE GSM	X671
ZTE GSM	Messenger Edition 251
ZTE GSM	F256
ZTE GSM	Messenger Edition 261
ZTE GSM	G-N281 Vairy Touch II
ZTE GSM	301Z
ZTE GSM	F320
ZTE GSM	Z320 (USB)
ZTE GSM	Z320 (BT)
ZTE GSM	Z331
ZTE GSM	Z353VL Cymbal T
ZTE GSM	T403 Telstra Easy Call 4
ZTE GSM	Z433 Altair
ZTE GSM	A462 Telstra 4GX Plus
ZTE GSM	Blade A465
ZTE GSM	Blade A475
ZTE GSM	G-S511 TMN Easy 10
ZTE GSM	S516
ZTE GSM	S522
ZTE GSM	VF543
ZTE GSM	VFD 600 Smart Prime 7
ZTE GSM	A452 Blade
ZTE GSM	A512 Blade
ZTE GSM	A520 Blade
ZTE GSM	NX612J Nubia V18
ZTE GSM	NX589J Nubia Z17 Mini S
ZTE GSM	Blade V580
ZTE GSM	Vodafone Smart Ultra 6
ZTE GSM	T610 Blade D
ZTE GSM	Z660G Whir
ZTE GSM	Z667
ZTE GSM	Z667G Whirl 2
ZTE GSM	Z716BL Citrine

ZTE GSM	Z719DL Zmax One
ZTE GSM	Z667T Zinger
ZTE GSM	Z718TL Jasper
ZTE GSM	Z730 Concord II
ZTE GSM	X730
ZTE GSM	Tania (USB)
ZTE GSM	Tania (BT)
ZTE GSM	X672 Pico Mini Stone
ZTE GSM	T U720
ZTE GSM	P729J Blade
ZTE GSM	P736E Atlas
ZTE GSM	Z753G Paragon
ZTE GSM	Z791G Scend
ZTE GSM	Z792 Fanfare
ZTE GSM	Z797C Quartz
ZTE GSM	Z798BL Majesty Pro
ZTE GSM	Z799VL Majesty Pro
ZTE GSM	Z812
ZTE GSM	Z815 Fanfare 2
ZTE GSM	Z830
ZTE GSM	Z833
ZTE GSM	Z831
ZTE GSM	Z835 Maven 3
ZTE GSM	K88
ZTE GSM	P736V Crescent
ZTE GSM	Z740
ZTE GSM	Z740G Sonata 4G
ZTE GSM	P752T Maxi Plus 5
ZTE GSM	Z755 Sonata 2
ZTE GSM	X760 Vegas
ZTE GSM	V768 Concord
ZTE GSM	Z788G Illustra
ZTE GSM	Beeline E600
ZTE GSM	Beeline Smart 2
ZTE GSM	G720T
ZTE GSM	G719C
ZTE GSM	Z777
ZTE GSM	T790 Pulse
ZTE GSM	B795 Icon Nero
ZTE GSM	Z793C Atrium
ZTE GSM	Z795G Solar
ZTE GSM	Digicel DL800
ZTE GSM	E810
ZTE GSM	E811
ZTE GSM	T815 Telstra Tempo
ZTE GSM	F852
ZTE GSM	F858
ZTE GSM	F880
ZTE GSM	Blubelt
ZTE GSM	Silverbelt
ZTE GSM	Tureis
ZTE GSM	P743T Skate
ZTE GSM	V795 Kis II
ZTE GSM	Z852 Fanfare 3
ZTE GSM	V857 Mimosa Mini

ZTE GSM	T870 Glide
ZTE GSM	V875 Easy A7
ZTE GSM	V880 Blade
ZTE GSM	Blade Vec 4G
ZTE GSM	V880G Blade G
ZTE GSM	Z971 Blade Spark
ZTE GSM	V970
ZTE GSM	990N Vodafone Smart 4 Max
ZTE GSM	F930
ZTE GSM	T930 Bubble Touch
ZTE GSM	Z930L Unico
ZTE GSM	F951E
ZTE GSM	Z958
ZTE GSM	Z959 Grand X3
ZTE GSM	V960 Skate
ZTE GSM	X960
ZTE GSM	Z962BL Max Duo
ZTE GSM	Z963VL Max Duo
ZTE GSM	Z965 Blade X
ZTE GSM	Z899VL Majesty Pro
ZTE GSM	Z970 ZMax
ZTE GSM	Z988 Grand X Max 2
ZTE GSM	X990
ZTE GSM	Z990 Avail
ZTE GSM	Z990G Merit
ZTE GSM	Z992 Avail 2
ZTE GSM	Z993 Prelude
ZTE GSM	Z995 Overture
ZTE GSM	Z998
ZTE GSM	N9136 Prestige 2
ZTE GSM	Z851 Prelude Plus
ZTE GSM	A2017 Axon 7
ZTE GSM	B2017G Axon 7 Mini
ZTE GSM	C2017 Axon 7 Max
ZTE GSM	A2017U Axon 7
ZTE GSM	P825T20 Turkcell T40
ZTE GSM	Z2321A
ZTE GSM	U9180 V5
ZTE GSM	N9517 Blade Force
ZTE GSM	Blade V1000 V1
ZTE GSM	Light Tab V9